



UWB Series modules AT Instruction Set

Version V1.0

Ai-Thinker John

Copyright (c) 2020

## Overview

This article describes theuWbSeries modulesATHow to use the command.

## Disclaimer and Copyright Notice

The information in this article, including for referenceURLAddresses are subject to change without notice.

The document is provided "as is" without any warranty of merchantability, fitness for a particular purpose or non-infringement. any warranty of any kind, and any warranty otherwise mentioned in any proposal, specification or sample. This document disclaims all liability, including This document shall not be construed as a liability for infringement of any patent rights arising from the use of the information in this document. No license, express or implied, is granted to you under any intellectual property rights.

All trade names, trademarks and registered trademarks mentioned herein are the property of their respective owners and are hereby acknowledged.

## Notice

Due to product version upgrades or other reasons, the contents of this manual may be changed. Shenzhen Anxinke Technology Co., Ltd. reserves the right to modify the contents of this manual without any notice or reminder. Shenzhen Anxinke Technology Co., Ltd. has made every effort to provide accurate information in this manual, but Shenzhen Anxinke Technology Ltd. does not guarantee that the contents of this manual are completely error-free, and all statements, information and suggestions in this manual do not constitute any warranties, express or implied.

## Revision History

date	Version	author	describe
2020.4.23	V0.0.0	Johhn	Initial release
2020.5.29	V1.0.0	Johhn	The number of base stations that can be added increases and recovery Factory settings
2020.9.16	V1.0.1	Johhn	Increasemaster_tagandslave_tag

--	--	--	--

## Table of contents

<b>1. Overview</b>	3
1.1 AT command abbreviations and conventions	3
1.2 AT command syntax	3
1.2.1 AT command syntax	3
<b>2. General Instructions</b>	5
2.1 AT test commands	5
2.2 AT+switchdis Set whether to enable ranging	5
2.3 AT+interval Set the distance measurement interval	5
2.4 AT+version query version	6

2.5AT+RST Reset.....	6
2.6AT+tem_hum Get temperature and humidity.....	6
2.7AT+xyz Get the three-axis acceleration.....	7
2.8AT+anchor_tag Set device mode.....	7

## 1. Overview

### 1.1 AT Command Abbreviations and Conventions

Send via serial portATCommand, you can useUBWmodule.

### 1.2 AT Command Syntax

All in the documentATThe command line must begin with "AT" As the beginning, with a carriage return (<CR>) as the ending.

The response is usually followed by the command, and its format is "<Enter><Line Feed><Response Content><Enter><Line Feed>"

(<CR><LF><Response content><CR><LF>").ATDuring the command introduction, only <response content> is introduced in detail.

In the process, <carriage return> and <line feed> are intentionally omitted.

#### 1.2.1 AT command syntax

All in the documentATThere are four types of commands:

Basic class commands: This classATThe command format is "AT<x><n>" or "AT&<x><n>", where "<x>" yes

The command comes with "<n>" This means that the command supports one or more parameters. For example:ATE<n>" , this command is used to close

Or enable the echo function, that isDCEWill be based on "n>" The value determines whether the received characters are echoed toDTE.n>" yes

Optional parameter. If no value is given, the default value will be used.

Parameter commands:ATThe command format is "ATS<n>=[<m>]" , where "<n>" yesSthe index of the register,

"<m>"is the parameter value assigned.ATIn the command, "<m>" Is an optional parameter. If no value is assigned,

default value.

Extension commands: Generally speaking, extension commands can be divided into the following types according to the operation format and application function:

AT	Format	Functional Description
Setting Instructions	AT+CXXX=n	This command is used to set the command or internal

		Program settings parameters
Query command	AT+CXXX?	This command is used to query the current value
Execute Instructions	1. AT+CXXX=<...>,<...> 2. AT+CXXX	This command is used to set user-defined parameters. Value and execute

## 2. General Instructions

### 2.1 AT test command

#### describe

This command is used to simply test whether the basic functions of the module are normal.

#### grammar

Execute Instructions	response
AT	OK

### 2.2 AT+switchdis Set whether to enable ranging

#### describe

This command controls whether to measure the distance, and is only valid in tag mode.

#### grammar

Execute Instructions	response
AT+switchdis=value	When value=0 When the distance measurement is turned off, return OK  When value=1 When the ranging function is turned on, the OK

### 2.3 AT+interval Set the distance measurement interval

#### describe

This command can set the ranging interval

#### grammar

Execute Instructions	response
AT+interval=value	OK

#### parameter

**<value>** Set the ranging interval

#### Remark

-The range is 5-50

-It sets the number of times data is acquired before the distance is output. The larger the value, the slower the refresh speed.

## 2.4 AT+version query version number

### describe

Query version number

### grammar

Execute Instructions	response
AT+version?	AIT-BU01-DB V000 T2020-4-17 OK

### Remark

-Get the manufacturer, module series and version number

## 2.5 AT+RST Reset

### describe

This command is used to reset the module.

### grammar

Execute Instructions	response
AT+RST	OK
<b>describe:</b>  Reset the module.	

## 2.6 AT+tem\_hum Get temperature and humidity

### describe

Get temperature and humidity information.

Syntax execution instructions	response
-------------------------------	----------

AT+tem_hum  <b>describe:</b>  Look up manufacturer information.	T:term  H:hum  OK
---	-------------------------------

**Remark**

-TemFor temperaturehumHumidity

## 2.7 AT+xyz Get three-axis acceleration

**describe**

Get three-axis acceleration information.

**grammar**

Execute Instructions  AT+xyz	response  x:num1  y:num2  x:num3  angle:num4  OK
------------------------------------	--

**Remark**

-X,y,zis the original data of three-axis acceleration,angleis the converted tilt angle

## 2.8 AT+anchor\_tag Set device mode

**describe**

This command sets the device mode andID.

**grammar**

Execute Instructions  AT+anchor_tag=model,ID	response  OK
--	--------------------



parameter

Model 1Yes Choiceanchormodel,0Yes Choicetagmodel

IDSetting up base stations and tagsID, from the beginning

Remark

- Base stationIDUp to four, tagstagMust existmaster\_tag,defaultIDfor0
- The factory firmware default isanchormodel

## 2.9 AT+FACTORY

describe

Restore factory settings.

grammar

Execute Instructions AT+FACTORY	response OK

Remark

-Default base station mode,IDfor0