


How to	URBS - Set Hume Release Forecast
Description	Create modifier to set Hume Release Forecast in URBS model
Comments	<i>italic</i> phrases taken from the book "Flood Forecasting: a Global Perspective". Please be aware that the screenshots may deviate slightly from the application
version	2016-01

Define multiple release patterns (Forecast and What-If scenario) on an hourly timestep.

Note: In the ensemble run only the Hume Release Forecast is considered, the What-If Hume Release Scenario is not.

Q_Release is by default empty (left column). The user can define a release pattern via the modifiers (right column). The set release pattern is used in the URBS run (see second figure of model output).



The defined release pattern can be visually checked against the total maximum, which is the sum of the maximum release via valves, hydro and spillway gates based on the level in the dam.

Note: Discharge is calculated via a conversion based on ReservoirOutletRatingTables, for which extrapolation is not allowed. This means that when the level in the dam is outside this range, no outflow discharge can be calculated or displayed.

