
















How to	Icons used on Map, Data Viewer and Status bar
Description	Description of part of the User Interface of ROWS
Comments	The <i>italic</i> phrases correspond to the red markings in the screenshots. Please be aware that the screenshots may deviate slightly from the application
version	2015-02



Icons used in the Map display and the Data Viewer display are not standard for every Delft-FEWS system. The icons used in ROWS are the following:

Location	Status: Validation (V) / Threshold (T)		
 Fluvial sites		V	data partly missing in view period
 Meteo sites		V	data completely missing in view period
 Storage sites		V	no data available at all
		V	data has been edited in view period
		V	soft limits are exceeded in view period
		V	hard limits are exceeded in view period
		T	Warning Level Major
		T	Moderate Flooding
		T	Warning Level Minor

The system status icon, on the right side of the status bar, indicates whether the system operates normally or severe errors are encountered. When a severe or fatal error is indicated in the status bar, this error can be analyzed with the System Monitor.

Icon	Description
	System is running normally, warnings may have been encountered
	System encountered severe errors
	System encountered fatal errors