

# GM862-GPS Software User Guide

GM862-GPS Software User Guide  
1vv0300729 Rev. 4 - 24/01/07



## Contents:

<b>1</b>	<b>Overview .....</b>	<b>4</b>
<b>2</b>	<b>Basic Operations .....</b>	<b>5</b>
2.1	Command Syntax .....	5
2.1.1	Interface Style.....	5
2.2	Command Response Timeout.....	6
2.3	Turning ON the GM862-GPS.....	9
2.4	Turning OFF the GM862-GPS.....	9
2.5	Checking GSM device functionality .....	10
2.5.1	Autobauding .....	10
2.5.2	SIM presence checking.....	11
2.5.3	Network checking.....	13
2.6	Placing a Voice call.....	19
2.6.1	Voice call device set up .....	19
2.6.2	Phone number dialing.....	21
2.6.3	Closing the voice call .....	22
2.7	Placing a CSD Data call (not GPRS) .....	23
2.7.1	Data call device set up .....	23
2.7.2	Phone number dialing (data call).....	24
2.7.3	Closing the Data call.....	25
2.8	Answer an incoming Call.....	26
<b>3</b>	<b>Advanced Operations .....</b>	<b>28</b>
3.1	Accessing the phonebook .....	28
3.1.1	Preliminary phonebook set up .....	28
3.1.2	Phonebook entry search by Name .....	32
3.1.3	Phonebook entry read by Index .....	33
3.1.4	Phonebook entry Write.....	34
3.1.5	Phonebook entry Delete.....	36
3.1.6	Phonebook entry Dial .....	37
3.2	Distinguish Calls .....	39
3.2.1	Identify the Call type .....	39
3.2.2	Identify the Caller .....	40
3.2.3	Restricting Calling Line Indication .....	41
3.2.4	Call Barring Control .....	43
3.3	DTMF tones .....	52
3.4	GSM Power Saving function .....	53
3.5	SMS handling.....	55
3.5.1	SMS device setup .....	55



3.5.2	IRA character set .....	66
3.5.3	Writing a New SMS to storage.....	68
3.5.4	Sending an SMS previously stored.....	70
3.5.5	Sending a new SMS without storing it .....	71
3.5.6	Deleting an SMS.....	73
3.5.7	Reading an SMS .....	74
3.5.8	Listing a group of SMSs.....	76
<b>3.6</b>	<b>Using General Purpose Input/Output pins.....</b>	<b>78</b>
3.6.1	GPIO pin setup .....	78
3.6.2	GPIO pin use .....	80
<b>3.7</b>	<b>Clock/Alarm function.....</b>	<b>84</b>
3.7.1	Clock date/time.....	84
3.7.2	Alarm function.....	86
<b>4</b>	<b>GPRS operations .....</b>	<b>91</b>
<b>4.1</b>	<b>Introduction .....</b>	<b>91</b>
4.1.1	CSD application example .....	93
4.1.2	GPRS application example .....	94
<b>5</b>	<b>GPS operations .....</b>	<b>95</b>
<b>5.1</b>	<b>Introduction .....</b>	<b>95</b>
<b>5.2</b>	<b>GM862-GPS Serial Ports .....</b>	<b>95</b>
5.2.1	GPS SERIAL PORT B (NMEA).....	95
<b>5.3</b>	<b>WGS 84.....</b>	<b>95</b>
<b>5.4</b>	<b>NMEA 0183.....</b>	<b>96</b>
5.4.1	GGA - Global Positioning System Fixed Data.....	97
5.4.2	GLL - Geographic Position - Latitude/Longitude .....	98
5.4.3	GSA - GNSS DOP and Active Satellites.....	99
5.4.4	GSV - GNSS Satellites in View .....	100
5.4.5	RMC - Recommended Minimum Specific GNSS Data .....	101
5.4.6	VTG - Course Over Ground and Ground Speed .....	102
<b>5.5</b>	<b>Checking GPS device functionality.....</b>	<b>103</b>
<b>5.6</b>	<b>CONTROLLING GPS RECEIVER.....</b>	<b>103</b>
5.6.1	POWER CONTROL OF GPS RECEIVER .....	103
5.6.2	GPS RESET.....	104
5.6.3	GPS ANTENNA MANAGEMENT.....	105
5.6.4	GPS PARAMETERS SAVE.....	106
5.6.5	RESTORE GPS PARAMETERS.....	106
5.6.6	READ ACQUIRED GPS POSITION .....	106
<b>6</b>	<b>Service and firmware update.....</b>	<b>108</b>
6.1	Step-by-Step upgrade procedure .....	108
<b>7</b>	<b>Document Change Log .....</b>	<b>111</b>



# 1 Overview

The purpose of this document is the description of some common AT command procedures that may be used with the **Telit GM862-GPS module**.

In this document, all the basic functions of a mobile phone will be taken into account and for each one of them, a proper command sequence will be suggested.

In the Advanced operation section the more useful services and features of the GSM network supported by the **Telit GM862-GPS module** is taken into account and some command sequence and usage are provided for each one of them.

This document and its suggested command sequences shall not be considered mandatory; instead, the information given shall be used as a guide for properly using the **Telit module**. For further commands and features that may not be explained in this document refer to the GM862-GPS Product Description document where all the supported AT commands are reported.

## NOTE

*The information presented in this document is believed to be accurate and reliable. However, Telit Communications S.p.A. assumes no responsibility for its use, nor any infringement of patents or other rights of third parties, which may result from its use. No license is granted by implication or otherwise under any patent rights of Telit Communications S.p.A. other than for circuitry embodied in Telit products. This document is subject to change without notice.*



## 2.1 Command Syntax

<cr>	represents the Carriage Return Character (13)
<lf>	represents the Line Feed Character (10)
<xx>	represents a parameter whatever name is in place of the xx. (< and > characters are only for delimiting the parameter and <b>must not</b> be issued to the terminal).
[<xx>]	represents an optional parameter whatever name is in place of the xx. ([ and ] characters are only for delimiting the optional parameter and <b>must not</b> be issued to the terminal).

### 2.1.1 Interface Style

The GM862-GPS module is using an AT interface that is defined in the document 80000ST10025a (AT Commands Reference Guide). The specification defines 3 possible AT interfaces:


1 – AT interface of the products, to the GM862-PCS, PYTHON, QUAD-PY, TRIZIUM and GM862-QUAD, PY interface style

2 - switches the AT command interface style of the product, to the new products like GE864, GC864 and the GPS products

The default interface for the GM862-GPS product is 2.

The switch between the different interfaces could also be performed with the **#SELINT** AT command. Refer to the AT Commands Reference Guide for the full command description.

All the AT commands described in this specification is related to SELINT 2





## 2.2 Command Response Timeout

Every command issued to the Telit GM862-GPS returns a result response if response codes are enabled (default) (see command ATQn). The time needed to process the given command and return the response varies from command to command and may depend also from the network on which the command may interact. As a result every command is provided with a proper timeout time, if this time elapses without any result from the operation, then the ERROR response is reported as if the operation was not successful.

The timeout time is quite short for commands that imply only internal set up commands, but may be very long for command that interact with the network (or even Networks).



**NOTE:** *In case no response is received after the timeout time has been elapsed, then try repeating the last command and if still no response is received until the timeout time, then an Unconditional Shutdown MUST be issued and then the device shall be powered ON again.*

In the table below are listed all the commands whose timeout differs from the default **100 ms** and their effective timeout is reported:

Command	Time-Out (Seconds)
+CBST	0.2
+CR	0.2
+CRC	0.2
+CRLP	0.2
+CSCS	0.2
+CEER	5
+CGMI	5
+CGMM	5
+CGMR	5
+CGSN	20
+CIMI	20
+CNUM	20
+CREG	5
+COPS	180
+CLCK	180
@CLCK	180
+CPWD	180
+CLIP	180
+CLIR	180
+CCFC	180
+CCWA	20
+CHLD	20
+CUSD	180
+CAOC	20
+CSSN	20



Command	Time-Out (Seconds)
+CLCC	20
+CPAS	5
+CPIN	20
+CSQ	5
+CPBS	5
+CPBR	20
+CPBF	20
+CPBW	20
+CALM	5
+CRSL	5
+CLVL	5
+CMUT	5
+CACM	20
+CMM	20
+CPUC	20
+CMEE	5
+VTS	20
+GMI	5
+GMM	5
+GMR	5
+GSN	20
I3	5
I4	5
I5	5
+CSMS	5
+CPMS	5
+CMGF	5
+CSCA	20
+CSMP	5
+CSDH	5
+CSAS	5
+CRES	5
+CNMI	5
+CMGS	180 / 5 for prompt">"
+CMSS	180
+CMGW	5 / 5 for prompt">"
+CMGD	5
+CMGR	5
+CMGL	5
#CAP	10
#SRS	10
#SRP	10
#STM	10
#PCT	10



Command	Time-Out (Seconds)
#SHDN	10
#QTEMP	10
#SGPO	10
#GGPI	10
#MONI	10
#CGMI	5
#CGMM	5
#CGMR	5
#CGSN	20
#CIMI	5
+CGACT	180
+CGATT	180
+CGDATA	20
+CGDCONT	20
+CGPADDR	20
+CGQMIN	20
+CGQREQ	20





## 2.3 Turning ON the GM862-GPS

To turn on the GM862-GPS the pin ON# must be tied low for at least 1 second and then released. To check if power has raised it is possible to monitor the PWRMON line, when this line goes high the module is powered on, but before it remains on the device needs other 900ms for software startup. Hence check the PWRMON line and 900 ms after its transition to high it is possible to release the ON# pin.

When turning on the module, both devices (GSM and GPS) will be started.

The GPS antenna will be supplied and the receiver will start the scanning activity to achieve the Fix.

## 2.4 Turning OFF the GM862-GPS

The turning off of the device can be done in two ways:

- by software command
- by hardware shutdown (refer to Hardware User Guide)

When the device is shut down by software command or by hardware shutdown, it issues to the network a detach request that informs the network that the device will not be reachable any more.

### 2.4.1.1 Software shutdown

- Send command **AT#SHDN<cr>**
- wait for **OK** response

The device shuts down with the following sequence of activities:

- Detach from the network
- Module Shutdown

In the case of Network unavailability the detach will be attempted few seconds (typical 6secs). After this timeout the module will be shut down.



## 2.5 Checking GSM device functionality

After a proper power on the device is ready to receive AT commands on the serial port. Several things have to be checked in order to be sure that the device is ready to send and receive calls and SMS:

### 2.5.1 Autobauding

At startup it is necessary to send an AT command to make the device set the right speed and character format of the serial port. When this is done the device responds with OK. If no response is received within the timeout period of 200 ms retry.

- Send command **AT<cr>**
- wait for **OK** response

after this initial command, it is advisable to fix the port rate, in order to eliminate possible errors in detecting the serial speed rate:

- Send command **AT+IPR=<rate><cr>**
- wait for **OK** response

where rate is the port speed and can be 0, 300,1200,2400,4800,9600,19200,38400,57600,115200 bps.

If **<rate>** is set to 0, then automatic speed detection is enabled and also character format (see **+ICF**) is set to auto-detect. (default)

If **<rate>** is specified and not 0, **DTE-DCE** speed is fixed at that speed, hence no speed auto-detection (autobauding) is enabled.



---

**TIP: The serial port suggested setting is: port speed 38400, character format 8N1 (8 bit per char, No parity bit, 1 stop bit).**

---



## 2.5.2 SIM presence checking

After autobauding the first thing to check is the SIM presence and PIN code insertion, this can be done with the following commands:

### 2.5.2.1 Enable the Extended error result codes

- send command **AT+CMEE=1<cr>**
  - wait for **OK** response
- or if you prefer the verbose format instead of the numerical format then:
- send command **AT+CMEE=2<cr>**
  - wait for **OK** response

### 2.5.2.2 Query SIM presence and status

- send command **AT+CPIN?<cr>**
- wait for response:


Response	Reason	Action
+CPIN: SIM PIN	SIM is present and PIN is required to continue operations	Proceed to par. 2.5.2.3
+CPIN: SIM PUK	SIM is present and 3 attempts to give SIM PIN have failed, so SIM PUK is required	Send command AT+CPIN=<SIM PUK>
+CPIN: READY	SIM is present and no PIN code is required to proceed	Proceed ahead
+CME ERROR: 10	SIM not present	Insert SIM or require SIM insertion and repeat from par. 2.5.2.2
+CME ERROR: 13	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. 2.5.2.2
+CME ERROR: 14	SIM is busy	retry later
+CME ERROR: 15	SIM is wrong type	Check SIM, it must be a GSM SIM.



### 2.5.2.3 Provide SIM PIN (only if required see point 2.5.2.2)

- send command **AT+CPIN=\*\*\*\*<cr>**  
where \*\*\*\* stands for the SIM PIN code (e.g. 1234)
- wait for response:


Response	Reason	Action
OK	SIM PIN was correct	Proceed ahead
ERROR	the PIN code inserted is not correct	Retry from par. 2.5.2.2

 **NOTE:** When receiving the **ERROR** message, repeat Query SIM presence and status since after 3 failed attempts SIM PIN is not anymore requested, but SIM PUK is requested instead, hence you may need to go through procedure 2.5.2.4

### 2.5.2.4 Provide SIM PUK (only if required see par. 2.5.2.2)

- send command **AT+CPIN=\*\*\*\*\*,<newpin><cr>**  
where \*\*\*\*\* stands for the SIM PUK code (e.g. 12345678) and <newpin> (e.g. 1234) will replace the old pin in the SIM.
- wait for response:


Response	Reason	Action
OK	SIM PUK was correct	Proceed ahead
ERROR	the SIM PUK code inserted is not correct	Retry from par. 2.5.2.4

 **TIP:** When receiving the **ERROR** message, be careful to check if the SIM PUK is correct before retrying, since after 10 failed attempts to provide the SIM PUK the SIM Card will lock and will not be usable anymore.



### 2.5.3.1 Query network status

- | Response                       | Reason   | Action   |
|--------------------------------|--|--|
| +CME ERROR: 10                 | SIM not present or damaged   | Check SIM or require SIM insertion and repeat from par. 2.5.2.2  |
| +CME ERROR: 11                 | SIM is present and PIN is required to continue operations  | Repeat par. 2.5.2.3  |
| +CREG: 0,0<br>or<br>+CREG: 1,0 | No GSM/DCS network is found  | Check for antenna cable connection (antenna may be disconnected or damaged) or change position if the antenna is OK. Repeat par. 2.5.3.1 until a network is found. |
| +CREG: 0,1<br>or<br>+CREG: 1,1 | Mobile is registered on its home network.  | Proceed ahead. Ready to call   |
| +CREG: 0,2<br>or<br>+CREG: 1,2 | Mobile is currently not registered on any network but is looking for a suitable one to register.         | Repeat procedure at par. 2.5.3.1 to see if it has found a suitable network to register in.   |
| +CREG: 0,3<br>or<br>+CREG: 1,3 | Mobile has found some networks but it is not allowed to register on any of them, no roaming was allowed. | Try in another place, and repeat procedure at par.2.5.3.1  |
| +CREG: 0,4<br>or<br>+CREG: 1,4 | Mobile is in an unknown network status   | Repeat procedure at par.2.5.3.1 to see if it has found a suitable network to register in   |
| +CREG: 0,5<br>or<br>+CREG: 1,5 | Mobile has found some networks and is currently registered in roaming on one of them                     | Proceed ahead. Ready to call   |





### 2.5.3.2 Network operator identification

Once the mobile has registered on some network (or even if it has returned +CREG:x,3), it is possible to query the mobile for network identifications codes and names:

- send command **AT+COPS=?<cr>**
- wait for response in the format:

**+COPS:** [list of supported (<stat> ,<oper (in <format>=0)>,,  
<oper (in <format>=2)>)s][,,(list of supported <mode>s),  
(list of supported<format>s)]

where:

**<stat>** - operator availability

- 0 - unknown
- 1 - available
- 2 - current
- 3 - forbidden

**<format>**

- 0 - alphanumeric long form (max length 16 digits)
- 2 - numeric 5 digits [country code (3) + network code (2)]

**<oper>**: network operator in format defined by **<format>** parameter.

Note: since with this command a network scan is done, this command may require some seconds before the output is given.

For example:

*command:*

AT+COPS=?<cr>

*Answer:*

+COPS: (2,"I WIND",,"22288"),(1,"SI MOBITELE GSM",,"29341"),(1,"vodafone IT",,"22  
210"),(1,"SI.MOBIL",,"29340"),(3,"I TIM",,"22201"),(0-4),(0,2)

OK

In this case the mobile is registered on the network " I WIND " which is a network from Italy Nation code :222 and Network ID: 88. There is also another network available for registration: "SI MOBITELE GSM" which is a network from Slovenia Nation Code:293 and Network ID: 41 , "SI.MOBIL" which is a network from Slovenia Nation Code:293 and Network ID: 40 and Vodafone IT from Italy with Nation code 22 and Network 10.

The other network is not available for registration:

" I TIM " from Italy Nation code :222 and Network ID: 01 - FORBIDDEN



**TIP:** In this case a "I WIND" logo might be reproduced on the MMI to give the user the information that is registered on that network.







**NOTE:** *this command issues a network request and it may require a quite long time to respond, since the device has to wait the answer from the network (it can be as long as 60 seconds). Hence don't use it if not needed.*

### 2.5.3.3 Check for received signal strength & quality

Once the mobile has registered on one network, it may be useful to know the received signal strength & quality to give the user an indication of the reliability of the network.

- send command **AT+CSQ<cr>**
- wait for response in the format:  
**+CSQ: <rss>,<ber>**


OK


where:


<rss> is an integer from 0 to 99 that indicates the received signal strength:


<rss> value	Signal strength	Indication
0	-113 dBm or less	Signal is VERY low: at the extreme sensibility limit
1	-111 dBm	MMI may indicate only 1 antenna bar
2	-109 dBm	MMI may indicate only 1 antenna bar
3	-107 dBm	MMI may indicate only 1 antenna bar
4	-105 dBm	MMI may indicate only 1 antenna bar
5	-103 dBm	MMI may indicate only 1 antenna bar
6	-101 dBm	MMI may indicate 2 antenna bars
7	-99 dBm	MMI may indicate 2 antenna bars
8	-97 dBm	MMI may indicate 2 antenna bars
9	-95 dBm	MMI may indicate 2 antenna bars
10	-93 dBm	MMI may indicate 3 antenna bars
11	-91 dBm	MMI may indicate 3 antenna bars
12	-89 dBm	MMI may indicate 3 antenna bars
13	-87 dBm	MMI may indicate 3 antenna bars
14	-85 dBm	MMI may indicate 3 antenna bars
15	-83 dBm	MMI may indicate 4 antenna bars
16	-81 dBm	MMI may indicate 4 antenna bars
17	-79 dBm	MMI may indicate 4 antenna bars
18	-77 dBm	MMI may indicate 4 antenna bars
19	-75 dBm	MMI may indicate 4 antenna bars
20	-73 dBm	MMI may indicate 4 antenna bars
21	-71 dBm	MMI may indicate 4 antenna bars
22	-69 dBm	MMI may indicate 4 antenna bars
23	-67 dBm	MMI may indicate 4 antenna bars
24	-65 dBm	MMI may indicate 4 antenna bars
25	-63 dBm	MMI may indicate 4 antenna bars
26	-61 dBm	MMI may indicate 4 antenna bars




 **NOTE:** when <rss> is less than 6, only 1 MMI antenna bar, the quality of a call will be poor and the call may even drop.

 **NOTE:** The quality is measured on the traffic channel, hence it is available only during a conversation, in Idle the reported value must not be considered.  
In conversation the quality decreases with the increase of the <ber> number.

 **NOTE:** The <ber> value refers strictly to the GSM radio channel and is a very technical parameter, it can be used to monitor the voice call quality since the voice quality is inversely proportional to the <ber> number.

 **NOTE:** For Data calls the signal quality reported is not directly connected to the connection quality. The reported signal quality refers only to the GSM radio channel link and not to the whole path from the caller to the receiver, so it may happen that the quality on the GSM radio link is very good and hence the reported <ber> is 0 (good quality) but the quality of the remaining path to the other party is very bad and hence the final data connection quality is very poor.

For this reason the signal quality indicator <ber> should not be taken into account to monitor data calls quality.



### 2.5.3.4 Quick Network Status Checking

Once the mobile has registered on one network, it may be useful to know the received signal strength and the network on which the mobile is registered. These information can be gathered with the commands +CREG, +COPS and +CSQ, which are part of the standard ETSI GSM 07.07 commands as seen before, unfortunately these commands are not so fast in the response due to network response time, especially the +COPS command. If You want to keep your software as general as possible you can follow the indications given before and forget this part; instead if you need or want a faster way to check at the mobile network information, the GM862-GPS provides a special command **#MONI** which can be used to gather all the information needed in a faster and simpler way:

- send command **AT#MONI=0<cr>**
- wait for **OK** response
  
- send command **AT#MONI?<cr>**
- wait for response in the format:  
**#MONI: <netname> BSIC:<bsic> RxQual:<qual> LAC:<lac> Id:<id> ARFCN:<arfcn>  
PWR:<dBm> dBmTA: <timadv>**

**OK**

or in the case the network name is not known:

**#MONI: Cc:<cc> Nc:<nc> BSIC:<bsic> RxQual:<qual> LAC:<lac> Id:<id> ARFCN:<arfcn>  
PWR:<dBm> dBm TA: <timadv>**

**OK**

#### where:

<netname> = name of network operator  
<cc> = country code  
<nc> = network operator code  
<n> = progressive number of adjacent cell  
<bsic> = base station identification code  
<qual> = quality of reception (0-7) (same as <ber> of +CSQ command)  
<lac> = localization area code  
<id> = cell identifier  
<arfcn> = assigned radio frequency channel  
<dBm> = received signal strength in dBm (same as "decoded" rssi value)  
<timadv> = timing advance



For example:

command:

AT#MONI=0<cr>

Answer:

OK

command:

AT#MONI?<cr>

Answer:

#MONI: I TIM BSIC:23 RxQual:7 LAC:AEAD Id:5265 ARFCN: 59 PWR: -80 dBm TA:0

OK

In this case the mobile is registered on the network "I TIM", the signal strength is -80dBm (MMI may indicate 4 antenna bars as reported on the table 5). The other information received is strictly technical and should not be given to the user.

For example2:

command:

AT#MONI=0<cr>

Answer:

OK

command:

AT#MONI?<cr>


Answer:

#MONI: Cc: 010 Nc: 03 BSIC:23 RxQual:7 LAC:0001 Id:0001 ARFCN: 60 PWR: -83 dBm TA:0

OK

In this case the mobile is registered on the network whose Country code is 010 and Network operator code is 03, the signal strength is -83dBm (MMI may indicate 4 antenna bars as reported on the table 5). The other information received is strictly technical and should not be given to the user. The values reported are random and have no meaning they are used only to explain command usage.

---

 **NOTE:** This command should be used only to gather information on network name and signal strength, to check if mobile is registered or is looking for a suitable network to register to, use always the +CREG command. This is due to the fact that if the network signal is too weak and mobile loses the registration, until a new network is found the #MONI command reports the last measured valid values and not the real ones.  
The TA (timing advance parameter) is valid only during a call.

---

 **TIP:** To properly use this feature, check network registration with command +CREG as seen on par. 2.5.3.1 and when mobile is registered query the mobile for network operator name and signal strength with #MONI command.

---



## 2.6 Placing a Voice call

Before a voice call can be placed, it is recommended to check if the mobile is registered on a network (see par. 2.5.3.1) and if the signal strength is enough to ensure a call can be made (see par. 2.5.3.2).

### 2.6.1 Voice call device set up

#### 2.6.1.1 Set the device in voice mode

- Send command **AT+FCLASS=8<cr>**
- wait for **OK** response

**NOTE:** This command may be omitted if the modifier ";" is added at the end of the ATD command after the number to be dialed.

#### 2.6.1.2 Set the desired audio path active

The GM862-GPS has two different audio paths:

- internal microphone/ear (MT)
- external microphone/ear (HF)

Usually the internal path is used for a handset function, while the external is used for handsfree function. There are two way to switch between these two paths:

- SOFTWARE: by using the command AT#CAP= <n> (with n=1 OR n=2)
- HARDWARE: by setting AT#CAP=0 and setting the AXE input high (internal MT) or low (external HF).

If only one path is needed, then it is preferable to use the internal one (MT).



---

**TIP: when Hardware control is not needed AXE pin can be left unconnected.**

---



---

**TIP: the audio paths can be switched also during a call in both ways.**

---

- Send command **AT#CAP=<n><cr>**

**where:**

- <n> = 0 for HARDWARE control with AXE input
- <n> = 1 for external HF path (regardless of the AXE input status)
- <n> = 2 for internal MT path (regardless of the AXE input status)

- wait for **OK** response





For example:

1 - Let's assume that the desired audio path is always the internal MT

Command:

AT#CAP=2<cr>

Answer:

OK

2 - Let's assume that the desired audio path has to be determined by HARDWARE pin AXE

Command:

AT#CAP=0<cr>

Answer:

OK

Now set the hardware pin AXE in the desired status.

### 2.6.1.3 Set the desired volume on the active audio path speaker output

This setting is not strictly necessary; it is also possible to keep the default volume setting.

- Send command **AT+CLVL=<vol><cr>**

where:

**<vol>** is a number between 0 and 10 representing the volume setting:

0 – minimum volume

10 - maximum volume

- wait for **OK** response



**NOTE:** The volume setting refers to the ACTIVE path ear line and is stored each time. When changing audio path the volume setting will be reset to the previously stored value for that audio path.





#### 2.6.1.4 Check for microphone mute setting

The microphone of the active path can be muted with an AT command; to be sure that it is not muted, it is suggested to check it with this command:

- Send command **AT+CMUT?<cr>**
- wait for response in the format:  
**+CMUT: <mute>**

OK

**where:**

<mute> is the muting setting for the microphone:  
0 - microphone active  
1 - microphone muted



**NOTE: The mute setting is different from Volume setting: it refers to both the audio paths, the mute setting will remain even when changing audio path.**

### 2.6.2 Phone number dialing

#### 2.6.2.1 Dial a given phone number

- Send command **ATD <PhoneNumber><cr>**

**where:**

**<PhoneNumber> is the phone number to be dialed**

- wait for response:

Response	Reason	Action
OK	The call has been placed	Wait for the other party to lift the receiver..
BUSY	The line called is busy	retry later
NO ANSWER	The receiver did not answer the call	retry later
NO CARRIER	Call placing has not been successful	check for mobile registration and signal strength (par. 0)



1- Let's assume you have to call the national number 040 - 4192111,

ATD 0404192111<cr>

OK,

*command:*

*response*

OK

*command:*

*response*

OK,

### 2.6.3.1 Hang up the voice call

- Send command **ATH<cr>**
- wait for response **OK**



## 2.7 Placing a CSD Data call (not GPRS)

Before a data call can be placed, it is recommended to check if the mobile is registered on a network (see par. 2.5.3.1) and if the signal strength is enough to ensure that a call can be made (see par. 2.5.3.2).

### 2.7.1 Data call device set up

#### 2.7.1.1 Set the device in data mode

- Send command **AT+FCLASS=0<cr>**
- wait for **OK** response



**TIP:** The +FCLASS setting is maintained in memory, so there's no need to repeat this command if +FCLASS setting is not changed.

#### 2.7.1.2 Set the desired modulation and speed for the connection

The data connection can be made using different modulations at different speeds.

This connection mode can be selected with the command +CBST. The syntax for the command is:  
AT+CBST=<mod>,0,<ce>

These parameters can be selected as seen in the table:

Command	Modulation	Speed [bps]	Connection Element
AT+CBST==0, 0, 1	Autobauding	----	non transparent
AT+CBST==1, 0, 1	V.21	300	non transparent
AT+CBST==2, 0, 1	V.22	1200	non transparent
AT+CBST==3, 0, 1	V.23	1200/75	non transparent
AT+CBST==4, 0, 1	V.22Bis	2400	non transparent
AT+CBST==6, 0, 1	V.32	4800	non transparent
AT+CBST==7, 0, 1	V.32	9600	non transparent
AT+CBST==14, 0, 1	V.34	14400	non transparent
AT+CBST==65, 0, 1	V.110	300	non transparent
AT+CBST==66, 0, 1	V.110	1200	non transparent
AT+CBST==68, 0, 1	V.110 / X.31	2400	non transparent
AT+CBST==70, 0, 1	V.110 / X.31	4800	non transparent
AT+CBST==71, 0, 1	V.110 / X.31	9600	non transparent
AT+CBST==75, 0, 1	V.110 / X.31	14400	non transparent



AT+CBST==1, 0, 0	V.21	300	transparent
AT+CBST==2, 0, 0	V.22	1200	transparent
AT+CBST==3, 0, 0	V.23	1200/75	transparent
AT+CBST==4, 0, 0	V.22Bis	2400	transparent
AT+CBST==6, 0, 0	V.32	4800	transparent
AT+CBST==7, 0, 0	V.32	9600	transparent
AT+CBST==65, 0, 0	V.110	300	transparent
AT+CBST==66, 0, 0	V.110	1200	transparent
AT+CBST==68, 0, 0	V.110 / X.31	2400	transparent
AT+CBST==70, 0, 0	V.110 / X.31	4800	transparent
AT+CBST==71, 0, 0	V.110 / X.31	9600	transparent

Once selected the appropriate <mod> and <ce> parameters from the table:

- Send command **AT+CBST=<mod>,0,<ce><cr>**
- wait for **OK** response

## 2.7.2 Phone number dialing (data call)

### 2.7.2.1 Dial a given phone number

- Send command **ATD <PhoneNumber><cr>**  
where:  
**<PhoneNumber>** is the phone number to be dialed

- wait for response:

Response	Reason	Action
CONNECT 9600	The called modem is now on line.	exchange data..
BUSY	The line called is busy	retry later
NO ANSWER	The receiver did not answer the call	retry later
NO CARRIER	The modem handshaking has not been successful	check for mobile registration and signal strength and eventually retry.



**TIP: The response to the ATD command is returned after the modem handshaking, this takes about 30 seconds, so allow this time before doing anything.**





1- Let's assume you have to call the national number 040 - 4192111,

ATD 0404192111<cr>

## CONNECT 9600



ATD +39404192111<cr>

## CONNECT 9600

ATD +386404192111<cr>

## CONNECT 9600

- Send escape sequence **+++**
- wait the escape sequence pause time ( see S12 parameter)
- wait for response **OK**





- Send command **ATH<cr>**
- wait for response **NO CARRIER**



When an incoming call is detected the device reports an unsolicited code which may be:


Unsolicited code	Reason
RING	The extended format of incoming call indication is disabled and a call (voice or data) is incoming.
+CRING: VOICE	The extended format of incoming call indication is enabled and a voice call is incoming.
+CRING: ASYNC	The extended format of incoming call indication is enabled and an asynchronous transparent data call is incoming.
+CRING: REL ASYNC	The extended format of incoming call indication is enabled and an asynchronous reliable (not transparent) data call is incoming.
+CRING: SYNC	The extended format of incoming call indication is enabled and a synchronous transparent data call is incoming.
+CRING: REL SYNC	The extended format of incoming call indication is enabled and a synchronous reliable (not transparent) data call is incoming.
+CRING: FAX	The extended format of incoming call indication is enabled and a fax call is incoming.





- Send command **ATA<cr>**
- wait for response:

Response	Reason	Action
CONNECT 9600	The incoming call was a DATA one and called modem is now on line.	exchange data..
ERROR	No incoming call is found, call may have been lost	call lost
NO CARRIER	The incoming call was a DATA one and the modem handshaking has not been successful	check for mobile registration and signal strength and modem settings.
OK	The incoming call was a VOICE call and is now active.	proceed ahead



## 3 Advanced Operations

### 3.1 Accessing the phonebook

The GM862-GPS can access the phonebook storage of the SIM card inserted, by using specific AT commands it is possible to store and recall phone numbers and their associated name.

#### 3.1.1 Preliminary phonebook set up

The GM862-GPS supports several SIM phonebook storages:

- "SM" - SIM phonebook  
This is the PB used to store and recall numbers during the normal operation of the device.
- "FD" - SIM fixed dialing-phonebook (only phase 2/2+ SIM)  
This PB has several restrictions; to set it you need the PIN2 code and after having activated the FD only the calls to the numbers stored in the FD or their children are allowed, all the other calls are forbidden.
- "LD" - SIM last-dialing-list (+CPBW and +CPBF are not applicable for this storage)  
This is the list of the last dialed numbers, it is updated automatically at each call originated and insertion or search on it is not possible, the only operations allowed are recall, read and delete.
- "MC" - SIM missed-calls-list (+CPBW and +CPBF are not applicable for this storage)  
This is the list of the missed calls calling numbers, it is updated automatically at each call missed and insertion or search on it is not possible, the only operations allowed are recall, read and delete.
- "RC" - SIM received-calls-list (+CPBW and +CPBF are not applicable for this storage)  
This is the list of the received calls calling numbers, it is updated automatically at each call received and insertion or search on it is not possible, the only operations allowed are recall, read and delete.

In order to access the storage you have to choose which one will be active. This must be the first PB operation always. Once selected storage, it is not anymore needed to select it again until the desired storage remains the one active and the device is not turned off.



### 3.1.1.1 Selecting PB storage active

- Send command **AT+CPBS=<PB><cr>**

where:

**<PB>** is the desired PB storage:

- SM – SIM phonebook
- FD – fixed dialing phonebook
- LD – last dialed calls list
- MC – missed calls list
- RC – received calls list

- wait for response:

Response	Reason	Action
OK	selected PB is now active	Proceed ahead
ERROR	some error occurred	Enable extended result codes (see par. 2.5.2.1) and retry.
+CME ERROR: 10	SIM not present	Check SIM or require SIM insertion and repeat from par. 2.5.2.2
+CMS ERROR: 310	SIM not present	Check SIM or require SIM insertion and repeat from par. 2.5.2.2
+CME ERROR: 11	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 2.5.2.3)
+CMS ERROR: 311	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 2.5.2.3)
+CME ERROR: 12	SIM is present and PUK is required to continue operations	insert SIM PUK (see par.2.5.2.4)
+CMS ERROR: 316	SIM is present and PUK is required to continue operations	insert SIM PUK (see par.2.5.2.4)
+CME ERROR: 13	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. 2.5.2.2
+CMS ERROR: 313	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. 2.5.2.2
+CME ERROR: 14	SIM is busy	retry later
+CMS ERROR: 314	SIM is busy	retry later
+CME ERROR: 15	SIM is wrong type	Check SIM, it must be a GSM SIM.
+CMS ERROR: 315	SIM is wrong type	Check SIM, it must be a GSM



+CME ERROR: 17	PIN2 is required to continue operations, since FD facility is not enabled.	SIM. Enable FD facility with +CLCK (see par.3.1.1.2) and retry.
----------------	--	--

**NOTE:** After power up & PIN authentication the device reads all the SIM for a backup, hence SIM access is inhibited (SIM is busy after the issue of the PIN or after power up if PIN request is disabled) for a time varying from few seconds to about a minute, depending on the percentage of written records in the SIM phonebook. If Phonebook commands are issued during this time the device returns an error message. If this happens, retry the operations later.

**NOTE:** Due to the particular features of the FD storage, when selecting the FD storage, the PIN2 must have been inserted or the FD facility must have been enabled. If +CPBS command reports +CME ERROR: 17 then enable the facility with command +CLCK (see par. 3.1.1.2)

For example:

1- Let's assume you want to select the "SM" normal phonebook for operations,

command:

AT+CPBS="SM"<cr>

response

OK

2- Let's assume you want to select the "MC" missed calls list for operations,

command:

AT+CPBS="MC"<cr>

response

OK

### 3.1.1.2 Enable Fixed Dialing Phonebook facility (only for FD PB)

- Send command **AT+CLCK=FD,1,<PIN2><cr>**

where:


**<PIN2>** is the PIN2 code of the SIM.

- wait for response:

Response	Reason	Action
OK	FD facility is now enabled	Return to select PB (see par. 3.1.1.1)
ERROR	some error occurred	Enable extended result codes (see par. 2.5.2.1), check if the PIN2 is correct



		and retry.
+CME ERROR: 16	the inserted PIN2 is wrong	Check PIN2 code and retry.

 **NOTE:** When receiving the **ERROR** or **+CME ERROR** message, repeat Query SIM presence and status since after 3 failed attempts SIM PIN2 is not anymore requested, but SIM PUK2 is requested instead, hence you may need to go through procedure 2.5.2.4 (but insert PUK2 instead of PUK1)



### 3.1.2 Phonebook entry search by Name

As first thing, you must select the "SM" storage as active (see par.3.1.1.1).

- send command **AT+CPBF=<Name><cr>**

where:

**<Name>** is the desired string to be found in the name field of the PB record.

- wait for response in the format:

**+CPBF= <index>,"<number>",<type>,"<name>"**  
**OK**

where:

**<index>** is the record number on the PB;

**<Number>** is the phone number;

**<type>** is the type of number:

145 – international numbering scheme

129 – national numbering scheme

**<Name>** is the alphanumeric name associated with the number.

or in the case no corresponding entries are found:

**+CME ERROR: 22** or simply **ERROR**.

---

 **NOTE: The search for <name> string is not case sensitive and the string may or may not be included in double brackets.**

---

For example:

1- Let's assume you want to select the "SM" normal phonebook for operations,

*command:*

**AT+CPBS="SM"<cr>**

*response*

**OK**

- Now you might want to look for the entries with the name starting with: "FA"

*command:*

**AT+CPBF="FA"<cr>**

*the response may look like:*

**+CPBF= 7,"+39404192369",145,"Fabio"**

**+CPBF= 9,"0404192111",129,"Fabrizio"**

**OK**





- Now you might want to look for the entries with the name starting with: "FAUSTO" but no record contains this name:

*command:*

AT+CPBF="FAUSTO"<cr>

*response:*

+CME ERROR: 22

or if extended error codes are disabled simply

*response:*

ERROR

### 3.1.3 Phonebook entry read by Index

As first thing, you must select the desired storage as active (see par.3.1.1.1). Then:

- send command **AT+CPBR=<index><cr>**

**where:**

**<index> is the index number of the desired PB record to be read.**

- wait for response in the format:

**+CPBR= <index>,"<number>",<type>,"<name>"**

**OK**

**where:**

**<index> is the record number on the PB;**

**<Number> is the phone number;**

**<type> is the type of number:**

145 – international numbering scheme

129 – national numbering scheme

**<Name> is the alphanumeric name associated with the number.**

or in the case the index number does not correspond to a written record:

**+CME ERROR: 22** or simply **ERROR.**

For example:

1- Let's assume you want to select the "SM" normal phonebook for operations,

*command:*

AT+CPBS="SM"<cr>

*response*

OK

- Now you might want to look for the entry at the position index = 7

*command:*



AT+CPBR=7<cr>  
*the response may look like:*  
+CPBR= 7,"+39404192369",145,"Fabio"

OK

- Now you might want to look for the entries at the positions from 7 to 9 and for example the position at index 8 is empty

*command:*  
AT+CPBR=7,9<cr>  
*the response may look like:*  
+CPBR= 7,"+39404192369",145,"Fabio"

+CPBR= 9,"0404192111",129,"Fabrizio"

OK

### 3.1.4 Phonebook entry Write

As first thing, you must select the desired storage as active (see par.3.1.1.1). Then:

- send command **AT+CPBW=<index>,<number>,<type>,<name><cr>**  
**where:**  
**<index>** is the index number of the desired PB record to be written (may be omitted if any empty record number can be used).  
**<Number>** is the phone number;  
**<type>** is the type of number:  
145 – international numbering scheme (contains the character "+")  
129 – national numbering scheme  
**<Name>** is the alphanumeric name associated with the number.
- wait for response:

Response	Reason	Action
OK	Record has been successfully written	Proceed ahead
ERROR	some error occurred	Enable extended result codes (see par. 2.5.2.1), and retry.
+CME ERROR: 10	SIM not present	Check SIM or require SIM insertion and repeat from par. 2.5.2.2
+CMS ERROR: 310	SIM not present	Check SIM or require SIM insertion and repeat from par. 2.5.2.2



+CME ERROR: 11	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 2.5.2.3)
+CMS ERROR: 311	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 2.5.2.3)
+CME ERROR: 12	SIM is present and PUK is required to continue operations	insert SIM PUK (see par.2.5.2.4)
+CMS ERROR: 316	SIM is present and PUK is required to continue operations	insert SIM PUK (see par.2.5.2.4)
+CME ERROR: 13	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. 2.5.2.2
+CMS ERROR: 313	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. 2.5.2.2
+CME ERROR: 14	SIM is busy	retry later
+CMS ERROR: 314	SIM is busy	retry later
+CME ERROR: 15	SIM is wrong type	Check SIM, it must be a GSM SIM.
+CMS ERROR: 315	SIM is wrong type	Check SIM, it must be a GSM SIM.
+CME ERROR: 21	invalid index	Change index number or leave it empty and retry.
+CME ERROR: 20	memory full	PB storage is full.
+CMS ERROR: 322	memory full	PB storage is full.

For example:

1- Let's assume you want to select the "SM" normal phonebook for operations,

*command:*

AT+CPBS="SM"<cr>

*response*

OK

- Now you might want to write a new record on the PB:

*command:*

AT+CPBW=,"0404192123",129,"NewRecord"<cr>

*response:*

OK

-Now you may want to check if operation has really succeeded and where the new record has been written. (obviously operation was successful, since the device returned OK)

*command:*

AT+CPBF="NEW"<cr>

*response:*

+CPBF= 8,"0404192123",129,"NewRecord"

OK

The new record was written at the position index 8. (The first free record index found).



### 3.1.5 Phonebook entry Delete

As first thing, the desired storage must be active (see par.3.1.1.1). Then:

- send command **AT+CPBW=<index><cr>**

where:

**<index> is the index number of the desired PB record to be deleted.**

- wait for response:

Response	Reason	Action
OK	Record has been successfully deleted	proceed ahead
ERROR	some error occurred	Enable extended result codes (see par. 2.5.2.1), and retry.
+CME ERROR: 21	invalid index, out of PB storage limits	check index number and retry.
+CME ERROR: 10	SIM not present	Check SIM or require SIM insertion and repeat from par. 2.5.2.2
+CMS ERROR: 310	SIM not present	Check SIM or require SIM insertion and repeat from par. 2.5.2.2
+CME ERROR: 11	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 2.5.2.3)
+CMS ERROR: 311	SIM is present and PIN is required to continue operations	insert SIM PIN (see par. 2.5.2.3)
+CME ERROR: 12	SIM is present and PUK is required to continue operations	insert SIM PUK (see par.2.5.2.4)
+CMS ERROR: 316	SIM is present and PUK is required to continue operations	insert SIM PUK (see par.2.5.2.4)
+CME ERROR: 13	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. 2.5.2.2
+CMS ERROR: 313	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. 2.5.2.2
+CME ERROR: 14	SIM is busy	retry later
+CMS ERROR: 314	SIM is busy	retry later
+CME ERROR: 15	SIM is wrong type	Check SIM, it must be a GSM SIM.
+CMS ERROR: 315	SIM is wrong type	Check SIM, it must be a GSM SIM.





***TIP: The delete operation simply overwrites the record number <index> with an empty record. If the record to be deleted was already empty, no error messages will be shown, but it will be only filled again with empty values.***

### 3.1.6 Phonebook entry Dial

You may want to dial a number previously stored in the phonebook. As first thing, you must find the desired phone number index position, to do it use the +CPBF command. Once the <index> number is known set up the device for the type of call you want to dial. Then:

- send command **ATD> <index><cr>**

**where:**

**<index> is the index number of the desired PB record to be dialed.**

wait for response according to the call type you issued.

For example:

1- Let's assume you want to make a Voice call on the internal audio path MT to "Fabio" whose number is stored on the SIM PB:

- Select the PB as active storage

*command:*

AT+CPBS="SM"<cr>

*response*

OK

- Now find the index number where "Fabio" is recorded:

*command:*

AT+CPBF="Fabio"<cr>

*the response may look like:*

+CPBF= 7,"+39404192369",145,"Fabio"

OK

- the first field is the index position: 7 in this case.

- Now set up Voice call:

*command:*

AT+FCLASS=8<cr>

*response:*

OK

AT#CAP=2 <cr>

OK

AT+CLVL=8<cr>

OK





AT+CMUT? <cr>  
+CMUT: 0

- and Dial:  
ATD> 7<cr>  
OK



## 3.2 Distinguish Calls

### 3.2.1 Identify the Call type

The GM862-GPS is able to identify the call type before answering it, it is so possible to have different ring indications (unsolicited codes) depending on the call type:

Unsolicited code	Reason
RING	The extended format of incoming call indication is disabled and a call (voice or data) is incoming.
+CRING: VOICE	The extended format of incoming call indication is enabled and a voice call is incoming.
+CRING: ASYNC	The extended format of incoming call indication is enabled and an asynchronous transparent data call is incoming.
+CRING: SYNC	The extended format of incoming call indication is enabled and a synchronous transparent data call is incoming.
+CRING: REL ASYNC	The extended format of incoming call indication is enabled and an asynchronous not transparent data call is incoming.
+CRING: REL SYNC	The extended format of incoming call indication is enabled and a synchronous not transparent data call is incoming.
+CRING: FAX	The extended format of incoming call indication is enabled and a fax call is incoming.

In order to use this feature you must enable the extended format of incoming calls



### 3.2.1.1 Set the extended incoming call indication

- Send command **AT+CRC=<n><cr>**

where:

**<n> is the operation mode selected:**

- 0 – extended results Disabled (device reports RING only)
- 1 – extended results Enabled (device reports +CRING: <type> indication)

- wait for **OK** response

### 3.2.2 Identify the Caller

The GM862-GPS is able to identify the caller number and give indication of it before the call is answered.

The calling number is presented after each RING or +CRING indication in the format:

**+CLIP: "<number>",<type>["<subaddress>",<satype>["<alpha>"],["<CLI validity>"]]]**

**OK**

where:

**<Number> is the phone number;**

**<type> is the type of number:**

- 145 – international numbering scheme
- 129 – national numbering scheme

**<subaddress> is the subaddress of the calling party**

**<satype> is the type of subaddress**

**<alpha> is an optional string type alphanumeric representation of <number> corresponding to the entry found in phonebook;**

**<CLI validity> is the validity status of CLI presentation:**

- 0 CLI valid.
- 1 CLI has been withheld by the originator.
- 2 CLI is not available due to interworking problems or limitation or originating network.

In order to use this feature you must enable the caller ID indication presentation, if feature is disabled then no CLI indication is given after the RING or +CRING code.



### 3.2.2.1 Set Caller line ID indication presentation

- Send command **AT+CLIP=<n><cr>**

where:

**<n> is the operation mode selected:**

- 0 – Calling Line Indication Presentation Disabled
- 1 – Calling Line Indication Presentation Enabled

- wait for **OK** response

For example:

1- Let's assume you receive a call from the national number 1234567890 and extended incoming calls indication is disabled while CLIP is enabled, you'll see:

*ring indication:*

RING

+CLIP: "1234567890",129

2- Let's assume you receive a call from the international number +391234567890 and extended incoming calls indication is disabled while CLIP is enabled, you'll see:

*ring indication:*

RING

+CLIP: "+391234567890",145

**NOTE:** this does not mean that the incoming call is an international one, it simply means that the numbering scheme used to identify the caller is the international one.

### 3.2.3 Restricting Calling Line Indication

The GM862-GPS is able to send the calling line indication (CLI) to the other party through the network when an outgoing call is made. This indication can be restricted (CLIR) in various ways:

- CLI sent always
- CLI never sent
- CLI temporary sent (normally not sent)
- CLI temporary not sent (normally sent)



### 3.2.3.1 CLIR Service status query

- send command **AT+CLIR?<cr>**
- wait for response in the format:  
**+CLIR: <n>,<m>**  
**OK**

where:


**<n> is the facility status on the Mobile**

- 0 - CLIR facility according to CLIR service network status
- 1 - CLIR facility active (CLI not sent)
- 2 - CLIR facility not active (CLI sent)

**<m> is the facility status on the Network**

- 0 - CLIR service not provisioned (service unavailable)
- 1 - CLIR service provisioned (service available)
- 2 - unknown (e.g. no network present, etc.)
- 3 - CLI temporary mode presentation restricted
- 4 - CLI temporary mode presentation allowed

---

 **NOTE: The <m> parameter reports the status of the service at network level. If the CLIR service is not provisioned, then it is not possible to use this service and changing the first parameter <n> will not change the CLI presentation to the other party behavior of the network.**

---

For example:

1- Let's assume you want to check your CLIR settings:

command:

AT+CLIR? <cr>

response:

+CLIR: 2,4

In this case the CLIR service is temporary mode allowed on the network and the mobile sends the CLI when calling. (CLI Restriction not active).





### 3.2.3.2 Restrict/Allow Caller line ID indication

- Send command **AT+CLIR=<n><cr>**

where:

**<n> is the operation mode selected:**

- 0 – Calling Line Indication to the other party According to Network service status.
- 1 – Calling Line Indication Restriction Enabled (CLI not sent)
- 2 – Calling Line Indication Restriction Disabled (CLI sent)

- wait for **OK** response

For example:

1- Let's assume you want to disable the CLI presentation to the other party permanently:

command:

AT+CLIR=1<cr>

response:


OK

### 3.2.4 Call Barring Control

The call Barring is a GSM service that allows the user to block certain types of calls:

- Barring All Outgoing Calls
- Barring Outgoing International Calls
- Barring Outgoing International Calls except to Home Country
- Barring All Incoming Calls
- Barring Incoming Calls when Roaming outside the home country
- All Barring services (applicable only for disabling command)
- All Outgoing barring services (applicable only for disabling command)
- All Incoming barring services (applicable only for disabling command)

The service can be queried, enabled and disabled.

 **NOTE: The call Barring service is handled by the network, hence all the relative commands issue a network request and it may take several seconds to have the response from the network.**

**Furthermore, all the Call Barring service commands must be issued when the mobile is Registered on some Network, else an error code is returned ( no network service ).**



### 3.2.4.1 Call Barring Service status query

- send command **AT+CLCK=<fac>,2<cr>**


where:

**<fac> is the facility to be queried:**

- AO - Barring All Outgoing Calls
- OI - Barring Outgoing International Calls
- OX- Barring Outgoing International Calls except to Home Country
- AI - Barring All Incoming Calls
- IR - Barring Incoming Calls when Roaming outside the home country
- AB - All Barring services (applicable only for disabling command)
- AG - All Outgoing barring services (applicable only for disabling command)
- AC - All Incoming barring services (applicable only for disabling command)

- wait for response:

Response	Reason	Action
+CLCK: 0	facility is disabled	calls are allowed
+CLCK: 1	facility is enabled	calls are barred
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax and service code
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.

 **NOTE: The call Barring service is handled by the network, hence all the relative commands issue a network request and it may take several seconds to have the response from the network.**

**Furthermore all the Barring service commands must be issued when the mobile is Registered on some Network, else an error code is returned ( no network service ).**



For example:

1- Let's assume you want to check whether the incoming calls when roaming outside Home Country are barred or not:

*command:*

AT+CLCK=IR,2<cr>

*response:*

+CLCK: 0

In this case, the incoming (received) calls ARE NOT BARRED when in Roaming outside the Home Country.

2- Let's assume you want to check whether the Outgoing (originated) international calls are barred or not:

*command:*

AT+CLCK=OI,2<cr>

*response:*

+CLCK: 1

In this case, the outgoing international calls ARE BARRED.



### 3.2.4.2 Barring/Unbarring All Incoming Calls

- Send command **AT+CLCK=AI,<en>,<pwd><cr>**

where:

**<en> is the operation selected:**

- 0 – Call Barring Disable (Unbarring)
- 1 – Call Barring Enable (Barring)

**<pwd> is the network password required to change facility status**

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all incoming calls will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to bar all the incoming calls and the network password of your operator is 0000:

*command:*

**AT+CLCK=AI,1,0000<cr>**

*response:*

**OK**



### 3.2.4.3 Barring/Unbarring Incoming Calls when in International Roaming

- Send command **AT+CLCK=IR,<en>,<pwd><cr>**

where:

**<en> is the operation selected:**

- 0 – Call Barring Disable (Unbarring)
- 1 – Call Barring Enable (Barring)

**<pwd> is the network password required to change facility status**

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all incoming calls when is international Roaming will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to bar all the incoming calls when the mobile is roaming outside its home country and the network password of your operator is 0000:

*command:*

**AT+CLCK=IR,1,0000<cr>**

*response:*

OK





### 3.2.4.4 Barring/Unbarring All Outgoing Calls

- Send command **AT+CLCK=AO,<en>,<pwd><cr>**

where:

**<en> is the operation selected:**

- 0 – Call Barring Disable (Unbarring)
- 1 – Call Barring Enable (Barring)

**<pwd> is the network password required to change facility status**

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all outgoing calls will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to bar all the outgoing calls (originated by mobile) and the network password of your operator is 0000:

*command:*

**AT+CLCK=AO,1,0000<cr>**

*response:*

**OK**



### 3.2.4.5 Barring/Unbarring All Outgoing International Calls

- Send command **AT+CLCK=OI,<en>,<pwd><cr>**

where:

**<en> is the operation selected:**

- 0 – Call Barring Disable (Unbarring)
- 1 – Call Barring Enable (Barring)

**<pwd> is the network password required to change facility status**

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all outgoing international calls will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to bar all the outgoing international calls (originated by mobile and to a number outside the home country of the mobile) and the network password of your operator is 1234:

*command:*

AT+CLCK=OI,1,1234<cr>

*response:*

OK



### 3.2.4.6 Barring/Unbarring All Outgoing International Calls except to Home Country

- Send command **AT+CLCK=OX,<en>,<pwd><cr>**

where:

**<en> is the operation selected:**

- 0 – Call Barring Disable (Unbarring)
- 1 – Call Barring Enable (Barring)

**<pwd> is the network password required to change facility status**

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all outgoing international calls except to Home Country will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to bar all the outgoing international calls except the ones towards the Home Country and the network password of your operator is 1234:

*command:*

**AT+CLCK=OX,1,1234<cr>**

*response:*

**OK**



### 3.2.4.7 Unbarring all the Calls

- Send command **AT+CLCK=AB,0,<pwd><cr>**

where:

**<pwd> is the network password required to change facility status**

- wait for response:

Response	Reason	Action
OK	Barring is now disabled	all calls will be allowed (unbarred)
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to disable all the barring services you might have previously activated and the network password of your operator is 0000:

*command:*

**AT+CLCK=AB,0,0000<cr>**

*response:*

**OK**



## 3.3 DTMF tones

DTMF tones are managed by specific AT commands. These tones are generated with AT commands only during voice calls. The minimum duration of a DTMF tone can be set on 10 ms but it should be considered that this value can vary with the limitations on network.

Group low	Group high		
	1209 Hz	1336 Hz	1477 Hz
697 Hz	1	2	3
770 Hz	4	5	6
852 Hz	7	8	9
941 Hz	*	0	#

**NOTE:** The GSM system architecture defines that the audio signal of the DTMF tones is inserted by the network switches on commands sent by the Mobile Station (MS). Thus, the default duration parameters may vary from network to network. In case that the devices to be controlled by DTMF are sensitive related to the duration of the tones and timing of the sequences, dedicated investigations on the parameter settings have to be made.





## 3.4 GSM Power Saving function


The Telit GM862-GPS has a special function that reduces the power consumption during the idle time, thus allowing a longer standby time with a given battery capacity.

This function monitors the DTR line indicating that the OEM application is ready to send commands, when it goes high (3V on UART) then the OEM application is not going to send any commands and the GM862-GPS module can save energy by shutting down its internal serial port.


When the OEM application becomes again ready, then the line DTR is tied low (0V on UART); the GM862-GPS detects this condition and powers up the serial port.

If the power saving function is activated, then the serial port must support the DTR line since when this line is high (Data Terminal is NOT ready) the device goes into a sleep condition and will not respond to commands until the DTR is tied low (Data Terminal is ready).

---

 **NOTE:** The power saving function does not affect the network behavior of the GM862-GPS, even during the power save condition the module remains registered on the network and reachable for incoming calls or SMS. If a call income during the power save, then the module will wake up and proceed normally with the unsolicited incoming call code. The DTR functionality is usable only when +CFUN=5 is selected.

---

 **TIP:** When the GM862-GPS wakes up from the sleep mode, it takes a maximum of 150 milliseconds before it can exchange commands on the serial port. Hence place a delay of at least 150 ms between the port opening (DTR lowering) and command sending. According to the V24 standard, when the module is not ready to receive commands it will tie up the CTS line, while it will pull it down when it's ready to receive commands; hence you can monitor the CTS line to ensure the GM862-GPS is ready for commands.

---



### 3.4.1.1 Enabling/Disabling the power saving function

- send command **AT+CFUN=<fun><cr>**

**where:**

**<fun> is the power saving function mode, the supported values are:**

0 - minimum functionality, NON-CYCLIC SLEEP mode: in this mode, the AT interface is not accessible.

1 - mobile full functionality with power saving disabled (factory default)

2 - disable TX

4 - disable both TX and RX

5 - mobile full functionality with power saving enabled

- wait for response:

Response	Reason	Action
OK	The power save is now active	
ERROR	some error occurred	Enable extended result codes (see par. 2.5.2.1), and retry.
+CME ERROR: 4	operation not supported	Check command syntax and <fun> value.



**TIP:** The power saving function is disabled by default when the device starts up, in order to guarantee that even without the DTR line support it is possible to exchange commands with the module; for this reason the power saving setting command shall be issued after every power up.



**NOTE:** The power saving for GSM part will not be activated if the GPS part is switched on. The DTR functionality is usable only when +CFUN=5 is selected.



## 3.5 SMS handling

The Telit GM862-GPS supports the Short Message Service, it is possible to store, delete, write, send and receive a SMS, which is a short text message up to 160 characters long.

### 3.5.1 SMS device setup

Before accessing the Short Message Service, the device has to be properly set up.

#### 3.5.1.1 Select SMS format type

The GM862-GPS supports SMS in two different formats:

- PDU
- Text

The difference is that in the PDU mode the device returns and receives SMS encoded in the format ready to be sent to the network; in TEXT mode the device converts automatically the read PDU into text and viceversa. By using TEXT mode the PDU data encoding knowledge is not needed and operations are easier. For this reason, we will use the TEXT mode to explain how to operate with SMS. If you are familiar with PDU encoding then you can operate with PDU by selecting that format and using appropriate command syntax.

- Send command **AT+CMGF=<mode><cr>**

where:

**<mode> is the SMS format type:**

- 0 – PDU
- 1 – Text

- wait for response **OK**



---

**TIP: This setting is stored and remains until the device is turned off. Hence, there's no need to issue it more than one time. For TEXT mode use <mode>=1.**

---

For example:

1- Let's assume you want to set TEXT format for the SMS:

command:

AT+CMGF=1<cr>

response:

OK



### 3.5.1.2 Check SMS Service Centre number

The SMS are sent by the GM862-GPS to a service centre (SMSC) where the message is dispatched towards its final destination or is kept until the delivery is possible. To ensure a correct behavior of this service the number of the service centre must be the one your network operator supports.

To check which number is stored as the SMSC:

- send command **AT+CSCA?<cr>**
- wait for response in the format:  
**+CSCA: <number>,<type>**

**OK**

where:

**<number> is the SMSC number**

**<type> is the SMSC number type:**

- 145 – international numbering scheme (number begins with "+")
- 129 – national numbering scheme



***TIP: This settings remains stored in the SIM card until it is changed or deleted, so this operation may be done only once if the SIM Card is not changed. The setting is maintained even after power down.***

For example:

1- Let's assume you want to check your SMSC number:

command:

AT+CSCA? <cr>

response:

+CSCA: +393359609600

**OK**

### 3.5.1.3 Add SMS Service Centre number (only if required)

If your previously check for SMSC returned an empty field:

+CSCA: ,129

or if the SMSC number stored does not correspond to the desired one, then the new number has to be stored. In this way the previously stored number will be overwritten.

- send command **AT+CSCA=<number>,<type><cr>**

where:

**<number> is the desired SMSC number**

**<type> is the SMSC number type:**

- 145 – international numbering scheme (number begins with "+")
- 129 – national numbering scheme

- wait for **OK**



For example:

1- Let's assume your desired SMSC number is +39335123456 (stored in international format):

*command:*

AT+CSCA=+39335123456,145<cr>

*response:*

OK

### 3.5.1.4 Select New Messages indication behavior

When the device receives a new message a unsolicited indication is generated, this indication may be sent to the DTE, buffered if the DTE is busy (for example during a data call) or discarded.

To set the desired behavior:

- send command **AT+CNMI=<mode>,<mt>,<bm>,<ds>,<bfr><cr>**

**where:**

Set command selects the behaviour of the device on how the receiving of new messages from the network is indicated to the **DTE**.

Parameter:

**<mode>** - unsolicited result codes buffering option

- 0 - Buffer unsolicited result codes in the **TA**. If **TA** result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications.
- 1 - Discard indication and reject new received message unsolicited result codes when **TA-TE** link is reserved, otherwise forward them directly to the **TE**.
- 2 - Buffer unsolicited result codes in the **TA** in case the **DTE** is busy and flush them to the **TE** after reservation. Otherwise forward them directly to the **TE**.
- 3 - if **<mt>** is set to 1 an indication via 100 ms break is issued when a SMS is received while the module is in GPRS online mode. It enables the hardware ring line for 1 s. too.

**<mt>** - result code indication reporting for SMS-DELIVER

- 0 - No SMS-DELIVER indications are routed to the **TE**.
- 1 - If SMS-DELIVER is stored into **ME/TA**, indication of the memory location is routed to the **TE** using the following unsolicited result code:

**+CMTI: <memr>,<index>**

where:

**<memr>** - memory storage where the new message is stored

"SM"

"ME"

**<index>** - location on the memory where SM is stored.

- 2 - SMS-DELIVERs (except class 2 messages and messages in the message waiting indication group) are routed directly to the **TE** using the following unsolicited result code:

(PDU Mode)

**+CMT: <alpha>,<length><CR><LF><pdu>**

where:





**<alpha>** - alphanumeric representation of originator/destination number corresponding to the entry found in **MT** phonebook  
**<length>** - PDU length  
**<pdu>** - PDU message

### (TEXT Mode)

**+CMT:***<oa>,<alpha>,<scts>[,<tooa>,<fo>,<pid>,<dcsc>,<sca>,<tosca>,<length>]<CR><LF><data>* (the information written in italics will be present depending on **+CSDH** last setting)

where:

**<oa>** - originating address, string type converted in the currently selected character set (see **+CSCS**)  
**<alpha>** - alphanumeric representation of **<oa>**; used character set should be the one selected with either command **+CSCS** or **@CSCS**.  
**<scts>** - arrival time of the message to the SC  
**<tooa>,<tosca>** - type of number **<oa>** or **<sca>**:  
 129 - number in national format  
 145 - number in international format (contains the "+")  
**<fo>** - first octet of GSM 03.40  
**<pid>** - Protocol Identifier  
**<dcsc>** - Data Coding Scheme  
**<sca>** - Service Centre address, string type, converted in the currently selected character set (see **+CSCS**)  
**<length>** - text length  
**<data>** - TP-User-Data

Class 2 messages and messages in the message waiting indication group (stored message) result in indication as defined in **<mt>=1**.

3 - Class 3 SMS-DELIVERs are routed directly to **TE** using unsolicited result codes defined in **<mt>=2**. Messages of other data coding schemes result in indication as defined in **<mt>=1**.

**<bm>** - broadcast reporting option

0 - Cell Broadcast Messages are not sent to the **DTE**

2 - New Cell Broadcast Messages are sent to the **DTE** with the unsolicited result code:

### (PDU Mode)

**+CBM:** **<length><CR><LF><PDU>**

where:

**<length>** - PDU length  
**<PDU>** - message PDU

### (TEXT Mode)

**+CBM:***<sn>,<mid>,<dcsc>,<pag>,<pags><CR><LF><data>*

where:

**<sn>** - message serial number  
**<mid>** - message ID  
**<dcsc>** - Data Coding Scheme



<pag> - page number  
<pages> - total number of pages of the message  
<data> - CBM Content of Message

<ds> - SMS-STATUS-REPORTs reporting option  
0 - status report receiving is not reported to the **DTE**  
1 - the status report is sent to the **DTE** with the following unsolicited result code:

**(PDU Mode)**

**+CDS: <length><CR><LF><PDU>**

where:

<length> - PDU length  
<PDU> - message PDU

**(TEXT Mode)**

**+CDS: <fo>,<mr>,,,<scts>,<dt>,<st>**

where:

<fo> - first octet of the message PDU  
<mr> - message reference number  
<scts> - arrival time of the message to the SC  
<dt> - sending time of the message  
<st> - message status as coded in the PDU

2 - if a status report is stored, then the following unsolicited result code is sent:

**+CDSI: <memr>,<index>**

where:

<memr> - memory storage where the new message is stored  
"SM"  
<index> - location on the memory where SM is stored

<bfr> - buffered result codes handling method:

- 0 - **TA** buffer of unsolicited result codes defined within this command is flushed to the **TE** when <mode>=1..3 is entered (**OK** response shall be given before flushing the codes)
- 1 - TA buffer of unsolicited result codes defined within this command is cleared when <mode>=1..3 is entered.

**NOTE:** issuing **AT+CNMI<CR>** is the same as issuing the Read command.

**NOTE:** issuing **AT+CNMI=<CR>** is the same as issuing the command **AT+CNMI=0<CR>**.

- wait for **OK**



**TIP:** In this command description the values that are always 0 are parameter reserved for future use, in the current software revision the only value supported is 0.



For example:

1- Let's assume you want to eliminate all the unsolicited codes that may be sent when receiving SMS & Status Report:

*command:*

AT+CNMI= 0,0,0,0,0<cr>

*response:*

OK

For example about a new message indication:

1- Let's assume you receive a new SMS delivery (AT+CNMI=1,1,0,0,0) and this new message is stored on the SIM "SM" storage at the location number 7; the unsolicited code you will receive (if code is enabled) is:

*unsolicited code:*

+CMTI: "SM",7

2- Let's assume you receive a new SMS Status Report delivery (AT+CNMI=1,0,0,2,0) and this new message is stored on the SIM "SM" storage at the location number 8; the unsolicited code you will receive is:

*unsolicited code:*

+CDSI: "SM",8



### 3.5.1.5 Set Text Mode Parameters (only in TEXT mode)

When the device is set to operate with Text SMS not with PDU, the SMS parameters that usually reside on the header of the PDU must be set apart with the command +CSMP.

The parameters to be set are:

- Message Format
- Validity Period
- Protocol Identifier
- Data Coding Scheme

The meaning and format of the parameters is:

- **Message format**, like defined for the first octet of message according to GSM 3.40:  
The format is an 8-bit parameter divided into 6 fields and then reported as an integer:

b7	b6	b5	b4	b3	b2	b1	b0
RP	UDHI	SRR	VPF		RD	MTI	

where

**MTI** message type parameter:

0 1 - SMS Submit (only value supported)

## RD reject duplicates parameter

0 - don't reject duplicates SMS in SC

1 - reject duplicates on SC

## VPF validity period format

0 0 - Validity period NOT present

1 0 - VP integer represented (relative)

1 1 - VP semi octet represented (absolute)

0 1 - reserved

## SRR status report request

0 - status report not requested

1 - status report requested

## UDHI user data Header Information

0 - No Header on PDU

1 - Header present on PDU

### RP reply path

0 - RP not set

1 - RP set

- Validity Period** numerical if in relative format or string if in absolute format



If in relative format (see VPF parameter) it is an integer:

144 to 167 – corresponding to 12 hours + ((VP -143) x 30 minutes)

197 to 255 – corresponding to (VP - 192) x 1 week

"gg/MM/YY,hh:mm:ss±tz"

gg day of expiration (2 characters)

YY year of expiration (2 characters)

mm minute of expiration (2 character)

± sign of the time zone ( + or - )

This parameter identifies the protocol used by the receiver entity and informs the SC that the conversion from SMS to that protocol should be done while delivering the message.



	handling system
50	Internet Electronic Mail
51-55	(reserved, 5 combinations)
56-62	values specific to each SC, usage based on mutual agreement between the SME and the SC (7 combinations available for each SC)
63	A GSM mobile station. The SC converts the SM from the received TP-Data-Coding-Scheme to any data coding scheme supported by that MS (e.g. the default).
64	Short Message Type 0
65	Replace Short Message Type 1
66	Replace Short Message Type 2
67	Replace Short Message Type 3
68	Replace Short Message Type 4
69	Replace Short Message Type 5
70	Replace Short Message Type 6
71	Replace Short Message Type 7
72..94	Reserved
95	Return Call Message
96..126	Reserved
127	SIM Data download

- **Data coding Scheme** as defined by GSM 3.38 – in numerical format

The DCS is an 8-bit parameter reported as an integer, the default value is 0, otherwise for simplicity, we report only the most useful DCS, for further Schemes refer to GSM 3.38

b7	b6	b5	b4	b3	b2	b1	b0
1	1	1	1	0	Alpha bet	Class	

where

**Alphabet**

- 0 - default Alphabet
- 1 - 8 bit

**Class**

- 0 0 - Class 0
- 0 1 - Class 1
- 1 0 - Class 2
- 1 1 - Class 3





**TIP:** The default value for DCS = 0 represents the default SMS sent by a mobile. If you don't need any particular data coding scheme use DCS=0.



**NOTE:** Not all the DCS combinations described in the GSM 3.38 are supported, both by the network and by the Telit GM862-GPS. Some features may be not implemented at network level or at device level, resulting in a +CMS ERROR: 303 (operation not supported) result code. If this happens then use a different DCS.

- send command **AT+CSMP=<fo>,<vp>,<pid>,<dc><cr>**  
where:

**<fo>:** Message format  
**<vp>:** Validity Period  
**<pid>:** Protocol Identifier  
**<dc>:** Data coding Scheme

- wait for **OK**

For example:

1- Let's assume you want to set the SMS parameters to the values:

- Message Format:
  - SMS submit
  - don't reject duplicates
  - VP Format integer (relative)
  - status report not requested
  - No Header on PDU
  - Reply path not set

Hence, the message format is the binary number 00010001 corresponding to the integer 17.

- Validity period 24 hours corresponding to an integer value 167.  
12 hours + ((167 - 143) x 30 min) = 24 hours
- Protocol ID implicit (SMS sent to a mobile terminal) corresponding to a value 0.
- DCS default value 0.

command:

AT+CSMP= 17,167,0,0

response:

OK

2- Let's assume you want to set the SMS parameters to the values:

- Message Format:
  - SMS submit
  - don't reject duplicates
  - VP Format semi octet (absolute)
  - status report requested



- No Header on PDU
- Reply path not set

Hence, the message format is the binary number 00111001 corresponding to the integer 57.

- Validity period format is absolute, hence it represents the expiration date of the message and the desired expiration date is for example 29/06/02 at 02:20 in the time zone of Italy (+1).  
"29/06/02,02:20:00+1"

- Protocol ID implicit (SMS sent to a mobile terminal) corresponding to a value 0.
- Data Coding Scheme:
  - Default Alphabet
  - Class 0 (e.g. immediate display SMS)

Corresponding to the binary number 11110000 corresponding to the integer 240.

*command:*

AT+CSMP= 57,29/06/02,02:20:00+1,0,240

*response:*

OK

### 3.5.1.6 Select SMS Memory and check for memory space

There are various types of storage where the SMS can be stored, the Telit GM862-GPS provides two different storage:

"ME" - mobile equipment memory

"SM" - SIM Card memory

The SMS are usually stored (this is true for both the originated and the received SMS) in the SM storage, the "ME" storage is a read only one where the Class 0 messages received are stored (regardless of the selected active storage which may be "SM").

For this reason the "ME" storage can be selected to read the Class 0 messages.

The GM862-GPS allows the user to select a different storage for the read-delete, write-send, and reception-saving SMS operations.

- send command **AT+CPMS=<memr>,<memw>,<mems><cr>**

where:

**<memr>: memory storage for Read and Delete commands**

- "SM"

- "ME" (No Delete operations allowed)

**<memw>: memory storage for Write and Send commands**

**<mems>: memory storage for new incoming message saving**

- "SM" only

- wait for response in the format:

**+CPMS:<usedr>,<totalr>,<usedw>,<totalw>,<useds>,<totals>**

OK



#### where

<usedr> - number of SMS stored into <memr>  
 <totalr> - max number of SMS that <memr> can contain  
 <usedw> - number of SMS stored into <memw>  
 <totalw> max number of SMS that <memw> can contain  
 <useds> - number of SMS stored into <mems>  
 <totals> max number of SMS that <mems> can contain

From this response you can check if the selected storage has room for new SMSs, the free positions in the storage X (where X can be r,w,s ) are <totalX> -<usedX>.

### 3.5.2 IRA character set

The character set used in SMS text mode is the IRA.

This set defines each char as a 7-bit value, hence from 0x00 to 0x7F. The table below reports all the chars supported and their hexadecimal code. To obtain the code for a char in the table remember that in the row it is reported the least significant nibble (4 bits) and in the column the most significant nibble. The empty cells correspond to reserved combinations.

		Most Significant Nibble							
		0x	1x	2x	3x	4x	5x	6x	7x
Least Significant Nibble	x0			SP <sup>1</sup>	0	@	P		p
	x1			!	1	A	Q	a	q
	x2			"	2	B	R	b	r
	x3			#	3	C	S	c	s
	x4			\$	4	D	T	d	t
	x5			%	5	E	U	e	u
	x6			&	6	F	V	f	v
	x7			'	7	G	W	g	w
	x8			(	8	H	X	h	x
	x9			)	9	I	Y	i	y
	xA	LF <sup>2</sup>		*	:	J	Z	j	z
	xB			+	;	K		k	
	xC			,	<	L		l	
	xD	CR <sup>3</sup>		-	=	M		m	
	xE			.	>	N		n	
	xF			/	?	O	£	o	

<sup>1</sup> - SP stands for space character

<sup>2</sup> - LF stands for Line Feed character

<sup>3</sup> - CR stands for Carriage Return character



Hence, the character corresponding to the 0x6B IRA code is 'k'.

***Please refer to the AT Commands Reference Guide for the full command description***



### 3.5.3 Writing a New SMS to storage

A new SMS can be written in the selected storage <memw> (in the current SW version only "SM" is supported) and then can be sent to the desired destination.

To write the new SMS:

- send command **AT+CMGW="<da>"<cr>**

where:

**<da>: destination address**

- wait for prompt ">"
- send SMS text (MAX 160 characters)
- end command with CTRL-Z character (0x1A hexadecimal) or abort command with ESC character (0x1B hexadecimal)
- wait for response:

Response	Reason	Action
+CMGW: <index>	Message has been successfully written in position number <index>	proceed ahead
OK		
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CMS ERROR: 330	SMSC address unknown	Insert SMSC address (see par. 3.5.1.3)
+CMS ERROR: 322	Memory Full	memory is full, hence delete some records and retry.

**NOTE:** if command is aborted with ESC character, then only the OK result code is returned.





For example:

1- Let's assume you want to write a new SMS to the storage and the destination address is the number +39338123456789. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

*command:*

`AT+CMGW="+39338123456789"`

*response:*

>

*now you can insert the message text in IRA format (note that the IRA format and ASCII format coincide for the alphabet characters but not for the other).*

*.... here will be inserted the SMS message text....*

*conclude text with the character CTRL-Z*

*response:*

`+CMGW: 3`

OK

In this case, the new SMS was successfully written to the location index 3 of the selected write memory (always "SM" SIM Card memory).



### 3.5.4 Sending an SMS previously stored

An already written SMS can be sent from the selected storage <memw> (in the current SW version only "SM" is supported).

To send the written SMS its location index is needed:

- send command **AT+CMSS=<index><cr>**

where:

**<index>: SMS location index**

- wait for response:

Response	Reason	Action
+CMSS: <mr> OK	Message has been successfully sent. <mr> represents the message reference number.	proceed ahead
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CMS ERROR: 330	SMSC address unknown	Insert SMSC address (see par. 3.5.1.3)
+CMS ERROR: 41	"Temporary Failure", may be that the device is not registered on any network	Check for signal strength and network registration
+CMS ERROR: 331	No network service	Check for signal strength and network registration
+CMS ERROR: 1	Unassigned number	The destination address number does not exist. Check it and repeat command.
+CMS ERROR: 42	network congestion	Retry later
+CMS ERROR: 96	Mandatory information missing	Check for destination address in the SMS, overwrite it and retry.



For example:

1- Let's assume you want to send a SMS that was written to the storage index position number 3. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

*command:*

AT+CMSS=3

*response:*

+CMSS: 1

OK

In this case, the SMS was successfully sent to the destination and its network message reference number is 1.

### 3.5.5 Sending a new SMS without storing it

A new SMS can be sent directly to the network without storing it.

- send command **AT+CMGS="<da>"<cr>**

where:

**<da>: destination address**

- wait for prompt ">"
- send SMS text (MAX 160 characters)
- end command with CTRL-Z character (0x1A hexadecimal) or abort command with ESC character (0x1B hexadecimal)
- wait for response:

Response	Reason	Action
+CMGS: <mr> OK	Message has been successfully sent. <mr> represents the message reference number.	proceed ahead
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CMS ERROR: 330	SMSC address unknown	Insert SMSC address (see par. 3.5.1.3)
+CMS ERROR: 41	"Temporary Failure", may be that the device is not registered on any network	Check for signal strength and network registration
+CMS ERROR: 331	No network service	Check for signal strength and network registration
+CMS ERROR: 1	Unassigned number	The destination address number does not exist. Check it and repeat command.



+CMS ERROR: 42	network congestion	Retry later
+CMS ERROR: 96	Mandatory information missing	Check for destination address in the SMS, overwrite it and retry.
OK	command aborted by user	you issued a ESC char

For example:

1- Let's assume you want to directly send a new SMS to the destination address number +39338123456789. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

*command:*

AT+CMGS="+39338123456789"

*response:*

>

*now you can insert the message text in IRA format (note that the IRA format and ASCII format coincide for the alphabet characters but not for the other).*

*.... here will be inserted the SMS message text to be sent....*

*conclude text with the character CTRL-Z*

*response:*

+CMGW: 4

OK

In this case, the new SMS was successfully sent to the SC and its network reference number is 4. Do not confuse message reference with message index position, the first indicates the network reference for identifying the sent message (the eventually requested status report will have the same reference) while the second indicates the position where the message has eventually been stored in memory.



### 3.5.6 Deleting an SMS

An already written/received SMS can be deleted from the selected storage (in the current SW version only "SM" is supported).

To delete the SMS its location index is needed:

- send command **AT+CMGD=<index><cr>**

where:

**<index>: SMS location index**

- wait for response:

Response	Reason	Action
OK	Message has been successfully deleted.	proceed ahead
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CMS ERROR: 321	Invalid memory index e.g. the given record was already empty	Check the <index> number and retry.

For example:

1- Let's assume you want to delete a previously written SMS that was written to the storage index position number 3. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

*command:*

AT+CMGD=3

*response:*

OK

In this case, the SMS was successfully deleted.

2- Let's assume you want to delete a received SMS that was stored to the index position number 7:

*command:*

AT+CMGD=7

*response:*

OK



### 3.5.7 Reading an SMS

A new SMS can be read with the command:

- send command **AT+CMGR=<index><cr>**

where:

**<index>: SMS location index**

- wait for response in the format:

*Output format for received messages (the information written in italics will be present depending on +CSDH last setting):*

**+CMGR: <stat>,<oa>,<alpha>,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data>**

*Output format for sent messages:*

**+CMGR: <stat>,<da>,<alpha>[,<toda>,<fo>,<pid>,<dcs>,,<sca>,<tosca>,<length>]<CR><LF><data>**

*Output format for message delivery confirm:*

**+CMGR: <stat>,<fo>,<mr>,,,<scts>,<dt>,<st>**

where:

**<stat>** - status of the message

"REC UNREAD" - new received message unread

"REC READ" - received message read

"STO UNSENT" - message stored not yet sent

"STO SENT" - message stored already sent

**<fo>** - first octet of the message PDU

**<mr>** - message reference number

**<scts>** - arrival time of the message to the SC

**<dt>** - sending time of the message

**<st>** - message status as coded in the PDU

**<pid>** - Protocol Identifier

**<dcs>** - Data Coding Scheme

**<oa>** - Originator address, string type represented in the currently selected character set (see **+CSCS**)

**<da>** - Destination address, string type represented in the currently selected character set (see **+CSCS**)

**<alpha>** - string type alphanumeric representation of **<da>** or **<oa>**, corresponding to an entry found in the phonebook; used character set is the one selected with command **+CSCS**. *NB: this optional field is currently not supported.*

**<sca>** - Service Centre number

**<tooa>,<toda>,<tosca>** - type of number **<oa>,<da>,<sca>**

129 - number in national format





145 - number in international format (contains the "+")

**<length>** - text length

**<data>** - TP-User\_data

- If **<dcs>** indicates that GSM03.38 default alphabet is used , each character of GSM alphabet will be converted into current TE character set (see **+CSCS**)
- If **<dcs>** indicates that 8-bit or UCS2 data coding scheme is used, each 8-bit octet will be converted into two IRA character long hexadecimal number (e.g. octet 0x2A will be converted as two characters 0x32 0x41)

**NOTE:** in both cases if status of the message is 'received unread', status in the storage changes to 'received read'.

**NOTE:** an error result code is sent on empty record **<index>**.

For example:

1- Let's assume you want to read the SMS that is stored at the position index 4. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

*command:*

AT+CMGR=4

*response:*

+CMGR: "STO UNSENT", "+393351234565"

Telit Test Message for Text Mode SMS.

OK

In this case the SMS was successfully read, the text contained was:

" Telit Test Message for Text Mode SMS."

The message was written to the storage by user (STO) but still not sent (UNSENT) to the destination address that's the number +393351234565

2- Let's assume you want now to read the SMS that is stored at the position index 5:

*command:*

AT+CMGR=5

*response:*

+CMGR: "REC UNREAD", "+393381234567890", , "29/06/01,12:30:04+01"

Telit Test Message for Text Mode SMS RECEIVING.

OK

In this case the SMS was successfully read, the text contained was:

" Telit Test Message for Text Mode SMS RECEIVING."

The message was received (REC) from the number +393381234567890 at 12:30:04 the day 29/06/01 in the European time zone +1.

After this read command the message at index 5 becomes REC READ.



### 3.5.8 Listing a group of SMSs

The SMS can be grouped into 5 different groups depending on their status:

- REC UNREAD - received messages still not read
- REC READ - received messages already read
- STO UNSENT - written messages not yet sent
- STO SENT - written messages already sent
- ALL - all types of messages

It is possible to have the list of all the messages in one group:

- send command **AT+CMGL=<stat><cr>**

where:

**<stat> - status group of the message**

- "REC UNREAD" - new message
- "REC READ" - read message
- "STO UNSENT" - stored message not yet sent
- "STO SENT" - stored message already sent
- "ALL" - all messages

- wait for response in the format:

**For every message in the group:**

**+CMGL: <index>,<stat>,<oa/da> [,,,<tooa/toda>,<length>]  
<CR><LF><text>**

where:

- <index> - message index position on the storage**
- <stat> - status of the message**
  - "REC UNREAD" - new message
  - "REC READ" - read message
  - "STO UNSENT" - stored message not yet sent
  - "STO SENT" - stored message already sent
- <oa/da> - sender number/destination number**
- < tooa/toda > - type of number <oa/da>**
  - 145 - international number (contains "+" character)
  - 129 - national number
- <length> - length of the message text in characters**
- <text> - message text**

**NOTE:** If status of the message is 'received unread', status in the storage changes to 'received read'.



For example:

1- Let's assume you want to list all the SMS received read that are stored. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

*command:*

AT+CMGL="REC READ"

*response:*

+CMGL: 5, "REC READ", "+393381234567890"

Telit Test Message for Text Mode SMS RECEIVING.

+CMGL: 8, "REC READ", "+393381234567890"

Telit Second Test Message for Text Mode SMS RECEIVING.

OK

In this case the SMS group was successfully read, the messages Received UNREAD were two in the position indexes 5 & 8. The optional parameters <toa/toda> and <length> were not shown.



## 3.6 Using General Purpose Input/Output pins

The **Telit GM862-GPS** provides various General Purpose Input/Output pins, these pins can be configured via AT commands as Inputs, Outputs and two of them as "alternate function".

The "alternate function" are supported by pins GPIO5, which can be configured to become a RF Transmission monitor output pin that reflects the RF transmission activation, GPIO6, which can be configured to become an alarm output pin that reflects the alarm status, and GPIO7 which can be configured to become a buzzer output pin.

With these pins your application can control external hardware directly using the **Telit GM862-GPS** pins, with little or even no hardware added.

### 3.6.1 GPIO pin setup

Before using the GPIO pin, you must configure them to select their direction or alternate function

#### 3.6.1.1 Setting GPIO pin as OUTPUT

When you set a GPIO as output, you must specify also the value that the pin output must take:

- Send command **AT#GPIO=<pin>,<value>,1<cr>**

where:


**<pin>** is the GPIO pin number at which the command applies:

2 – GPIO2	7 – GPIO7
3 – GPIO3	8 – GPIO8
4 – GPIO4	9 – GPIO9
5 – GPIO5	10 – GPIO10
6 – GPIO6	11 – GPIO11
	12 – GPIO12
	13 – GPIO13

**<value>** is the GPIO pin value that the pin will assume:

- 0 – LOW
- 1 – HIGH

- wait for response **OK**

 **NOTE: The #GPIO setting is not saved and will be lost on power off, so at start-up repeat pin initialization commands. At start-up the setting for GPIO5, GPIO6 and GPIO7 instead is maintained even after a shutdown to permit RFTXMON, alarm & buzzer feature to work always.**



For example:

1- Let's assume you want to set GPIO3 pin as Output and you want it to be in LOW status:

command:

AT#GPIO=3,0,1<cr>

response:

OK

In this case, the GPIO3 pin was successfully put in output direction and its status has been set to LOW.

### 3.6.1.2 Setting GPIO pin as INPUT

When you set a GPIO as input, you must specify also a dummy value for the pin state:

- Send command **AT#GPIO=<pin>,<dummy\_value>,0<cr>**

where:


**<pin>** is the GPIO pin number at which the command applies:

1 – GPI1	7 – GPIO7
	8 – GPIO8
3 – GPIO3	9 – GPIO9
4 – GPIO4	10 – GPIO10
5 – GPIO5	11 – GPIO11
6 – GPIO6	12 – GPIO12
	13 – GPIO13

**<value>** is a dummy value can be either:

- 0 – dummy value
- 1 – dummy value

- wait for response **OK**

 **NOTE:** The #GPIO setting for all GPIO except from GPIO6, GPIO7, is not saved and will be lost on power off, so at start-up repeat pin initialization commands.  
At start-up all the GPIOs except from GPIO6 & GPIO7 are configured by default as INPUT, but the setting for GPIO6 and GPIO7 instead is maintained even after a shutdown to permit alarm & buzzer feature to work always.

For example:

1- Let's assume you want to set GPIO4 pin as Input:

command:

AT#GPIO=4,0,0<cr>

response:

OK

In this case, the GPIO4 pin was successfully put in input direction.





## 3.6.2 GPIO pin use

After having set-up the GPIO pin direction you can query the input status of an INPUT pin or set the output status of an OUTPUT pin.

### 3.6.2.1 Querying GPIO pin status

To query for the pin status:

- Send command **AT#GPIO=<pin>,2<cr>**

where:

**<pin>** is the GPIO pin number at which the command applies:

1 – GPIO1	7 – GPIO7
2 – GPIO2	8 – GPIO8
3 – GPIO3	9 – GPIO9
4 – GPIO4	10 – GPIO10
5 – GPIO5	11 – GPIO11
6 – GPIO6	12 – GPIO12
	13 – GPIO13

- wait for response in the format:

**#GPIO: <dir>,<stat>**  
**OK**

where:


**<dir>** - GPIO<pin> direction setting

**<stat>** - status of the pin

**0** - LOW

**1** - HIGH

 **NOTE:** In case the GPIO pin direction is set to **ALTERNATE FUNCTION (2)**, then the reported **<stat>** has no meaning and shall not kept as valid, but shall be threaten as a dummy value.

 **TIP:** The query reports depending on the pin direction:

- the read pin status in case the direction is input;
- the previously set pin status in case the direction is output.

In any case, you can know if the pin at the query moment is high or low and the pin direction.

For example:

1- Let's assume you want to query the GPIO3 pin for its status:

command:

AT#GPIO=3,2<cr>

response:

#GPIO: 0,1

OK

In this case, the GPIO3 pin was set in input direction and its status has been measured to be HIGH.



2- Let's assume you want to query the GPIO4 pin for its status:

*command:*

AT#GPIO=4,2<cr>

*response:*

#GPIO: 1,0

OK

In this case, the GPIO4 pin was set in output direction and its status is LOW.

3- Let's assume you want to query the GPIO6 pin for its status:

*command:*

AT#GPIO=6,2<cr>

*response:*

#GPIO: 2,0

OK

In this case, the GPIO6 pin was set in "alternate function" direction and therefore works as alarm output. The reported status = LOW has no meaning.

### 3.6.2.2 Setting GPIO pin output status

To set the pin status (when pin is set as OUTPUT):

- Send command **AT#GPIO=<pin>,<value>,1<cr>**

where:

**<pin>** is the GPIO pin number at which the command applies:

2 – GPIO2	7 – GPIO7
3 – GPIO3	8 – GPIO8
4 – GPIO4	9 – GPIO9
5 – GPIO5	10 – GPIO10
6 – GPIO6	11 – GPIO11
	12 – GPIO12
	13 – GPIO13

**<value>** is the pin value to be set and can be:

- 0 – LOW
- 1 – HIGH

- wait for response **OK**

For example:

1- Let's assume you want to set the GPIO3 pin HIGH:

*command:*

AT#GPIO=3,1,1<cr>

*response:*

OK



In this case, the GPIO3 pin was set in output direction and its status has been set to HIGH.

### 3.6.2.3 Using GPIO5 pin as RFTXMON OUTPUT (alternate function)

When you set the GPIO5 pin as RFTXMON output function, the pin reports the Transmitter active status. To set the pin in alternate function you must specify also a dummy value for the pin state:

- Send command **AT#GPIO=5,<dummy\_value>,2<cr>**

where:

**<value> is a dummy value can be either:**

- 0 – dummy value
- 1 – dummy value

- wait for response **OK**



**TIP:** Remember that the alternate function places the GPIO5 pin always in OUTPUT direction.



**NOTE:** The #GPIO5 direction setting is saved and will be kept after a power off. The saving can be applied only for the alternate mode.

For example:

1- Let's assume you want to set GPIO5 pin as RFTXMON OUTPUT:

command:

AT#GPIO=5,0,2<cr>

response:

OK

In this case, the GPIO5 pin was successfully put in RFTXMON output direction.

### 3.6.2.4 Using GPIO6 pin as ALARM OUTPUT (alternate function)

When you set the GPIO6 pin as alarm output function, the pin reports the alarm state following the +CALA settings. To set the pin in alternate function you must specify also a dummy value for the pin state:

- Send command **AT#GPIO=6,<dummy\_value>,2<cr>**



where:

**<value> is a dummy value can be either:**

- 0 – dummy value
- 1 – dummy value

- wait for response **OK**





1- Let's assume you want to set GPIO6 pin as ALARM OUTPUT:

AT#GPIO=6.0.2<cr>

OK

In this case, the GPIO6 pin was successfully put in alarm output direction.



When you set the GPIO7 pin as buzzer output function, the pin will output a waveform suitable to drive a Buzzer, provided a simple external mosfet driver is developed and that the #SRP settings are adequate. To set the pin in alternate function you must specify also a dummy value for the pin state:

- where:**

0 – dummy value

1 – dummy value

- wait for response **OK**



1- Let's assume you want to set GPIO7 pin as BUZZER OUTPUT:

AT#GPIO=7,0,2<cr>

OK



In this case, the GPIO7 pin was successfully put in buzzer output direction.

## 3.7 Clock/Alarm function

The **Telit GM862-GPS** provides a Real Time Clock and Alarm embedded in the product; it is therefore possible to set-up the proper time, check the actual time, set-up an alarm time at which the alarm will be triggered with various behavior depending on the +CALA setting.

The only requirement is that the power input to the **Telit GM862-GPS** has to be guaranteed without interruptions, the **Telit GM862-GPS** has no backup battery; therefore it will lose the time setting if its power supply is interrupted.

On Alarm trigger the **Telit GM862-GPS** can:

- automatically Wake-up fully operative from shutdown as if the ON/OFF
- automatically Wake-up from shutdown in a special status namely "alarm status" where it will not look for or try to register into any network, as if it would be off, except from the fact that it proceeds with the alarm action and it can receive commands to return completely operative or shutdown immediately.
- If already ON at alarm trigger time, simply proceed with the Alarm action

Once Woken-up the **Telit GM862-GPS** proceeds with the chosen action that can be

- issue an unsolicited code "+ALARM: <user\_text>" on the serial port until a 90s timeout expires or a special Wake-up command is received
- play an Alarm tone until a 90s timeout expires or a special Wake-up command is received
- rise the pin GPIO6 until a 90s timeout expires or a special Wake-up command is received
- any combination of these actions

With these features, the **Telit GM862-GPS** for example can:

- Wake-up itself and its controlling hardware by using the GPIO6 pin at the desired time, so timely surveys can be programmed without the need to keep the any hardware on and therefore reducing power consumption to a minimum.
- Activate some special hardware on time trigger event with the GPIO6 pin.
- Alert the controlling application that the alarm time has come with the unsolicited code "+ALARM:<user\_text>"
- Alert the user with the alarm tone played

### 3.7.1 Clock date/time

Before using the Alarm feature, you must regulate the internal clock.





### 3.7.1.1 Regulate the Clock

- Send command **AT+CCLK="<time>"<cr>**

where:

**<time>** - current time as quoted string in the format : "yy/MM/dd, hh:mm:ss±zz"

yy - year (two last digits are mandatory), range is 00..99

MM - month (two last digits are mandatory), range is 01..12

dd - day (two last digits are mandatory), range is 01..31 (if the month MM has less than 31 days, the clock will be set for the next month)

hh - hour (two last digits are mandatory), range is 00..23

mm - minute (two last digits are mandatory), range is 00..59

ss - seconds (two last digits are mandatory), range is 00..59

±zz - time zone (indicates the difference, expressed in quarter of an hour, between the local time and GMT; two last digits are mandatory), range is -47..+48

**NOTE:** If the parameter is omitted the behavior of Set command is the same as Read command.

- wait for response **OK**



**TIP:** Remember that the string time has to be encapsulated in double brackets.



**NOTE:** The time will start immediately after the time setting command.

For example:

1- Let's assume you want to regulate your clock to 7 November 2002 at 12h 24m 30s for the time zone +01h central Europe:

command:

AT+CCLK="02/11/07,12:24:30+04"<cr>

response:

OK

In this case, the time was successfully set.

### 3.7.1.2 Read the current date/time

- Send command **AT+CCLK?<cr>**

- wait for response in the format:

**+CCLK: <time>**

**OK**

**NOTE:** the three last characters of **<time>** are not returned by **+CCLK?** because the **ME** doesn't support time zone information.



For example:

1- Let's assume you want now to read the current time:

*command:*

`AT+CCLK?<cr>`

*response:*

`+CCLK="02/11/07,12:26:47"<cr>`

OK

In this case the current date/time is: 7 November 2002 12h 26m 47s

## 3.7.2 Alarm function

Once the current time has been set, the alarm function can be setup.

### 3.7.2.1 Regulate the Alarm time & behavior

- Send command **AT+CALA="<time>",0,<type>,"<text>"<cr>**

where:

**<time>** is the Alarm time string in the same format of the clock setting command:

yy/MM/dd,hh:mm:ss±zz

where:

yy : two digits year (00-99)

MM : two digits month (01-12)

dd : two digits day (01-31)

hh : two digits hour (00-24)

mm : two digits minute (00-60)

ss : two digits seconds (00-60)

±zz: signed two digits timezone (-11 - +11)

**<type>** is the Alarm behavior:

0 - reserved for other equipment use.

1 - the MODULE simply wakes up fully operative as if the **ON/OFF** button had been pressed. If the device is already **ON** at the alarm time, then it does nothing.

2 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE issues an unsolicited code every 3s:

**+ALARM: <text>**

where **<text>** is the **+CALA** optional parameter previously set.

The device keeps on sending the unsolicited code every 3s until a **#WAKE** or **#SHDN** command is received or a 90s timeout occurs. If the device is in "alarm mode" and it does not receive the **#WAKE** command within 90s then it shuts down. (default)




- <text>** - unsolicited alarm code text string. It has meaning only if **<type>** is equal to 2 or 5 or 6.

- 



### 3.7.2.2 Stop the Alarm activity

To stop the Alarm activity there are three ways, you can either decide to exit from alarm and shutdown the device or exit from alarm and entering the normal operational status; otherwise you can leave the alarm go on until the 90s timeout is reached.




- Send command **AT#SHDN<cr>**
- wait for response **OK**

- Send command **AT#WAKE=0<cr>**
- wait for response **OK**

When the device awakes by means of an alarm time expire, the module starts the alarm activity but not the network activity, permitting some operations to be done by the controlling application without registering the mobile in the network.

**<status>** is the operating mode:

1 - alarm mode



### 3.7.2.3.1 Alarm operation example

For example:

1- Let's assume you have a battery powered device, a meteorological unit that measures every hour the conditions and therefore needs to send a new SMS every hour to the central server, for example indicating the whether status just measured. Let say your application shall consume the absolute minimum power to achieve the job, since it will be placed in a remote position where its battery shall last as long as possible and therefore it should shutdown completely and wake up every hour for just the time needed to measure & send the whether, successively shutdown.

- set up the time in the internal clock (only the first time..)

*command:*

AT+CCLK="02/11/07,12:24:30+01"<cr>

*response:*

OK

- set up the next alarm in order to raise the GPIO6 pin to power up the controlling application too.

*command:*

AT+CALA="02/11/07,13:24:30+01",0,6,"TIME TO MEASURE & SMS...!"<cr>

*response:*

OK

- shutdown the GM862-GPS and successively the controlling application.

*command:*

AT#SHDN<cr>

*response:*

OK

... after an hour..

The GM862-GPS will turn itself ON in "Alarm Mode" and contemporarily both rise the GPIO6 pin which turns on the power to the controlling application and issue every 3s an unsolicited code +ALARM: TIME TO MEASURE & SMS...!

- turn on the keep alive line in the controlling application that keeps itself ON.

- stop the alarm activity in the GM862-GPS (recognized by the +ALARM unsolicited code) and bring the GM862-GPS in operating mode

*command:*

AT#WAKE=0<cr>

*response:*

OK

- take the whether measure

- send the SMS with the whether data (see Sending a new SMS without storing it par. 3.5.5).

- read the current time.

*command:*

AT+CCLK?<cr>





*response:*  
+CCLK="02/11/07,13:24:47"<cr>  
OK

- calculate & set up the next alarm in order to raise the GPIO6 pin to power up the controlling application too.

*command:*  
AT+CALA="02/11/07,14:24:47+01",0,6,"TIME TO MEASURE & SMS...!"<cr>

*response:*  
OK

- shutdown the GM862-GPS and successively the controlling application.


*command:*  
AT#SHDN<cr>

*response:*  
OK




## 4.1 Introduction

An example of this kind of operation is shown in the following picture, where the point to point connection is between the two peers as if all the devices inside the dashed line are not present:



An example of GPRS connection is shown in the following picture, where the GPRS connection is between the GPRS modem and the internet as if all the devices inside the dashed line are not present:



### *GPRS interconnectivity*



GM862-GPS Software User Guide  
1vv0300729 Rev. 4 - 24/01/07

Due to this kind of connection, when activating the GPRS connection you must provide the network parameters to enter through the internet point of the GPRS network ISP (Internet Service Provider) and not the phone number to be dialed; therefore it is not possible to establish a direct point to point GPRS connection between two modems as in CSD case, instead an internet tunneling must be done to achieve a point to point connection between two peers.

This approach as the immediate advantage of projecting the controlling application of the GPRS modem directly on the internet, ready to be accessed virtually from anywhere in the world at the same cost on the GPRS; actually the billing of the GPRS connection is based on the amount of data exchanged (number of packets transferred) independently from the time the connection is active or where these packet must be delivered. Therefore, it is possible to leave the controlling application always connected and ready to receive/send data on demand, while paying only for the data really exchanged.

The drawback of the GPRS connection is that the controlling application must have its own TCP/IP protocol stack embedded to decode the packets that arrive from GPRS and encode the ones to be sent through the internet.

There are few considerations than must be done on the GPRS connections:

- the GPRS connection speed with a GPRS class 10 multislot device is asymmetrical, 3 time slots in reception (43200 bps max) and 2 time slot in sending (28800 bps max).
- The controlling application of the module must have a TCP/IP - PPP software stack to interface with the GPRS modems.
- The controlling application must relay on some ISP that may be the Network Operator of the SIM to gain access to the internet through the GPRS connection.
- Because of the point before, the receiving application must have internet access either.
- Since the communication is based upon TCP/IP packets, then it is possible to talk contemporarily with more than one peer.
- When required, the data security in internet shall be guaranteed by security protocols over the TCP/IP that must be managed by the controlling application.

### 4.1.1 CSD application example

Let's suppose you have several remote meteorological measurement units spread around the territory, and you want to access them wirelessly through a GSM module in CSD operation.

For each remote unit, there's a modem to connect with the server application, with its own SIM card and unique phone number.

Now there are two possibilities:

- the server application calls on demand the remote units, provided it has stored their phone numbers in a private database.
- the remote units call the server application modem when needed and eventually retry in the case they found it busy; this time the phone number to be stored is only one, the server number which must be stored on the remote units.

In both cases, once connected, the remote unit sends the meteorological data to the server, which places it in a central database for further reading by anyone who accesses the meteorological internet site for example.

The drawback of this approach is that the CSD modem needs about 30s to establish the connection and, depending on the amount of data to be transferred (usually few hundreds bytes), some seconds to transfer them. So let say we pay a 40s call while we need only 10s to transfer data.



## 4.1.2 GPRS application example

The same application can be made with the GM862-GPS using the GPRS feature.

The remote unit is always connected to the internet (at no charge) taking advantage of the features of the GPRS system, when it needs to send data to the server application it simply fills the TCP/IP packets for the server with the meteorological data and gives them to the GM862-GPS to be delivered. The central server has a single modem to connect to the internet, receives the TCP/IP packets from all the remote units and places the contained data in the central database.

The advantage of using GPRS is that the remote unit is always connected and reachable and it pays only for the amount of data (small) transferred and not for the connection time as in CSD operations; in addition the call billing is equal for devices placed anywhere in the Network Operator State and the server can be anywhere in the World.

Furthermore, in the CSD operation the server shall have a set of modems and multiple phone lines to ensure that the calling units will not find it busy, while a single modem is enough for GPRS operation. The speed at which the packets can be transferred is up to 57600 bps (class 10 device, 4+1), 4 times faster than CSD.

**NOTE:** For more detailed information about GPRS connections and practical examples refer to the Easy GPRS User Guide





## 5 GPS operations

### 5.1 Introduction

The GM862-GPS module is equipped with a SiRFStar III GPS receiver that is controllable by the GSM modem using a set of AT commands or dedicated NMEA sentences.

### 5.2 GM862-GPS Serial Ports

2 serial ports are available on the module:

- MODEM SERIAL PORT
- GPS SERIAL PORT B (NMEA)

#### 5.2.1 GPS SERIAL PORT B (NMEA)

This port is carrying out the GPS navigation data in NMEA 0183 format.

The default configuration is 4800 bps, 8, n, 1

It is available on the following pins:

PIN #	NAME	DESCRIPTION	TYPE
35	TX_GPS	GPS TX Data (NMEA)	CMOS 2.8V
41	RX_GPS	GPS RX Data (NMEA)	CMOS 2.8V

### 5.3 WGS 84

GPS receivers perform initial position and velocity calculations using an earth-centered earth-fixed (ECEF) coordinate system. Results may be converted to an earth model (geoid) defined by the selected datum. For GM862-GPS the default datum is WGS 84 (World Geodetic System 1984) which provides a worldwide common grid system that may be translated into local coordinate systems or map datums. (Local map datums are a best fit to the local shape of the earth and not valid worldwide).



The NMEA 0183 is a specification created by the National Marine Electronics Association (NMEA) that defines the interface between other marine electronic equipment.  
The standard permits marine electronics to send information to computers and to other marine equipment.  
GPS receiver communication is defined within this specification.  
The actually supported version is 2.2

The provided NMEA sentences are :

<b>GGA</b>	Time, position and fix type data.
<b>GLL</b>	Latitude, longitude, UTC time of position fix and status.
<b>GSA</b>	GPS receiver operating mode, satellites used in the position solution and DOP values.
<b>GSV</b>	The number of GPS satellites in view satellite ID numbers, elevation, azimuth, and SNR values.
<b>VTG</b>	Course and speed information relative to the ground.
<b>RMC</b>	Time, date, position, course and speed data.



### 5.4.1 GGA - Global Positioning System Fixed Data

This sentence provides Time, position, and fix related data for a GPS Receiver

Table A contains the values for the following example:

\$GPGGA,161229.487,3723.2475,N,12158.3416,W,1,07,1.0,9.0,M,, , ,0000\*18

## Table A

Name	Example	Units	Description
Message ID	\$GPGGA		GGA protocol header
UTC Time	161229.487		hhmmss.sss
Latitude	3723.2475		ddmm.mmmm
N/S Indicator	N		N=north or S=south
Longitude	12158.3416		dddmm.mmmm
E/W Indicator	W		E=east or W=west
Position Fix Indicator	1		See Table B
Satellites Used	07		Range 0 to 12
HDOP	1.0		Horizontal Dilution of Precision
MSL Altitude	9.0	meters	
Units	M	meters	
Geoid Separation		meters	
Units	M	meters	
Age of Diff. Corr.		second	Null fields when DGPS is not used
Diff. Ref. Station ID	0000		
Checksum	*18		
<CR> <LF>			End of message termination

### Table B

Value	Description
0	Fix not available or invalid
1	GPS SPS Mode, fix valid
2	Differential GPS, SPS Mode, fix valid
3-5	Not supported
6	Dead Reckoning Mode, fix valid



## 5.4.2 GLL - Geographic Position - Latitude/Longitude

This sentence provides latitude and longitude of vessel position, time of position fix and status

Table C contains the values for the following example:

\$GPGLL,3723.2475,N,12158.3416,W,161229.487,A,A\*41

**Table C**

Name	Example	Units	Description
Message ID	\$GPGLL		GLL protocol header
Latitude	3723.2475		ddmm.mmmm
N/S Indicator	N		N=north or S=south
Longitude	12158.3416		dddmm.mmmm
E/W Indicator	W		E=east or W=west
UTC Time	161229.487		hhmmss.sss
Status	A		A=data valid or V=data not valid
Mode	A		A=Autonomous, D=DGPS, E=DR (Only present in NMEA version 3.00)
Checksum	*41		
<CR> <LF>			End of message termination



### 5.4.3 GSA - GNSS DOP and Active Satellites

This sentence reports the GPS receiver's operating mode, satellites used in the navigation solution reported by the GGA sentence and DOP values.

Table D contains the values for the following example:

\$GPGSA,A,3,07,02,26,27,09,04,15,, , , , ,1.8,1.0,1.5\*33

**Table D: GSA Data Format**

Name	Example	Units	Description
Message ID	\$GPGSA		GSA protocol header
Mode 1	A		See Table E
Mode 2	3		See Table F
Satellite Used1. Satellite used in solution.1	07		Sv on Channel 1
Satellite Used1	02		Sv on Channel 2
....			
Satellite Used1			
PDOP	1.8		
HDOP	1.0		
VDOP	1.5		
Checksum	*33		
<CR> <LF>			End of message termination

**Table E: Mode 1**

Value	Description
M	Manual—forced to operate in 2D or 3D mode
A	2D Automatic—allowed to automatically switch 2D/3D

**Table F: Mode 2**

Value	Description
1	Fix not available
2	2D (<4 SVs used)
3	3D (>3 SVs used)





## 5.4.4 GSV - GNSS Satellites in View

This sentence reports the number of satellites (SV) in view, satellite ID numbers, elevation, azimuth and SNR value.

There could be four satellites information per transmission so, if the number of satellites in view is bigger, separated GSV sentences will be generated. The number of sentence in transmission and the total to be transmitted is shown in the first 2 fields of the sentence.

Table G contains the values for the following example:

```
$GPGSV,2,1,07,07,79,048,42,02,51,062,43,26,36,256,42,27,27,138,42*71
```

```
$GPGSV,2,2,07,09,23,313,42,04,19,159,41,15,12,041,42*41
```

**Table G: GSV Data Format**

Name	Example	Units	Description
Message ID	\$GPGSV		GSV protocol header
Number of Messages	2		Range 1 to 3
Message Number1	1		Range 1 to 3
Satellites in View	07		
Satellite ID	07		Channel 1 (Range 1 to 32)
Elevation	79	degrees	
Azimuth	048	degrees	
SNR (C/No)	42	dBHz	
....	....	....	
Satellite ID	27		Channel 4 (Range 1 to 32)
Elevation	27	degrees	Channel 4 (Maximum 90)
Azimuth	138	degrees	Channel 4 (True, Range 0 to 359)
SNR (C/No)	42	dBHz	Range 0 to 99, null when not tracking
Checksum	*71		
<CR> <LF>			End of message termination



## 5.4.5 RMC - Recommended Minimum Specific GNSS Data

This sentence reports Time , date, position, course and speed data.

Table H contains the values for the following example:

\$GPRMC,161229.487,A,3723.2475,N,12158.3416,W,0.13,309.62,120598, ,\*10

**Table H: RMC Data Format**

Name	Example	Units	Description
Message ID	\$GPRMC		RMC protocol header
UTC Time	161229.487		hhmmss.sss
Status	A		A=data valid or V=data not valid
Latitude	3723.2475		ddmm.mmmm
N/S Indicator	N		N=north or S=south
Longitude	12158.3416		dddmm.mmmm
E/W Indicator	W		E=east or W=west
Speed Over Ground	0.13	knots	
Course Over Ground	309.62	degrees	True
Date	120598		ddmmyy
Magnetic Variation		degrees	E=east or W=west
Mode	A		A=Autonomous, D=DGPS, E=DR
Checksum	*10		
<CR> <LF>			End of message termination




**NOTE:** SiRF Technology Inc. does not support magnetic declination. All “course over ground” data are geodetic WGS84 directions.



This sentence reports the actual course and speed relative to the ground.

\$GPVTG,309.62,T, ,M,0.13,N,0.2,K,A\*23

Name	Example	Units	Description
Message ID	\$GPVTG		VTG protocol header
Course	309.62		Measured heading
Reference	T		True
Course		degrees	Measured heading
Reference	M		Magnetic
Speed	0.13	knots	Measured horizontal speed
Units	N	Knots	
Speed	0.2	km/hr	Measured horizontal speed
Units	K		Kilometers per hour
Mode	A		A=Autonomous, D=DGPS, E=DR
Checksum	*23		
<CR> <LF>			End of message termination



## 5.5 Checking GPS device functionality

After a proper power on the device is ready to receive AT commands on the MODEM serial port. The GPS receiver also will be automatically powered on and it will start the scan of the available GPS signals.

On the NMEA serial port (default 4800 bps, 8, n, 1) there must be presence of the NMEA sentences.

## 5.6 CONTROLLING GPS RECEIVER

The GM862-GPS module is provided by a set of AT commands that permits to configure and use it through the MODEM serial port.

For the full list of available commands please refer to the GM862-GPS AT Commands Reference Guide.

### 5.6.1 POWER CONTROL OF GPS RECEIVER

The GPS receiver is by default switched on at the first power On.

If is necessary to switch it off or On is possible to use the AT\$GPSP command.

The GPS part is supplied by the VAUX1 signal provided by the GSM part. The GPS receiver is usable if the GSM module is switched on (or at least in power saving).

This command also switch off the GPS antenna supply.

Syntax of the command :

AT\$GPSP=<status>

Where <status> means :

- 0 GPS controller is powered down
- 1 GPS controller is powered up (default)
- ? Returns the range of values accepted

AT\$GPSP? will return the current status.

Example 1 : (to switch off the GPS)

AT\$GPSP=0<CR>

OK

Example 2 : (to know the status)

AT\$GPSP?<CR>

The answer will be:

\$GPSP: 0



OK



## 5.6.2 GPS RESET

With the command **AT\$GPSR=<reset type>** is possible to reset the GPS module.

Parameter:

**<reset type>**

- 0 - Hardware reset: the GPS receiver is reset and restarts by using the values stored in the internal memory of the GPS receiver.
- 1 - Coldstart (No Almanac, No Ephemeris): this option clears all data that is currently stored in the internal memory of the GPS receiver including position, almanac, ephemeris, and time. The stored clock drift however, is retained. It is available in controlled mode only.
- 2 - Warmstart (No ephemeris): this option clears all initialization data in the GPS receiver and subsequently reloads the data that is currently displayed in the Receiver Initialization Setup screen. The almanac is retained but the ephemeris is cleared. It is available in controlled mode only.
- 3 - Hotstart (with stored Almanac and Ephemeris): the GPS receiver restarts by using the values stored in the internal memory of the GPS receiver; validated ephemeris and almanac. It is available in controlled mode only.

Example :

Let's suppose to perform a cold start of the GPS receiver.

AT\$GPSR=1<cr>

OK

The Receiver will clear all the parameters in its memory and it will start a new scanning of the available satellites.





## 5.6.3 GPS ANTENNA MANAGEMENT

The GPS receiver needs an active antenna. This antenna could be supplied by the module. By default the antenna supply is set to ON (the provided voltage is related to VBATT so the GPS antenna have to accept a range of supply voltage from 3.4 to 4.2V DC)


With the **AT\$GPSAT** command is possible to define this setting.

The syntax is **AT\$GPSAT=<type>**

Parameter:

**<type>**

- 0 - GPS Antenna not supplied by the module
- 1 - GPS Antenna supplied by the module (default)

 **NOTE:** if current **<type>** is 0, either **\$GPSAV?** and **\$GPSAI?** have no meaning.

### 5.6.3.1 GPS Antenna Current and Voltage Readout

With the commands **AT\$GPSAV?** and **AT\$GPSAI?** is possible to measure the supply voltage and consumption of the GPS antenna.

The answer is (in the case of 3.8V dc measurement)

**\$GPSAV: 3800**

OK

For the current with the command **AT\$GPSAI?** The answer is :

**<value>[, <status>]**

**<value>** the measured current in mA

**<status>** <sup>(1)</sup>

- 0** GPS antenna OK
- 1** GPS antenna consumption out of the limits

STATUS is available only if the SW antenna protection is activated.

**\$GPSAI: 040,0**

OK



## 5.6.4 GPS PARAMETERS SAVE

This command allows saving the set parameters in the module's memory  
Syntax of the command :

AT\$GPSSAV

After this command restart the module to update the modifications.

## 5.6.5 RESTORE GPS PARAMETERS

This command allows restoring the factory default parameters for the GPS module  
Syntax of the command :

AT\$GPSRST

After this command restart the module to update the modifications.

## 5.6.6 READ ACQUIRED GPS POSITION

This command allows reading the acquired position of the GPS receiver  
Syntax of the command :

AT\$GPSACP

The response syntax is:

\$GPSACP:<UTC>,<latitude>,<longitude>,<hdop>,<altitude>,<fix>,<cog>,<spkm>,<spkn>,<date>,<nsat>

The fields contain the following information:

<UTC>: (referred to GGA sentence)  
hhmmss UTC of Position

Values:

hh (hour) 00 to 23  
mm (minutes) 00 to 59  
ss (seconds) 00 to 59

<latitude>: (referred to GGA sentence)  
ddmm.mmmm N/S  
Values:  
dd (degrees) 00 to 90  
mm.mmmm (minutes) 00,0000 to 59.9999  
N/S: North / South



<longitude>: dddmm.mmmm E/W	(referred to GGA sentence) Values: ddd (degrees) 00 to 180 mm.mmmm (minutes) 00,0000 to 59.9999 E/W: East / West
<hdop>: x.x	(referred to GGA sentence) Horizontal Dilution of Precision
<altitude>: xxxx.x	(referred to GGA sentence) Altitude – mean-sea-level (geoid) (meters)
<fix>:	0 - Invalid Fix 2 - 2D fix 3 - 3D fix
<cog>: ddd.mm	(referred to VTG sentence) Course over Ground (degrees, True) Values: ddd: 000 to 360 degrees mm 00 to 59 minutes
<spkm>: xxxx.x	(referred to VTG sentence) Speed over ground (Km/hr)
<spkn>: xxxx.x	(referred to VTG sentence) Speed over ground (knots)
<date>: ddmmyy	(referred to RMC sentence) Date of Fix Values: dd (day) 01 to 31 mm (month) 01 to 12 yy (year) 00 to 99 (2000 to 2099)
<nsat> : nn	Number of satellites in Use (referred to GGA sentence) 00-12 (may be different from the number in view)

Example:

[\\$GPSACP:080220,4542.82691N,01344.26820E,259.07,3,2.1,0.1,0.0,0.0,270705,09](#)

OK



## 6 Service and firmware update

The **Telit GM862-GPS** module firmware can be updated through the same serial interface, which is used normally for the AT commands. Since the software group is continuously working, in order to improve the overall performances and introduce new features on the product, we suggest, in order to keep updated the modules firmware, to foresee an external access to that interface with level converters to RS232, which allows connecting a Windows-based PC. It shall be possible to start the update procedure at POWER OFF condition of the module and then switch it ON to continue.

During the application development or evaluation phase of the **Telit GM862-GPS** module, the RS232 interface with the level converters or the USB port implemented on the **Telit Evaluation Kit EVK2** can be used to connect to a Windows-based PC on which the specific program for updating the Software (TFI) can be run.

### 6.1 Step-by-Step upgrade procedure

The firmware update can be done with a specific software tool provided by Telit that runs on Windows based PCs.




First the program will erase the content of flash memory, then the program will write on the flash memory. To update the firmware of the module, we suggest the following procedure:

- Collect information about the Hardware and implemented version of Software by the command AT+CGMR<enter>, which returns the Software version information;  
AT+CGMM<enter>, which returns the Model Identification.
1. Switch OFF the module.
  2. Run the file *TFI\_xxxx.exe*. When the following window should be displayed select the language preferred by pressing the correspondent button.




3. The End User License Agreement will appear. Please, read it and accept the terms if you are going to proceed.







5. Select the right COM port and speed. Note that to go faster than 115200 you need a special hardware on the PC. Then Press the Download button and within 5 seconds power-on the GM862-GPS.



Wait for the end of programming green message OK



The [Telit GM862-GPS module](#) is now programmed with the new firmware.

**NOTE:** the above pictures show how the application dialogs appear for the GM862-PCS product. The GM862-GPS TFI application is similar.



## 7 Document Change Log

Revision	Date	Changes
ISSUE #0	04/05/06	First release
ISSUE #1	07/09/06	Review of all the document
ISSUE #2	21/11/06	2.6.2.1
ISSUE #3	19/12/06	General review of the whole document -removed GPRS part, camera -added SW firmware update
ISSUE #4	24/01/07	Updated 5.6.3 GPS Antenna Management

