


21. TECHNICAL FEATURE

COIL-INTEGRATED SPARK PLUG CAP (DIRECT IGNITION COIL)

21-1

COIL-INTEGRATED SPARK PLUG CAP (DIRECT IGNITION COIL)

The direct ignition coil is the spark plug cap with the built-in ignition coil. The spark plug wire is omitted, and the light weight and compact size ignition device is accomplished by the direct ignition coil.




MEMO

22. TROUBLESHOOTING

ENGINE DOES NOT START OR IS HARD TO START	22-1	POOR PERFORMANCE AT HIGH SPEED	22-4
ENGINE LACKS POWER	22-2	POOR HANDLING	22-4
POOR PERFORMANCE AT LOW AND IDLE SPEED	22-3		


ENGINE DOES NOT START OR IS HARD TO START




TROUBLESHOOTING

ENGINE LACKS POWER






POOR PERFORMANCE AT LOW AND IDLE SPEED




TROUBLESHOOTING

POOR PERFORMANCE AT HIGH SPEED



POOR HANDLING



23. INDEX

AIR CLEANER	3-5	FLYWHEEL REMOVAL	10-3
AIR CLEANER HOUSING	5-14	FORK	13-12
ALTERNATOR CHARGING COIL	16-6	FRONT BRAKE CALIPER	15-16
ALTERNATOR STATOR	10-2	FRONT FAIRING	2-5
BATTERY	16-4	FRONT INNER FAIRING	2-4
BRAKE FLUID	3-20	FRONT MASTER CYLINDER	15-8
BRAKE FLUID REPLACEMENT/AIR BLEEDING	15-3	FRONT WHEEL	13-7
BRAKE LIGHT SWITCH	19-14	FUEL LINE	3-4
BRAKE LIGHT SWITCH	3-22	FUEL PUMP	5-37
BRAKE PAD/DISC	15-5	FUEL TANK	2-3
BRAKE PADS WEAR	3-21	GEARSHIFT LINKAGE	9-12
BRAKE SYSTEM	3-22	GENERAL SAFETY	1-1
BRAKE/TAILLIGHT	19-4	HANDLEBAR	13-3
CABLE & HARNESS ROUTING	1-18	HANDLEBAR SWITCHES	19-13
CAMSHAFT INSTALLATION	8-19	HEADLIGHT	19-3
CAMSHAFT REMOVAL	8-4	HEADLIGHT AIM	3-23
CARBURETOR ASSEMBLY	5-22	HIGH ALTITUDE ADJUSTMENT	5-34
CARBURETOR CHOKE	3-5	HORN	19-17
CARBURETOR COMBINATION	5-26	IGNITION PULSE GENERATOR	17-7
CARBURETOR DISASSEMBLY/INSPECTION	5-18	IGNITION SWITCH	19-12
CARBURETOR INSTALLATION	5-30	IGNITION SYSTEM INSPECTION	17-4
CARBURETOR REMOVAL	5-15	IGNITION TIMING	17-7
CARBURETOR SEPARATION	5-16	LICENSE LIGHT	19-5
CARBURETOR SYNCHRONIZATION	3-13	LOW FUEL INDICATOR/FUEL RESERVE SENSOR	19-16
CHARGING SYSTEM INSPECTION	16-5	LUBRICATION & SEAL POINTS	1-16
CLUTCH	9-4	MAIN JOURNAL BEARING	12-6
CLUTCH DIODE	18-11	MAINTENANCE SCHEDULE	3-3
CLUTCH SWITCH	19-15	MODEL IDENTIFICATION	1-3
CLUTCH SYSTEM	3-23	NEUTRAL SWITCH	19-15
COIL-INTEGRATED SPARK PLUG CAP (DIRECT IGNITION COIL)	21-1	NUTS, BOLTS, FASTENERS	3-26
COMBINATION METER	19-6	OIL COOLER	4-8
COOLANT REPLACEMENT	6-4	OIL PRESSURE CHECK	4-3
COOLANT TEMPERATURE GAUGE/ THERMOSENSOR	19-9	OIL PRESSURE INDICATOR	19-12
COOLING FAN MOTOR SWITCH	19-11	OIL PUMP	4-6
COOLING SYSTEM	3-15	OIL STRAINER/PRESSURE RELIEF VALVE	4-4
CRANKCASE ASSEMBLY	11-11	PILOT SCREW ADJUSTMENT	5-33
CRANKCASE SEPARATION	11-3	PISTON/CYLINDER	12-10
CRANKPIN BEARING	12-8	RADIATOR COOLANT	3-14
CRANKSHAFT	12-3	RADIATOR RESERVE TANK	6-11
CYLINDER COMPRESSION	8-3	RADIATOR/COOLING FAN	6-8
CYLINDER HEAD ASSEMBLY	8-16	REAR BRAKE CALIPER	15-19
CYLINDER HEAD COVER INSTALLATION	8-21	REAR FENDER/SEAT RAIL	2-8
CYLINDER HEAD COVER REMOVAL	8-3	REAR MASTER CYLINDER/BRAKE PEDAL	15-12
CYLINDER HEAD DISASSEMBLY	8-8	REAR WHEEL	14-3
CYLINDER HEAD INSTALLATION	8-17	REGULATOR/RECTIFIER	16-7
CYLINDER HEAD REMOVAL	8-7	RIGHT CRANKCASE COVER INSTALLATION	9-14
DIRECT AIR INDUCTION (D.A.I.) SYSTEM	5-36	RIGHT CRANKCASE COVER REMOVAL	9-3
DIRECT AIR INTAKE DUCT	2-6	SEAT	2-2
DRIVE CHAIN	3-16	SEAT COWL	2-2
EMISSION CONTROL INFORMATION LABELS	1-32	SECONDARY AIR SUPPLY SYSTEM	3-15, 5-37
EMISSION CONTROL SYSTEMS	1-29	SERVICE INFORMATION	
ENGINE IDLE SPEED	3-14	ALTERNATOR	10-1
ENGINE INSTALLATION	7-6	BATTERY/CHARGING SYSTEM	16-1
ENGINE OIL	3-11	CLUTCH/GEARSHIFT LINKAGE	9-1
ENGINE OIL FILTER	3-12	COOLING SYSTEM	6-1
ENGINE REMOVAL	7-3	CRANKCASE/TRANSMISSION	11-1
EVAPORATIVE EMISSION CONTROL SYSTEM (California type only)	3-16, 5-39	CRANKSHAFT/PISTON/CYLINDER	12-1
EXHAUST SYSTEM	2-7	CYLINDER HEAD/VALVE	8-1
FLYWHEEL INSTALLATION	10-6	ELECTRIC STARTER	18-1
		ENGINE REMOVAL/INSTALLATION	7-2
		FRAME/BODY PANELS/EXHAUST SYSTEM	2-1
		FRONT WHEEL/SUSPENSION/STEERING	13-1

INDEX

SERVICE INFORMATION		WINDSHIELD	2-6
FUEL SYSTEM	5-3	WIRING DIAGRAM.....	20-1
HYDRAULIC BRAKE	15-1		
IGNITION SYSTEM	17-1		
LIGHTS/METERS/SWITCHES	19-1		
LUBRICATION SYSTEM	4-1		
MAINTENANCE	3-1		
REAR WHEEL/SUSPENSION	14-1		
SERVICE RULES	1-2		
SHIFT FORK/SHIFT DRUM	11-4		
SHOCK ABSORBER.....	14-9		
SIDE FAIRING	2-4		
SIDE STAND	3-24		
SIDE STAND SWITCH.....	19-15		
SPARK PLUG	3-6		
SPECIFICATIONS	1-4		
SPEEDOMETER/SPEED SENSOR.....	19-8		
STARTER CLUTCH	10-4		
STARTER MOTOR	18-4		
STARTER RELAY SWITCH.....	18-10		
STEERING HEAD BEARINGS	3-27		
STEERING STEM	13-21		
SUSPENSION.....	3-24		
SUSPENSION LINKAGE	14-11		
SWINGARM	14-13		
SYSTEM TESTING	6-3		
TACHOMETER.....	19-9		
THERMOSTAT	6-6		
THROTTLE OPERATION.....	3-4		
THROTTLE SENSOR	17-7		
TOOLS	1-14		
TORQUE VALUES	1-11		
TRANSMISSION	11-6		
TROUBLESHOOTING			
ALTERNATOR.....	10-1		
BATTERY/CHARGING SYSTEM	16-3		
CLUTCH/GEARSHIFT LINKAGE	9-2		
COOLING SYSTEM.....	6-2		
CRANKCASE/TRANSMISSION.....	11-2		
CRANKSHAFT/PISTON/CYLINDER	12-2		
CYLINDER HEAD/VALVE	8-2		
ELECTRIC STARTER	18-2		
ENGINE DOES NOT START OR IS HARD			
TO START.....	22-1		
ENGINE LACKS POWER.....	22-2		
FRAME/BODY PANELS/EXHAUST SYSTEM	2-1		
FRONT WHEEL/SUSPENSION/STEERING.....	13-2		
FUEL SYSTEM	5-5		
HYDRAULIC BRAKE	15-2		
IGNITION SYSTEM.....	17-3		
LUBRICATION SYSTEM	4-2		
POOR HANDLING	22-4		
POOR PERFORMANCE AT HIGH SPEED.....	22-4		
POOR PERFORMANCE AT LOW AND IDLE SPEED	22-3		
REAR WHEEL/SUSPENSION	14-2		
TURN SIGNAL LIGHT	19-3		
TURN SIGNAL RELAY	19-18		
VALVE CLEARANCE	3-8		
VALVE GUIDE REPLACEMENT.....	8-12		
VALVE SEAT INSPECTION/REFACING	8-13		
WATER PUMP	6-12		
WHEELS/TIRES	3-27		