


- On the CF links connection step, after including the data that is related to the CPC CETUS side of the connection, enter YES on the Timing-only link option of the Connect to CF Channel Path panel (see Figure 9-13) and press Enter.



- ```

Command ==> _____ CF Channel Path Connectivity List _____ Row 1 of
  Scroll ==> CSR

Select one or more channel paths, then press Enter.

Source processor ID . . . . . : MUSCA      Musca
Source channel subsystem ID . : 1
Source partition name . . . . . : *

-----Source-----
/ CHP CHID CF Type Mode Occ Proc.CSSID CHP CHID CF Type Mode
_ E0 12/1 N CS5 SHR N CETUS.2 E1 20/2 N CS5 SHR
                                     -CU- -#
                                     Type Dev
                                     STP

```

### 9.4.2 STP timing-only links: Managing the configuration

Complete the steps that are described in 9.3.2, “ICA SR: Managing the configuration” on page 208 by using the respective CHPID/PCHID of the links you are interested in checking the status.