

Contents

Thank you for buying this Pioneer product.
Please read through these instructions so you will know how to operate your model properly. After you have finished reading the instructions, keep this document in a safe place for future reference.

Important

The screens shown in the examples may differ from actual screens, which may be changed without notice for performance and function improvements.

■ Precaution	4
Information to User	4
License, Warranty Disclaimer & Limitation of Liability.....	5
Important safety information	5
Parking brake interlock.....	5
When using a display connected to V OUT	6
To avoid battery exhaustion.....	6
Rear view camera	6
Handling the USB connector.....	6
Failure to operate.....	6
Visit our website.....	6
Protecting the LCD panel and screen.....	6
Notes on internal memory.....	6
About this manual	7
■ Basic operation	8
Checking part names and functions	8
Remote control	8
Inserting/ejecting/connecting media.....	8
On first-time startup	8
How to use the screens.....	9
Supported AV source	10
Selecting a source	10
Using the touch panel	10
■ Registration and connection of Bluetooth device	10
Displaying the "Bluetooth" screen.....	10
Registering your Bluetooth devices.....	10

Connecting a registered Bluetooth device manually	11
Switching visibility	11
Entering the PIN code for Bluetooth wireless connection	11
Displaying the device information.....	11
Clearing the Bluetooth memory.....	11
Updating Bluetooth software	11
Displaying the Bluetooth software version.....	11
■ Hands-free phoning	12
Displaying the Phone menu screen.....	12
Making a phone call	12
Receiving a phone call	12
Changing the phone settings	13
Notes for hands-free phoning.....	13
■ Setup for iPod	13
iPod compatibility	13
Information on the connections and functions	13
■ Radio	14
Starting procedure	14
Storing the strongest broadcast frequencies	14
Tuning into strong frequencies	14
■ Disc	15
Starting procedure	16
Selecting files from the file name list	16
Switching the media file type.....	16
Searching for the part you want to play	16
Operating the DVD menu	17
Switching the subtitle/audio language.....	17
■ Compressed audio files	17
Starting procedure (for Disc)	18
Starting procedure (for USB)	18
Selecting files from the file name list	18
Switching the media file type	18
■ Compressed video files	18
Starting procedure	19
Selecting files from the file name list	19
■ Still image files	19

Starting procedure	19
Selecting files from the file name list	20
Switching the media file type.....	20
Setting the slideshow interval.....	20
■ iPod	20
Connecting your iPod.....	21
Starting procedure	21
Selecting song or video sources from the playlist screen	21
■ Bluetooth audio player	21
Starting procedure	22
Selecting files from the file name list	22
■ AUX source	22
Starting procedure	22
Setting the video signal	22
■ System settings	23
Displaying the "System" setting screen	23
Activating the Bluetooth audio source	23
Setting the ever scroll	23
Setting the rear view camera.....	23
Setting the camera for Rear View mode	23
Selecting the system language	23
Setting the beep sound	23
Adjusting the response positions of the touch panel (touch panel calibration)	23
Setting the dimmer	24
Adjusting the picture	24
■ Audio adjustments	25
Displaying the "Audio" setting screen	25
Using fader/balance adjustment.....	25
Using balance adjustment.....	25
Adjusting source levels	25
Adjusting loudness.....	25
Using the subwoofer output.....	25
Adjusting the subwoofer settings.....	26
Switching the rear speaker output.....	26
Switching the RCA rear output.....	26
Boosting the bass	26
Setting the high pass filter	26
Using the equalizer	26
■ Theme menu	27
Selecting the theme color.....	27

■ Setting up the video player	27
Setting the top-priority languages	27
Setting the angle icon display.....	28
Setting parental lock	28
Setting the DivX Subtitle	28
Displaying your DivX VOD registration code.....	28
Displaying your DivX VOD deregistration code.....	28
Automatic playback of DVDs	29
Setting the video signal for the rear view camera.....	29
■ Favorite menu	29
Creating a shortcut	29
Selecting a shortcut	29
Removing a shortcut.....	29
■ Common operations	29
Setting the time and date	29
Changing the wide screen mode.....	29
■ Other functions	30
Resetting various settings/Restoring this product to the default settings	30
■ Connection	30
Precautions.....	30
Precautions before connecting the system.....	30
Before installing this product	31
To prevent damage	31
Notice for the blue/white lead	31
This product	31
Power cord	32
Speaker leads	32
Power amp (sold separately).....	32
iPod / iPhone.....	33
iPod / iPhone with Lightning connector	33
iPod / iPhone with 30-pin connector	33
Camera	33
External video component and the display	34
■ Installation	34
Precautions before installation	34
Before installing	34
Installation notes	34