

### Clock

---

#### Can't set the clock.

---

- You cannot set the clock if USB is selected by the input selector.

### Timers

---

#### Timer playback doesn't work.

---

- Make sure the clock has been set correctly (see pages 55 to 56).
- Timed operation will fail if the stereo receiver is on at the specified On time, so make sure it's set to Standby (see pages 58 to 59).
- The timer may overlap with another timer. If you program several timers, make sure they don't overlap (see page 57).
- If you press the [SLEEP] or [TIMER] button while a timed operation is in progress, the timer will be cancelled.

Onkyo is not responsible for damages (such as CD rental fees) due to unsuccessful recordings caused by the unit's malfunction. Before you record important data, make sure that the material will be recorded correctly.

The stereo receiver contains a microcomputer for signal processing and control functions. In very rare situations, severe interference, noise from an external source, or static electricity may cause it to lockup. In the unlikely event that this should happen, unplug the power cord, wait at least 5 seconds, and then plug it again.