

Timing Lights	4-24	Protection Against Chafing	4-53
Checking the Internal Timing of a Magneto.....	4-25	Protection Against High Temperature.....	4-53
High-Tension Magneto E-Gap Setting (Bench Timing)	4-26	Protection Against Solvents and Fluids	4-54
Timing the High-tension Magneto to the Engine.....	4-27	Protection of Wires in Wheel Well Area.....	4-54
Performing Ignition System Checks.....	4-27	Routing Precautions	4-54
Ignition Switch Check	4-28	Installation of Cable Clamps	4-54
Maintenance and Inspection of Ignition Leads	4-28	Lacing and Tying Wire Bundles	4-55
Replacement of Ignition Harness	4-29	Single-Cord Lacing	4-55
Checking Ignition Induction Vibrator Systems.....	4-30	Double-Cord Lacing.....	4-56
Spark Plug Inspection and Maintenance	4-30	Lacing Branch-Offs.....	4-56
Carbon Fouling of Spark Plugs	4-30	Tying	4-57
Oil Fouling of Spark Plugs.....	4-30	Cutting Wire and Cable	4-58
Lead Fouling of Spark Plugs	4-31	Stripping Wire and Cable.....	4-58
Graphite Fouling of Spark Plugs.....	4-31	Solderless Terminals and Splices	4-59
Gap Erosion of Spark Plugs	4-32	Copper Wire Terminals.....	4-59
Spark Plug Removal.....	4-32	Crimping Tools	4-60
Spark Plug Reconditioning Service.....	4-33	Aluminum Wire Terminals	4-60
Inspection Prior to Installation	4-34	Splicing Copper Wires Using Preinsulated Wires ...	4-61
Spark Plug Installation	4-35	Emergency Splicing Repairs.....	4-61
Spark Plug Lead Installation	4-35	Splicing with Solder and Potting Compound.....	4-61
Breaker Point Inspection	4-36	Connecting Terminal Lugs to Terminal Blocks.....	4-62
Dielectric Inspection.....	4-38	Bonding and Grounding.....	4-62
Ignition Harness Maintenance.....	4-38	General Bonding and Grounding Procedures.....	4-63
High-Tension Ignition Harness Faults	4-38	Connectors	4-65
Harness Testing.....	4-39	Types of Connectors.....	4-65
Turbine Engine Ignition Systems.....	4-40	Connector Identification.....	4-65
Capacitor Discharge Exciter Unit.....	4-41	Installation of Connectors	4-65
Igniter Plugs	4-42	Conduit.....	4-67
Turbine Ignition System Inspection and Maintenance	4-42	Electrical Equipment Installation.....	4-67
Inspection	4-43	Electrical Load Limits	4-67
Check System Operation	4-43	Controlling or Monitoring the Electrical Load.....	4-67
Repair	4-43	Circuit Protection Devices.....	4-68
Removal, Maintenance, and Installation of Ignition System Components.....	4-43	Switches	4-68
Ignition System Leads	4-44	Relays	4-69
Igniter Plugs	4-44	Chapter 5	
Powerplant Electrical Systems.....	4-45	Engine Starting Systems	5-1
Wire Size	4-45	Introduction.....	5-1
Factors Affecting the Selection of Wire Size.....	4-47	Reciprocating Engine Starting Systems.....	5-2
Factors Affecting Selection of Conductor Material	4-47	Inertia Starters	5-2
Conductor Insulation	4-49	Direct Cranking Electric Starter	5-2
Identifying Wire and Cable	4-50	Direct Cranking Electric Starting System for Large Reciprocating Engines.....	5-3
Electrical Wiring Installation	4-51	Direct Cranking Electric Starting System for Small Aircraft	5-7
Wire Groups and Bundles	4-51	Reciprocating Engine Starting System Maintenance Practices.....	5-7
Twisting Wires	4-52	Troubleshooting Small Aircraft Starting Systems.....	5-8
Spliced Connections in Wire Bundles.....	4-52	Gas Turbine Engine Starters	5-8
Slack in Wiring Bundles.....	4-52	Electric Starting Systems and Starter Generator Starting System	5-10
Bend Radii.....	4-52		
Routing and Installation	4-53		