














































12 Warning lights › Warning lights overview

Symbol	Meaning
	Rear fog light switched on » page 37 .
	ABS faulty » page 109 .
	Tyre pressure control system faulty » page 133 .
	Tyre pressure change » page 128 , » page 132 .
	Illuminates - Power assisted steering faulty » page 29 .
	Flashing - Steering lock not unlocked » page 29 .
	Flashing - Steering lock faulty » page 29 .
	KESSY - starting problem » page 101 .
	KESSY - no key found » page 23 .
EPC	Petrol engine control faulty » page 120 .
	Emission control system faulty » page 120 .
	Front passenger airbag switched on » page 36 .
ON 	flashes together with OFF - Key switch for airbag deactivation is faulty » page 36 .
OFF 	Front passenger airbag switched off » page 36 .
	Airbag system faulty » page 35 .
	Illuminates for 4 seconds and then flashes - Airbag or belt tensioner deactivated with diagnostic device » page 35 .
	ASR deactivated » page 109 .
	Illuminates - ESC or ASR faulty » page 109 .
	Flashing - ESC or ASR is engaged » page 108 .
	Turn signal light, left » page 37 , » page 38 .
	Turn signal light, right » page 37 , » page 38 .
	Trailer turn signal light » page 38 .

Symbol	Meaning
	Front fog lights switched on » page 37 .
	The selector lever is locked » page 103 .
	ACC controls the driving speed » page 112 .
	The cruise control system controls the driving speed » page 111 .
	High beam or flasher activated » page 37 .
	Rear seat belt not fastened » page 30 .
	A rear seat belt is fastened » page 30 .
	Low outside temperature » page 49 .
	High beam Assist System switched on » page 39 .
	Bulb in the vehicle exterior lights failed » page 38 .
	Charging of the 12-volt vehicle battery » page 120 , » page 123 , » page 123 .
	Engine oil pressure too low » page 119 .
	Engine oil level too high or engine oil level sensor impaired » page 119 .
	Engine oil level too low » page 119 .
	Coolant temperature too high » page 120 .
	Coolant level is too low » page 119 .
	Along with  - Engine fault » page 123 .
	Windscreen washer fluid level too low » page 44 .
	Clogged particle filter » page 120 .
	Automatic gearbox overheated » page 104 , » page 104 .
	Automatic gearbox impaired » page 104 , » page 104 .
	Service event » page 147 .
	Engine was switched off automatically by START-STOP » page 102 .