

Index

A

Accessories	107
AE lock	44
AF frames	48
AUTO mode (shooting mode).....	14, 24
AV cable	107, 108

B

Batteries → Date/time (date/time battery)	
Battery charger	2, 107
Battery pack	
Charging	10
Eco mode	100
Level	127
Power saving	18

C

Camera	
Reset all	104
Camera access point mode	76
Camera Connect	70
CameraWindow	76
CANON IMAGE GATEWAY	70, 82
Center (AF frame mode).....	49
Color (white balance).....	46
Connecting via an access point.....	78
Continuous shooting.....	33
Cropping	113
Custom white balance	47

D

Date/time	
Adding date stamps	32
Changing	13
Date/time battery	13
Settings	12
World clock	99
Defaults → Reset all	
Digital zoom	28, 52
Display language	13
DPOF	116
Drive mode	33

E

Eco mode	100
Editing	
i-Contrast	67
Red-eye correction	68
Resizing images	67
Editing or erasing connection	
information	94
Erasing	63
Error messages	124
Exposure	
Compensation	44
Eye-Fi cards	2

F

Face AiAF (AF frame mode).....	48
Face self-timer (shooting mode).....	41
Favorites	66
File numbering	102
Fireworks (shooting mode).....	37
Fish-eye effect (shooting mode).....	38
Flash	
Deactivating flash	32, 52
On	51
Slow synchro	51
Focusing	
AF frames	48
AF-point zoom	50
Servo AF	49
Focus lock	49
Focus range	
Infinity	48
Macro	47
FUNC. menu	
Basic operations	20
Table	130, 134

G

Grid lines	52
------------------	----

I

i-Contrast	46, 67
Images	
Display period	53
Erasing	63
Playback → Viewing	
Protecting	60
Image stabilization	54

Image Sync	91
Indicator	22
Infinity (focus range)	48
ISO speed	45

L

Lamp	35
Long shutter (shooting mode).....	42
Low light (shooting mode)	37

M

Macro (focus range)	47
Magnified display	59
Memory cards	2
Recording time	137
Menu	
Basic operations	21
Table	129
Metering method	45
Miniature effect (shooting mode).....	39
Monochrome (shooting mode).....	40
Movies	
Recording time	137

P

P (shooting mode)	44
Package contents	2
Photobook set-up	118
PictBridge	107, 112
Playback → Viewing	
Portrait (shooting mode)	37
Poster effect (shooting mode)	38

Before Use

Basic Guide

Advanced Guide

Camera Basics

Auto Mode

Other Shooting
Modes

P Mode

Playback Mode

Wi-Fi Functions

Setting Menu

Accessories

Appendix

Index

