

⚠ WARNING

ACC does not respond to stationary objects or to crossing or oncoming objects.

❗ ACC is intended primarily for use on motorways.

Speed range

ACC allows a speed setting in the range of 30-160 km/h.

If control is started at a speed of less than 30 km/h on vehicles with an automatic transmission, the speed is automatically increased to 30 km/h or controlled according to the speed of the vehicle ahead.

Distance level

The distance to the vehicle ahead can be adjusted to five different levels.

⚠ WARNING

► Maintain a minimum distance in accordance with the country-specific legal regulations.

Automatic stop and start

A vehicle with an automatic transmission can be decelerated to a stop using the ACC and start moving again. Control is disconnected in case of longer holding periods.

Overtaking

If your vehicle changes to the fast lane and no vehicle is detected in front, ACC accelerates up to the set speed.

Status display in the instrument cluster display



illuminates - ACC is activated



illuminates together with - Control is active
When the control starts, the set speed is displayed.




illuminates - ACC does not decelerate sufficiently

► Depress the brake pedal.

Operation

Operating with the lever



- ON** Activate ACC (control inactive)
- RESUME** Start or resume control/Increase speed in steps of 1 km/h (sprung position)
- CANCEL** Stop control (sprung position)
- OFF** Deactivate ACC
- SPEED+** Increase speed in steps of 10 km/h
- SPEED-** Reduce speed in steps of 10 km/h
- DISTANCE** Set distance level
- SET** Start control/Reduce speed in steps of 1 km/h

Starting control with the current speed


► Tap on **SET**.

Or:

► If no speed is saved, move the lever to the sprung position **RESUME**.

Set distance level

► Move the **DISTANCE** switch to the sprung position - or +.



Line **A** appears in the display, indicating the change in distance.

► Use the **DISTANCE** switch to set the desired distance level.

For temporary acceleration

► Depress the accelerator pedal.

The vehicle accelerates and control is temporarily interrupted. Upon releasing the accelerator, control is resumed.