

Subject **WP Sequence No. – Page No.**

H

Harness/Container	0037 00-1
Hook and Pile Tapes, Riser	0035 00-1
Housing, Main Ripcord	0044 00-1
Housing, Reserve Ripcord	0043 00-1
How to Use this Manual	v

I

Illustrated List of Manufactured Items	0077 00-1
Initial Receipt.....	0004 00-1
Inspection Criteria, Porosity	0048 00-1
Inspection	0011 00-1
Installation of Safety Stow	0005 00-9
Installing Attaching Tie	0004 00-2
Installing the Automatic Activation Device	0014 00-43
In-Storage Inspection	0011 00-8/ 0060 00-2
Introduction To Maintenance Allocation Chart (MAC)	0063 00-1

J

Junction Plate, AAD	0045 00-1
---------------------------	-----------

L

Layout and Line Check	0013 00-3/0014 00-6
Layout.....	0005 00-3/0006 00-3
Line Sets (Preferred Method), Suspension	0054 00-1
Lines (4A/B and 5A/B), Suspension.....	0053 00-1
Lines (Alternate Method), Suspension/Cascade	0055 00-1
Lines, Control	0057 00-1
List of Acronyms and Abbreviations.....	0001 00-3
List of Effective Pages	A
Location And Description of Major Components.....	0002 00-1
Lubrication Service Intervals	0008 00-3

M

Main and Reserve Parachute Characteristics, Table 1	0002 00-14
Main and Reserve Pilot Chute Attachment	0020 00-1
Main Canopy Release Cable Channel.....	0034 00-1
Main Canopy Release Ripcord and Housing	0042 00-1
Main Canopy Replacement.....	0025 00-1
Main Deployment Bag.....	0021 00-1
Main or Reserve Canopy, Crossport.....	0027 00-1
Main Parachute, Packing Procedures.....	0014 00-1
Main Pilot Chute Bridle Line or Deployment Bag.....	0018 00-1