



Figure 16-60. The conditioned air distribution system on a Boeing 737. The main distribution manifold is located under the cabin floor. Riser ducts run horizontally then vertically from the manifold to supply ducts, which follow the curvature of the fuselage carrying conditioned air to be released in the cabin.