

- |                              |                               |
|------------------------------|-------------------------------|
| A - Safety Switch            | H - Aft Air Valve, Close      |
| B - Mechanic's Signal        | I, J, K, L - Fuel Dumping     |
| C - Forward Air Damper       | M - Port Helium Valve, Close  |
| D - Forward Air Valve, Open  | N - Port Helium Valve, Open   |
| E - Aft Air Valve, Open      | O - St'bd Helium Valve, Close |
| F - Aft Air Damper, Close    | P - St'bd Helium Valve, Open  |
| G - Forward Air Valve, Close | Q, R - Slip Tanks             |

(A)

(I) (J) (K) (L)

(M) (O)




Fig. XI - Flight and Instrument Panel