

5. The system connects to IBM to verify the authorization code and retrieve the license key. After the license key has been retrieved, it is automatically applied. The Encryption screen is updated to indicate that the encryption feature is licensed (Figure 6-90).

The screenshot shows the 'System Setup' window with the 'Encryption' tab selected. The left sidebar lists various setup steps, with 'Encryption' currently active. The main content area asks 'Was the encryption feature purchased for this system?' with 'Yes' selected. Below, it says 'Activate the encryption licenses for each enclosure.' and shows a table with one row: 'Control Enclosure' with M/T-M '9846-AF8' and S/N 'F313150', marked as 'Licensed' with a green checkmark. At the bottom, there are 'Need Help', 'Cancel', 'Back', and 'Next' buttons.

Type	M/T-M	S/N	Licensed
Control Enclosure	9846-AF8	F313150	✓

Figure 6-90 Encryption screen showing feature licensed

6. Click **Next**.