



- L 1 Light Control Rheostat
- O 1 Outer Mirror SW
- P 3 Parking Brake SW
- P 4 Power Point Socket
- R 2 Radio Receiver Assembly
- R 3 Radio Receiver Assembly
- R 5 Rear Window Defogger SW
- S 9 Security Indicator Lamp
- S 11 Short Connector (Theft Warning ECU)
- S 12 Spiral Cable
- S 13 Stop Lamp SW
- T 9 Theft Warning ECU
- T 13 Turn Signal Flasher
- U 1 Unlock Warning SW

Position of Parts in Instrument Panel

