



---

Position of Parts in Body

---

- B 9 Back Door Lock Assembly
- B 10 Blower Motor (Rear)
- B 11 Blower Resistor (Rear)
- B 12 Blower SW (Rear)
  
- C 15 Center Stop Lamp
- C 16 Clearance Warning ECU
  
- D 4 Door Courtesy SW (Driver's Side)
- D 5 Door Courtesy SW (Front Passenger's Side)
- D 6 Door Courtesy SW (Rear LH)
- D 7 Door Courtesy SW (Rear RH)
- D 8 Door Lock Assembly (Driver's Side)
- D 9 Door Lock Assembly (Front Passenger's Side)
- D 10 Door Lock Assembly (Rear LH)
- D 11 Door Lock Assembly (Rear RH)
  
- F 11 Front Seat Inner Belt (Driver's Side)
- F 13 Fuel Suction Pump and Gage Assembly
  
- J 35 Junction Connector
- J 36 Junction Connector
  
- L 2 License Plate Lamp
  
- M 2 Map Lamp
  
- O 2 Outer Rear View Mirror (LH)
- O 3 Outer Rear View Mirror (RH)

## Position of Parts in Body

