

MiniPanel™ FX DMX CHART -V110-

Mode/Channel			Value	Function
St	Ba	Ex		
22 Ch	19 Ch	34 Ch		
1	1	1	0-255	PAN Movement 8bit : Pan Movement
2		2	0-255	Pan Fine 16bit Fine control of Pan movement
3	2	3	0-255	TILT Movement 8bit : Tilt Movement
4		4	0-255	Tilt Fine 16bit Fine control of Tilt movement
5	3	5	0-225 226-235 236-255	Speed Pan/Tilt movement: max to min speed blackout by movement no function
6	4	6		Pan Motor continuous rotation
			0-127	no function
			128-189	Forwards Pan rotation from fast to slow
			190-193	No rotation
7	5	7	194-255	Backwards Pan rotation from slow to fast
				Tilt Motor continuous rotation
			0-127	no function
			128-189	Forwards Tilt rotation from fast to slow
8	6		190-193	No rotation
			194-255	Backwards Tilt rotation from slow to fast
9	7		0-255	Red LED - all arrays : Red (0-Black , 255-100% Red)
10	8		0-255	Green LED - all arrays : Green (0-Black , 255-100% Green)
11	9		0-255	Blue LED - all arrays : Blue (0-Black , 255-100% Blue)
			0-255	White LED - all arrays : White (0-Black , 255-100% White)
		19	0-255	Red LED - array 1 : Red (0-Black , 255-100% Red)
		20	0-255	Green LED - array 1 : Green (0-Black , 255-100% Green)
		21	0-255	Blue LED - array 1 : Blue (0-Black , 255-100% Blue)
		22	0-255	White LED - array 1 : White (0-Black , 255-100% White)
		23	0-255	Red LED - array 2 : Red (0-Black , 255-100% Red)
		24	0-255	Green LED - array 2 : Green (0-Black , 255-100% Green)

		25	0-255	Blue LED - array 2 : Blue (0-Black , 255-100% Blue)
		26	0-255	White LED - array 2 : White (0-Black , 255-100% White)
			• • • • •	
		31	0-255	Red LED - array 4 : Red (0-Black , 255-100% Red)
		32	0-255	Green LED - array 4 : Green (0-Black , 255-100% Green)
		33	0-255	Blue LED - array 4 : Blue (0-Black , 255-100% Blue)
		34	0-255	White LED - array 4 : White (0-Black , 255-100% White)
12	10	8	0-31 32-63 64-95 96-127 128-159 160-191 192-223 224-255	Shutter, strobe: Led turn off Led turn on Strobe effect slow to fast Led turn on Pulse-effect in sequences Led turn on Random strobe effect slow to fast Led turn on
13	11	9	0-255	Dimmer intensity: Intensity 0 to 100%
14	12	10	0-7 8-39 40-71 72-103 104-135 136-167 168-199 200-231 232-255	Color Macro: No function from RED to YELLOW from YELLOW to GREEN from GREEN to CYAN from CYAN to BLUE from BLUE to MAGENTA from MAGENTA to RED from RED to WHITE Crossfading colours from slow to fast
15	13	11	0-4 5--9 10--14 15-19 20-24 25-29 30-34 35-39 40-44 45-49 50-54 55-59 60-64 65-69 70-74 75-79 80-84 85-89 90-94 95-99 100-104 105-109	Color Presets: No function White2700k White3200k White4200k White5600k White6500k White8000k Yellow Magenta Cyan Salmon Turquoise Light Green Steel Blue Orange Straw Pale Lavander Pink Red Green Blue White

			110-114 115-119 120-124 125-255	Rainbow1 Rainbow2 Rainbow3 Reserved
16	14	12	0-255	<u>Color Presets Dimmer:</u> Dimmer 0% to 100%
17	15	13	0--9 10-14 15-19 20-24 25-29 30-34 35-39 40-44 45-49 50-54 55-59 60-64 65-69 70-74 75-79 80-84 85-89 90-94 95-99 100-104 105-109 110-255	<u>Chase Patterns:</u> Led trun off Chase 1 Chase 2 Chase 3 Chase 4 Chase 5 Chase 6 Chase 7 Chase 8 Chase 9 Chase 10 Chase 11 Chase 12 Chase 13 Chase 14 Chase 15 Chase 16 Chase 17 Chase 18 Chase 19 Chase 20 Reserved
18	16	14	0-125 126-130 131-255	<u>Chase Speed:</u> Fast to Slow Backward Stop (Speed=0) Slow to Fast Forward
19	17	15	0-255	<u>Chase Fade:</u> Fade Chase
20	18	16	0-255	<u>Zoom :</u> Zoom adjustment
21		17	0-255	<u>Zoom Fine :</u> Fine control for Zoom adjustment
22	19	18	0-79 80-84 85-87 88-90 91-93 94-96 97-99 100-119 120-139 140-159 160-179 180-199 200-219 220-239 240-255	<u>Reset, internal programs:</u> Normal All motor reset Scan motor reset no function no function no function Others motor reset Internal program 1 (scene1~8 of EEPROM) Internal program 2 (scene9~16 of EEPROM) Internal program 3 (scene17~24 of EEPROM) Internal program 4 (scene25~32 of EEPROM) Internal program 5 (scene33~40 of EEPROM) Internal program 6 (scene41~48 of EEPROM) Internal program 7 (scene49~56 of EEPROM) Reserved