

VEHICLE MAINTENANCE		
Engine Compartment - CR-4	73	Headlamps 85
Engine Compartment - 4SPTC	74	Head Lamp Adjustment 85
Changing Engine Oil	75	Head Lamp Bulb Replacement 86
Changing Oil Filter	75	Bulb Specification 87
Engine Air Filter	76	Fuses 88
Fuel Filter & Priming CR-4	77	Vehicle Care 89
Fuel Filter & Priming 4SPTC	77	FUEL, LUBRICANTS & COOLANTS
Fan Belt Tension Adjustment	78	Fuel 92
Brake Clutch System Bleeding	79	Lubricants 93
Cooling System	80	Coolants 93
Brake System	80	Recommended Oils, Lubricants 94
Brake Adjustment	82	TECHNICAL SPECIFICATIONS 95
Wheels & Tyres	83	SPECIAL INSTRUCTIONS 99
Wheel Change	83	SERVICE SCHEDULE 101
Wheel Alignment	83	RECORD OF SERVICE PERFORMED 105
Tyre Pressure	83	RECORD OF REPAIRS CARRIED OUT 107
Wheel Balancing	84	ALPHABETICAL INDEX 108
Replacing Tyre / Tube	84	ABBREVIATIONS 110
Replacing Tyre / Rim	84	
Tyre Rotation	85	