

Headlamp Leveling Switch

A motorised headlamp leveling arrangement with the setting knob at the RH side of dash board.

As and when required headlamp leveling setting is done by rotating the knob to select one of the level marked in the switch depending upon the loading of vehicle.

Loading Condition	Switch position / Marks assigned.
Unladen + One person in Driver seat / Driver + Co-Driver / Driver + Co driver + all the Seats farthest to rear occupied	0
All the seats occupied / Laden (All seats occupied Luggage in boot space to achieve permissible load on the rear axle.	1
Driver + Evenly distributed load in the boot to obtain permissible load on corresponding axle.	2

Since the leveling switch takes care of focus pattern under different load conditions; it is advisable to select the correct position before starting a trip (depending on load)



Headlamp Levelling Switch