

Do's

12. Disconnect alternator terminals while carrying out any welding on the vehicle.
13. **Avoid panic braking.** Use lower gears while descending gradients.
14. **Start the vehicle always in the 1st gear** to avoid premature clutch wear.
15. **Keep both foot and parking brakes properly adjusted.**
16. **Before engaging reverse gear, ensure that vehicle has come to a stop,** declutch, wait for a few seconds and shift into reverse gear.
17. **When parking on slopes, use wheel chocks,** apply parking brake and keep vehicle in low gear.
18. **In case of emergency** parking or breakdown on road, **push the hazard warning switch** to flash all the blinker lights to warn other road users.
19. **Release parking brake before driving off.**
20. **Release the ignition key as soon as engine starts.**
21. Retighten wheel mounting nuts after 100 km of every wheel change. Tightening Torque : 12 -15 mkg.
22. Use only recommended FUSES and always keep spare fuses in the box.
23. **In case of engine not starting first check the fuse of fuel injection pump solenoid.**
24. **Ensure** doors are properly closed.
25. **If your vehicle has a turbocharged engine, keep engine at idling speed for atleast a minute after starting and also before stopping it,** to protect the turbocharger against damage due to oil starvation.