

BEFORE DRIVING**CHECK**

- Fuel level
- Coolant level
- Engine oil level
- Tyre pressure
- Brake and clutch fluid level
- Doors are firmly closed

ADJUST

- Driver seat
- Rear view mirrors

ENSURE

- Gear shift lever is in neutral position.
- All switches and lamps are working.
- Brake fail indicator is 'OFF'
- Fuel level indicated on fuel gauge is above reserve tank.

START THE ENGINE AND OBSERVE THAT :

- LOW OIL PRESSURE INDICATOR LIGHT GOES 'OFF'
- BATTERY CHARGING INDICATOR LIGHT GOES 'OFF'
- ENSURE THAT PARKING BRAKE IS RELEASED (INDICATOR LAMP 'OFF')
- VEHICLE IS NOW READY FOR A DRIVE.
- DO NOT ALLOW VEHICLE TO ROLL BACK ON GRADIENTS.

During running - in period :

i.e. first 2,000 km of operation :

Do not exceed the following vehicle speeds :

Gear	Min	Max
1st	-	20
2nd	15	35
3rd	25	55
4th	35	75
5th	45	95

- Avoid rapid acceleration and prolonged high speed running of the engine.
- Avoid sudden braking.
- Retighten wheel nuts to 12-15 mkg. torque after first 100 km of running of a new vehicle and after every wheel change.