

Changing fuel filter element (4SPTC) :

Unscrew drain plug and drain fuel from fuel bowls. Remove fuel filter with top cover from mounting bracket.

Unscrew fuel filter bowl mounting bolt and replace bowl with element.

Replace fuel tank side filter element at specified intervals and FIP side filter element.

Assemble fuel filter and fit it on mounting bracket.



Changing Fuel filter (4SPTC)

Priming fuel system (4SPTC) :

Unscrew fuel lift pump plunger knob. Pull and push it 10-14 times (30-40 times if fuel tank has been completely emptied). Tighten fuel lift pump plunger knob. Start engine and check for smooth running.

If erratic fuel supply is still felt, check for air suction in fuel pipeline from fuel tank to FIP and rectify.



Priming Fuel System (4SPTC)