

filters and batteries in compliance with the current legislation.

- Do not allow any unauthorised person to tamper with engine settings or to carry modifications on the vehicle.
- Never allow the vehicle to run out of fuel.
- Parts like brake liners, clutch disc should be vacuum cleaned. Do not use the compressed air for cleaning these parts which may spread the dust in the atmosphere.

While carrying out the servicing or repairs on your vehicle, you should pay keen attention to some of the important aggregates, which greatly affect emission. These components are :

- 1. Fuel injection pump, Injectors/ Nozzles**
- 2. Air intake & Exhaust system especially for leakages**

3. Cylinder head for valve leakage

4. All filters such as air, oil and fuel filters (check periodically)

5. Turbocharger and intercooler (if fitted)

6. Catalytic converter (if fitted)

7. EGR System and components

8. Electrical Connections for EGR

This Owner's Manual contains further information on driving precautions and maintenance care leading to environment protection. Please familiarise yourself with these aspects before driving.