

Roof A. C.

Where roof mounted air conditioner unit is installed, the blower switch has 4 positions “HIGH”, “MED”, “LOW” and “OFF”. The switch is located on left hand side on the roof A.C Air flow direction can be adjusted by adjusting the air vents. The roof A.C. can be switched ‘ON’ provided the front A.C. is ‘ON’. However, the blower of the roof A.C unit can be operated independently.



Roof AC