

Driver's & Co-driver's seat

Adjustable type seat is provided for driver and co-driver. The driver seat is fitted with lever and handle, to adjust the seat. The seat can be adjusted in forward and backward directions. In few versions, both seats are also provided with lumbar support (3) to give you maximum driving comfort.

To achieve correct position for proper driving, lift the handle (2) and slide the seat either forward or backward. Once the desired position is achieved push down the handle to lock the seat. Turn the lever (1) to adjust backrest to the desired position. Release the lever to lock it.

Do not adjust seat while driving.



1. Seat backrest inclination adjustment lever

2. Seat sliding (forward & backward) lever

3. Lumbar support adjustment knob (if fitted)

