

ON

By turning the key to this position all remaining electrical systems become operative and lamps of battery charging indicator, low oil pressure will come 'ON'.

In 'ON' position, the glow plug controller switches 'ON' the glow plugs and glow indicator lights up. After a few seconds, depending on the ambient temperature, the indicator light only goes off indicating that the engine can be started. Glow plugs remain 'ON' for few seconds and switches 'OFF' automatically.

As a safety feature glow plugs are automatically switched 'OFF' after a lapse of certain time if the engine is not started to conserve battery.

In this case to start the engine repeat the operation by first going to 'ACC' or 'LOCK' position.

START

Turn the key further clockwise to start position (spring loaded) to operate starter motor. As soon as the engine starts release the ignition key, so that key can come back to 'ON' position and starter motor disengages and glow plug is switched 'OFF'. Vehicle is driven in this position. By turning the ignition key from 'ON' position to 'ACC' or 'LOCK' position engine can be stopped.