

Power Windows : (if provided)

Separate knobs are provided on the switch to operate the four door window glasses individually .

To open the door window glass, push the respective knobs down.

To close the door window glass, pull the respective knobs up.

In the lock position, the rear window switches become inoperative. However the rear windows can be operated by the switches on the console. Illumination on rear window switches goes 'OFF' in locked position. press down the lock button to unlock. Express power down on driver and co-driver windows are provided.

Individual window winding switches have been provided only on the rear doors.



Switches on the central console for operating the door glasses



Individual Switches on the rear doors for operating the rear door glasses