

Low Oil Pressure Indicator:



When the ignition key is turned to the 'IGN' position, symbol lights up and goes off as soon as the required engine oil pressure is developed after starting the engine.

If the low oil pressure indicator does not glow or remains 'ON' with the 'IGN' on and engine is running, it indicates a fault in the electrical circuit/lubrication system. Check & get the problem attended to at an Authorised Service outlet.

Battery Indicator:

Symbol lights up when the 'IGN' is turned 'ON' and should go 'OFF' after the engine starts.



NOTICE

If it remains 'ON' while the engine is running. It indicates that the battery is not getting charged. Switch off all unnecessary electrical equipment and get the problem attended to at an Authorised Service outlet.

Parking Brake Indicator cum Low Brake Fluid Warning Light :



This indicator has multiple functions as follows :

- It lights up when the parking brakes is applied and goes off when parking brake is released.
- It also lights up when brake fluid level is low.

- When ignition key is turned to "IGN" position, this indicator lights up and goes off when engine starts in normal condition. If it continuously ON while engine is running, get the problem attended to an Authorised Service Outlet.

Water In Fuel Indicator:



This indicator indicates excess water accumulation in the sedimenter. It turns 'ON' when ignition is turned 'ON' and goes 'OFF' in approximately three seconds. When this lamp remains 'ON', water needs to be drained from sedimenter immediately.

⚠ CAUTION

If water is not drained from sedimenter, it can cause serious damage to fuel injection system.

Seat Belt Indicator:



The indicator initially flashes when the ignition is ON and seat belt is not fastened. It will continue to flash until the vehicle exceeds a speed of 20 kmph. After that, it will remain continuously ON accompanied by a buzzer that will buzz approximately for 100 seconds. After that, the buzzer goes OFF but the indicator continues to remain ON.