

SERVICE SCHEDULE

SR. NO.	OPERATION	FREQUENCY (In km)	PDI	1500	15000	30000	45000	60000	75000	90000	105000
	PROPELLER SHAFT										
1	Grease propeller shaft with grease gun (at slip joint - splines end) & Check Centre bracket mounting bolts for looseness. Tighten if necessary	15000 km			•	•	•	•	•	•	•
	AXLE										
1	Change oil in axle (First at 15,000 KM, there after every 75,000 KM)	75000 km			•					•	
2	Change grease in rear hubs& adjust bearing play (only for TML axle)	45000 km					•			•	
3	Clean breather in Axle	Every Service	•	•	•	•	•	•	•	•	•
	SUSPENSION & STEERING										
1	Grease idler arm (seal type idler arm)	15000 km			•	•	•	•	•	•	•
2	Wheel alignment & balancing. Inspect if abnormal condition noticed	30000 km				•		•		•	
3	Apply torque on front suspension bolts.	Every Service	•	•	•	•	•	•	•	•	•
4	Check condition of rubber bushes in the following & replace if necessary. 1) Top wishbone 2) Lower wishbone 3) Anti roll bars 4) Leaf Spring	45000 km					•			•	
5	Check shock absorber, its bushes, replace if necessary	30000 km				•		•		•	
6	Grease steering spindle and sleeve	30000 km				•		•		•	
7	Check & adjust front wheel bearing play & Change grease in front hubs	45000 km					•			•	
8	Check steering gearbox oil level & top-up, if necessary (only for mechanical steering)	45000 km					•			•	
9	Change oil in power steering system & change filter element	75000 km							•		
10	All the suspension & steering ball joints to be checked for any rubber boot tear, attend if any.	Every Service	•	•	•	•	•	•	•	•	•
	CLUTCH & BRAKES										
1	Check parking brakes, adjust if necessary	15000 km			•	•	•	•	•	•	•
2	Check front brake pads & rear brake linings. Replace if necessary	15000 km			•	•	•	•	•	•	•
3	Change Clutch & Brake Fluid (or 2 years whichever is earlier)	30000 km				•		•		•	