

ACCESSORY SWITCHES

There are six (6) operating switches provided on the centre console of your vehicle's dashboard, just above the Music System.

Rear Windshield Demister (unlatched switch) (if fitted)

Push the operating switch on the fascia to turn the demister "ON". The demister will switch off automatically after 15 minutes.

**NOTICE**

Clean the windshield glass carefully from inside to avoid any damage to demister heater element

Rear Fog lamp (unlatched switch) (if fitted)

The fog lamps are provided on rear bumper to improve the visibility and warning in foggy weather or during heavy rains.



The rear fog lamps can be switched on with parking lamp and front fog lamps 'ON' and can remain 'ON' till the parking lamp is switched 'OFF'. The rear fog lamps can also be switched 'ON' even if only headlights are 'ON'.

NOTICE

Use only during foggy conditions or heavy rains if required.

Rear Windshield Wash and Wipe (unlatched switch) (if fitted)

Push and hold the switch knob for the operation of the wash function for the desired duration for rear visibility through glass.



The function indicator lights up when wash function is "ON". Along with wash fluid getting sprayed, the wiper also operates with a delay to wipe the glass surface through a timer control unit. On release of this switch, this function stops.

Rear Windshield Wiper (Latched switch) (if fitted)

To operate this function, push to switch 'ON' and again, push to switch 'OFF'. The function indicator lights up when the wiper function is 'ON'.

**Front Fog lamp (Latched switch)(if fitted)**

The fog lamps are provided on front bumper to improve the visibility in foggy weather or during heavy rains.

