

File

View

Option

Help

vecSpectra

Golden Dragon Hotel

> Home

Setup

Inspect

Dashboard

Preferences

Login

Help

Site Info

Site Name: Golden Dragon Hotel

Elevators: 4 (Grouped)

Last Maint.: 2012-04-11

Status: Normal

[More info...](#)

Elevators

Passenger Lift #1

Host Name: NO1

Status: Idle

Last Maint.: 2012-04-11

▲ 28

Closed

Logs

Motion

Calls

Control

7 ▲ ▼

6 ▲ ▼

5 ▲ ▼

4 ▲ ▼

3 ▲ ▼

2 ▲ ▼

1 ▲ ▼

G ▲ ▼

Passenger Lift #2

Host Name: NO2

Status: Idle

Last Maint.: 2012-04-11

▼ 18

Closed


Logs

Calls


Motion

Control

Pos.: 4217.05 mm



Speed: 2.480 m/s



Passenger Lift #3

Host Name: NO3

Status: Offline

Last Maint.: ---

--

Calls

Motion

Logs

Control

[12:30:45] Goto 5/F

[12:30:50] Arrive 5/F

[12:40:50] Parking

[12:55:00] Disconnected

Online

Local IP: 192.168.1.200

Home Screen (Vertical)

> Home > Inspect

- > Overview
- > Calls and Schedule
- > Motion
- > Devices
 - [Hall Link](#)
 - Car Link
- > Logs
- > Statistic

OS native design Menu tree

Hall Link Device List:

ID	Type/Name
2	DM3A (Main Lobby)
3	DM3A
4	DM3A
5	DM2A
6	GP4G
7	Liftshow (Hotel Lobby)

Refresh

Device

Device ID: 7 (0x07)
Device Type: 4 (DM3A)
Serial Number: 00001504
Power Mode: Normal
Status: Normal
Hardware Version: 0x0100
Firmware Version: 0x0221

Control

Refresh Set Output
Power Down Set Display
Reset Set Trigger

I/O Status

Input: 0x00108000

Output: 0xF0000001

	In	Out		In	Out		In	Out		In	Out
1	●	●	9	●	●	17	●	●	25	●	●
2	●	●	10	●	●	18	●	●	26	●	●
3	●	●	11	●	●	19	●	●	27	●	●
4	●	●	12	●	●	20	●	●	28	●	●
5	●	●	13	●	●	21	●	●	29	●	●
6	●	●	14	●	●	22	●	●	30	●	●
7	●	●	15	●	●	23	●	●	31	●	●
8	●	●	16	●	●	24	●	●	32	●	●

Display

 28

Char: 28
Arrow: 2 (Up Rolling)
Msg: None
Dim: No

Inspect Screen

For all dimension not stated, please take approximate value by the scale as shown in this file and round them to nearest 12px unit. Except 6px and 18px.



DM3A Inspect



DM2A Inspect

Device

Device ID: 7 (0x07)
Device Type: 1 (GP32)
Serial Number: 00001504
Power Mode: Normal
Status: Normal
Hardware Version: 0x0100
Firmware Version: 0x0221

Control

Refresh

Power Down

Reset

I/O Status

Input: 0x00108000

Output: 0xF0000001

In	Out	In	Out	In	Out	In	Out	
1			9			17		
2			10			18		
3			11			19		
4			12			20		
5			13			21		
6			14			22		
7			15			23		
8			16			24		

Set Trigger

Set Output

GP32 Inspect

Device

Device ID: 7 (0x07)
Device Type: 3 (GP4G)
Serial Number: 00001504
Power Mode: Normal
Status: Normal
Hardware Version: 0x0100
Firmware Version: 0x0221

Control

Refresh

Power Down

Reset

Gong

Gong Code: 2

Floor ID: 15

Set Gong

I/O Status

Input: 0x00


Output: 0x0F


In	Out	
1		
2		
3		
4		

Set Trigger

Set Output

GP4G Inspect





Door Inspect Screen

Safety Chain

- DFC - Door Fully Closed
- DW - Hall Door Closed
- HES - Hall Safety Sense
- CES - Car Safety Sense

Feedbacks

- ENABLE - Main Contact
- DBDE
- DBDF
- BS - Brake Sense
- LVCFB - LVC feedback

Motor Driver

- DRVOK - Driver Ready
- DRVBM - Driver Brake Monitor
- DRVENF - Driver Enabled Feedback

Door Zones

- UDZ - Upper Door Zone
- LDZ - Lower Door Zone
- USL - Upper Shaft Limit
- LSL - Lower Shaft Limit

Inspection

- INS - Inspection
- INSUP - Inspection Up
- INSDOWN - Inspection Down

System

- ADO - Advance Door Open
- V24MON - 24V Monitor
- ENCF - Encoder Fault Sense
- THM - Temperature Monitor

Generic Relay Output

- RL1 - UR *Output port name is fixed*
- RL2 - DR
- RL3 - RR *Output source name change according to crossbar setting*
- RL4 - BR
- RL5 - RBR
- RL6 - SPDCHK
- RL10 - FR

Digital Output

- P10.1 - DRVEN
- P10.2 - DRVFWD
- P10.3 - DRVREV
- P10.4 - Always 0
- P10.5 - Always 0 *Unassigned output will display as '0'*
- P10.6 - Always 0
- P10.7 - Always 0

Config I/Os

Input/Output Inspect Screen

Inputs and Outputs Status


LED Color Scheme

● (Y) Yellow: Output

● (G) Green: Input/General Signal




● (R) Red: Output/Fault Signal

Bright color as '1'/Active
Dull color as '0'/Inactive



Input Name: Advance Door Open
Input Source: P1.2
Inverted: No
Status: Logic 1

Mouseover each I/O will show the
physical port name and status
(inverted/0-1 status) of the I/O



Config I/Os

Block Diagram I/O Inspect Screen

FileViewOptionHelp

vecSpectra

Passenger Lift #1 (NO1)

> Home > Inspect > Logs > Log #1029

Normal Log: Green
Warning: Yellow
Critical: Red

20px, regular, #000

24x24px

Log #1029

Click this to prompt user with yes/no msgbox 'sure to delete?' and delete log when answer yes

DeleteSearch<>

1px, solid, #888

16px, bold, #000
can show 2 lines of error title

14px, bold, #000
14px, regular, #000

[831] Main Contact feedback timeout

1px, solid, #ccc

Basic Information

Type:	Warning
Date:	2012-09-23
Time:	23:15:20
Error Code:	831
Description:	Main Contact feedback timeout

Extra Information

Counts:	8
Last Happen:	2012-08-31 10:20:30
Extra data:	← Align
Sequence:	0x1A
Sequence Time:	21.50
Position:	7823.20mm
Speed:	1748.12mm/s

← Align

Playback





Click this to return to log (table style)

short record of Speed, I/O, calls playback, assistant information

Online

Local IP: 192.168.1.200

Log Screen (Card style)

	[12:34:56] [MCS] Error 1
	[12:34:56] [MCS] Error 2
	[12:34:56] [OCS] Long error message
	[12:34:56] [MCS] Very long error message 1
	[12:34:56] [OCS] Error 3

4~5 lines
14px regular #000
background stripe on
even lines with #fff and #ddd

Double click each line to goto
Inspect->Log

Info Panel (Logs 1)



Text based summary of the error/logs

Log record #
16px, bold, #00f
Click it to goto Inspect->Log

Log type and icon
14px, bold, var color

16x16px

nav buttons


Log #123456
Warning

<
>

Time:

2012-09-23 16:05:20

Code:

[MCS] 10050

Message:

Brake Open Feedback Time out (Count: 5)

text align
baseline




1px solid #000

Description of 'Code'

Extra information
translate from 'Detail'

Info Panel (Logs 2)

LogCard based error/logs



Display real-time schedule

show horizontal scroll bar if more than 2 column

break into 2 or more column if floor >24 for each column

Calls and Schedule Screen

Color Scheme for charts:

#ed0 


#af4 

#3af 



Pos.: 42.1705 mm

Speed: 2.480 m/s



Grid: X spacing 20px ~0.5second, Y spacing: 10px (auto scale)

Chart size: 235px x 60px

BG: Gradient
#000000->#181818

Pos. Line:
#ed0, solid, 1px


Speed Line:
#af4, solid, 1px

Grid Line:
#444, solid, 1px

*out-dated spec
don't use*




15 16 17 18




Floor ascending
from bottom to top,
For more than 30
floors, use scroll bar.


Info Panel (Calls)





Info Panel (Control)



Info Panel (Control 2)



Info Panel (Control 3)



Site List Manager

'Remote site list' is a preset list of elevator and site saved in the client computer so that user can easily access to his maintaining elevators.

Client can store and remember login info such as IP:Port, username and password.

Quick Access Site List:
List all preseted site at once. Put local elevators on top.
Mark site name as (Remote) for remote site and (Local) for local site.
If local site has preseted data in remote site list, clear out duplicated items.

Site name = 14px, bold, #000
Elevator name = 14px, regular, #000, and indent 24px

Remote Site

For general guideline on Pop-up windows, please refer to 'GNOME Human Interface Guidelines 2.2.2' section '8.2. Window Layout'

<http://developer.gnome.org/hig-book/3.4/design-window.html.en>

Detail Spec Please follow general guideline on Pop-up windows

Form1

Site List

Sample Node

Sample Node

Sample Node

Sample Node

Add Site

Move Up

Add Elevator

Move Down

Delete

Site Information

Site Name: Text1

IP Address: Text1

Username: Text1

Password: Text1

Auth. Key: Text1

Elevator Information

Elevator Name: Text1

IP Address: Text1 ☐ Global

Port: Text1 ☐ Global

Username: Text1 ☐ Global

Password: Text1 ☐ Global

Auth. Key: Text1 ☐ Global

Cancel

Save

Site list tree:
Same display order as
in dashboard
Allow right click to
move up, move down,
copy/cut/paste

Tree
action
buttons

Site info:
When 'site' is selected on site list tree,
ENABLE this section.
When 'elevator' is selected on site list
tree, DISABLE editing on this section.

Elevator info:
When 'site' is selected on site list tree,
HIDE this section.
When 'elevator' is selected on site list
tree, SHOW this this section.

Global=copy setting from site info,
gray out text box when checked

Manage Remote Site