

oDesktop

AddMessage	ClearMessages	CloseAllWindows
CloseProject	CloseProjectNoForce	DeleteProject
DeleteRegistryEntry	DoesRegistryValueExist	DownloadJobResults
EnableAutoSave	ExportOptionsFiles	GetActiveProject
GetAutoSaveEnabled	GetBuildDateTimeString	GetDefaultUnit
GetDistributedAnalysisMachines	GetDistributedAnalysisMachinesForDesignType	GetExeDir
GetGDIObjectCount	GetLibraryDirectory	GetLocalizationHelper
GetMessages	GetPersonalLibDirectory	GetProcessID
GetProjectDirectory	GetProjectList	GetProjects
GetRegistryInt	GetRegistryString	GetRunningInstancesMgr
GetScriptingToolsHelper	GetSysLibDirectory	GetTempDirectory
GetTool	GetUserLibDirectory	GetVersion
LaunchJobMonitor	NewProject	OpenAndConvertProject
OpenMultipleProjects	OpenProject	OpenProjectWithConversion
PageSetup	PauseRecording	PauseScript
Print	QuitApplication	RefreshJobMonitor
ResetLogging	RestoreProjectArchive	RestoreWindow
ResumeRecording	RunACTWizardScript	RunProgram
RunScript	RunScriptWithArguments	SelectScheduler
SetActiveProject	SetActiveProjectByPath	SetLibraryDirectory
SetProjectDirectory	SetRegistryFromFile	SetRegistryInt
SetRegistryString	SetTempDirectory	ShowDockingWindow
Sleep	SubmitJob	TileWindows

oProject

AddDataset	AddMaterial	AnalyzeAll
ChangeProperty	ClearMessages	CloneMaterial
Close	CopyDesign	CutDesign
DeleteDataset	DeleteDesign	DeleteToolObject
EditDataset	EditMaterial	ExportDataset
ExportMaterial	GetActiveDesign	GetArrayVariables
GetChildNames	GetChildObject	GetChildTypes
GetConfigurableData	GetDefinitionManager	GetDependentFiles
GetDesign	GetDesigns	GetEDBHandle
GetLegacyName	GetName	GetObjPath
GetPath	GetPropNames	GetPropValue
GetProperties	GetPropertyValue	GetTopDesignList
GetVariableValue	GetVariables	ImportDataset
InsertDesign	InsertDesignWithWorkflow	InsertToolObject
Paste	PasteDesignBlock	Redo
RemoveAllUnusedDefinitions	RemoveMaterial	RemoveUnusedDefinitions
Rename	Save	SaveAs
SaveAsStandAloneProject	SaveProjectArchive	SetActiveDefinitionEditor
SetActiveDesign	SetPropValue	SetPropertyValue
SetVariableValue	SimulateAll	Undo
UpdateDefinitions		

oDefinitionManager

AddComponent	AddDataset	AddFootprint
AddMaterial	AddPadstack	AddScript
AddSurfaceMaterial	AddSymbol	ChangeProperty
CloneMaterial	CreateComponentData	DeleteDataset

DoesMaterialExist

DoesSurfaceMaterialExist

EditComponent

EditDataset

EditFootprint

EditMaterial

EditPadstack

EditScript

EditSurfaceMaterial

EditSymbol

ExportComponent

ExportDataset

ExportFootprint

ExportMaterial

ExportPadstack

ExportScript

ExportSurfaceMaterial

ExportSymbol

GetInUseProjectMaterialNames

GetManager

GetMaterialNamesInConfiguredLibraries

GetProjectMaterialNames

GetProperties

GetPropertyValue

ImportDataset

ModifyLibraries

RemoveComponent

RemoveFootprint

RemoveMaterial

RemovePadstack

RemoveScript

RemoveSurfaceMaterial

RemoveSymbol

SetPropertyValue

UpdateDefinition

UpdateDefinitionFromLib

oDesign

AbortSolveAsynch

AddDataset

Analyze

AnalyzeAll

AnalyzeAllNominal

AnalyzeDistributed

ApplyMeshOps

ChangeProperty

ClearLinkedData

ConstructVariationString

DeleteDataset

DeleteFieldVariation

DeleteFullVariation

DeleteLinkedDataVariation

DeleteVariation

DistributeAnalysis

EditDataset

EditNotes

ExportConvergence

ExportDataset

ExportMeshStats

ExportProfile

GenerateMesh

GenerateModelDef

GenerateModelDefForMeshAssemblyManager

GenerateSolverInputFiles

GetArrayVariables

GetChildNames

GetChildObject

GetChildTypes

GetConfigurableData

GetData

GetDataVersion

GetDesignType

GetDesignValidationInfo

GetModule

GetName

GetNominalVariation

GetNoteText

GetObjPath

GetOutputVariableValue

GetOutputVariables

GetPostProcessingVariables

GetPropNames

GetPropValue

GetProperties

GetPropertyValue

GetSolutionType

GetSolveAsynchStatus

GetSolveInsideThreshold

GetVariableValue

GetVariables

GetVariationVariableValue

HasDataset

ImportDataset

IsDesignEncrypted

Paste

Redo

RenameDesignInstance

RunToolkit

SARSetup

SetActiveEditor

SetAllowMaterialOverride

SetDesignSettings

SetDoMeshAssembly

SetObjectDeformation

SetObjectTemperature

SetPropValue

SetPropertyValue

SetSolutionType

SetSolveInsideThreshold

SetTuningRanges

SetVariableValue

SimulateLink

Solve

SolveAsynch

StopSimLink

Undo

ValidateDesign

ValidateLink

Editor

AddViewOrientation

AlignFaces

AssignMaterial

AssignSurfaceMaterial

BreakUDMConnection

Chamfer

ChangeProperty

CleanUpModel

CloseAllWindows

Connect

Copy

CoverLines

CoverSurfaces

Create3DComponent

CreateBondwire

CreateBox

CreateCircle

CreateComponent

CreateCone

CreateCutplane

CreateCylinder

CreateEllipse

CreateEntityList

CreateEquationCurve

CreateEquationSurface

CreateFaceCS

CreateGroup

CreateHelix

CreateObjectCS

CreateObjectFromEdges

CreateObjectFromFace

CreateObjectFromFaces

CreatePoint

CreatePolyline	CreateRectangle	CreateRegion
CreateRegularPolygon	CreateRegularPolyhedron	CreateRelativeCS
CreateSphere	CreateSpiral	CreateTorus
CreateUserDefinedModel	CreateUserDefinedPart	CustomGeometryOperation
Defeature	DeletePolylinePoint	Delete
DeleteEmptyGroups	DeleteLastOperation	DeleteOperation
DeletePolylinePoint	DetachEdge	DetachEdges
DetachFace	DetachFaces	DoModalValidationForTest
DoesGeometryMatchForTest	DuplicateAlongLine	DuplicateAroundAxis
DuplicateMirror	Edit3DComponent	Edit3DComponentDefinition
EditEntityList	EditFaceCS	EditNativeComponentDefinition
EditObjectCS	EditPolyline	EditRelativeCS
Export	ExportGDSII	ExportModelImageToFile
Fillet	FitAll	FlattenGroup
GenerateAllUserDefinedModels	GenerateFacetDataForModel	GenerateHistory
GenerateUserDefinedModel	Get3DComponentDefinitionNames	Get3DComponentInstanceNames
Get3DComponentMaterialNames	Get3DComponentMaterialProperties	Get3DComponentParameters
Get3DComponentPartNames	GetActiveCoordinateSystem	GetBodyNamesByPosition
GetChildNames	GetChildObject	GetChildTypes
GetCoordinateSystems	GetEdgeByPosition	GetEdgeIDFromNameForFirstOperation
GetEdgeIDsFromFace	GetEdgeIDsFromObject	GetEdgeLength
GetEdgePositionAtNormalizedParameter	GetEntityListIDByName	GetFaceArea
GetFaceByPosition	GetFaceCenter	GetFaceIDFromNameForFirstOperation
GetFaceIDs	GetFaceIDsOfSheet	GetFullGeometry
GetGeometryModelerMode	GetGroupSubmodelNames	GetMatchedObjectName
GetModelBoundingBox	GetModelDrawAttributes	GetModelUnits
GetName	GetNumObjects	GetObjPath
GetObjectIDByName	GetObjectName	GetObjectNameByEdgeID
GetObjectNameByFaceID	GetObjectNameByID	GetObjectNameByVertexID
GetObjectShapeType	GetObjectsByMaterial	GetObjectsInGroup
GetOperationIndex	GetPartsForUserDefinedModel	GetPoints
GetPropNames	GetPropValue	GetProperties
GetPropertyValue	GetRelativeCoordinateSystems	GetSelections
GetSubGroupsInGroup	GetUserPosition	GetVertexIDFromNameForFirstOperation
GetVertexIDsFromEdge	GetVertexIDsFromFace	GetVertexIDsFromObject
GetVertexPosition	GetWireBodyNames	HealObject
Import	ImportDXF	ImportFromClipboard
ImportGDSII	Imprint	ImprintProjection
Insert3DComponent	InsertComponent	InsertNativeComponent
InsertPolylineSegment	Intersect	Make3DComponentIndenpendent
Mirror	Move	MoveCSToEnd
MoveEdges	MoveEntityToGroup	MoveFaces
ObjectExists	OffsetFaces	OpenExternalEditor
PageSetup	Paste	PerformExplicitSubtractions
ProjectSheet	ProjectUDPPParametersToValidPlane	ProjectUDPPParametersToValidPlane2
PurgeHistory	RefreshAllUserDefinedModelFrom	RefreshUserDefinedModelFrom
RefreshUserDefinedModelTo	RemoveBadEdges	RemoveBadFaces
RemoveBadVertices	RenamePart	ReplaceWith3DComponent
Rotate	Scale	Section
SendParametersAndGenerateUserDefineModel	SeparateBody	SetModelUnits
SetModelValidationSettings	SetPropValue	SetPropertyValue
SetTopDownViewDirectionForActiveView	SetTopDownViewDirectionForAllViews	SetWCS
ShowWindow	Simplify	Split
Stitch	Subtract	SweepAlongPath
SweepAlongVector	SweepAroundAxis	SweepFacesAlongNormal
SweepFacesAlongNormalWithAttributes	ThickenSheet	UncoverFaces

Ungroup
UpdatePriorityList
WrapSheet

Unite
UpgradeVersion
WriteAttributesBlockForTest

UpdateComponentDefinition
Validate3DComponent
WriteHistoryTreeLayoutForTest

oTool-NdExplorer

CheckCausality
ExportNetworkData

ExportFullWaveSpice
ExtractImpulseResponse

ExportNMFDData
SetExportTouchstoneOptions

oTool-ImportExport

ImportANF
ImportAutoCAD
ImportGDSII
ImportIDFandMerge
ImportXFL

ImportANFV2
ImportEDB
ImportGerber
ImportIPC

ImportAWRMicrowaveOffice
ImportExtracta
ImportIDF
ImportODB

oModule-BoundarySetup

AddAssignmentToBoundary
AssignAperture
AssignCurrent
AssignDielectricCavity
AssignFiniteCond
AssignGaussianBeam
AssignHybridRegion
AssignIncidentWave
AssignLinearAntennaWave
AssignLumpedPort
AssignMaster
AssignMultipactionSEE
AssignPerfectH
AssignRadiation
AssignSymmetry
AssignWavePort
AutoIdentifyTerminals
ConvertNportCircuitElementToPorts
DeleteAllBoundaries
EditAnisotropicImpedance
EditCircuitPort
EditDiffPairs
EditFloquetPort
EditGlobalMatEnv
EditImpedance
EditLayeredImp
EditLumpedPort
EditMaster
EditMultipactionSEE
EditPerfectH
EditSecondary
EditTerminal
GetBoundaries
GetDefaultBaseName
GetExcitationsOfType
GetNumBoundaries
GetNumExcitationsOfType
GetPortExcitationCounts

AlphaNumericMatrix
AssignCableNetwork
AssignCylindricalWave
AssignFEBI
AssignFloquetPort
AssignHalfSpace
AssignIERegion
AssignLatticePair
AssignLinkedImpedance
AssignLumpedRLC
AssignMultipactionChargeRegion
AssignNearFieldWave
AssignPlaneWave
AssignSecondary
AssignTerminal
AutoIdentifyLatticePair
ChangeImpedanceMult
CreateNportCircuitElement
DeleteAllExcitations
EditAperture
EditCurrent
EditFEBI
EditFresnel
EditHalfSpace
EditIncidentWave
EditLinkedImpedance
EditLumpedRLC
EditMultipactionChargeRegion
EditNportCircuitElement
EditPrimary
EditSlave
EditVoltage
GetBoundariesOfType
GetDiffPairs
GetHybridRegions
GetNumBoundariesOfType
GetNumHybridRegions
IdentifyNets

AssignAnisotropicImpedance
AssignCircuitPort
AssignDCThickness
AssignFarFieldWave
AssignFresnel
AssignHertzianDipoleWave
AssignImpedance
AssignLayeredImp
AssignLinkedRegion
AssignMagneticBias
AssignMultipactionDCBias
AssignPerfectE
AssignPrimary
AssignSlave
AssignVoltage
AutoIdentifyPorts
CircuitPortToLumpedPort
CreatePML
DeleteBoundaries
EditCableNetwork
EditDielectricCavity
EditFiniteCond
EditGlobalCurrentSourcesOption
EditHybridRegion
EditLatticePair
EditLinkedRegion
EditMagneticBias
EditMultipactionDCBias
EditPerfectE
EditRadiation
EditSymmetry
EditWavePort
GetBoundaryAssignment
GetExcitations
GetHybridRegionsOfType
GetNumExcitations
GetNumHybridRegionsOfType
LumpedPortToCircuitPort

ModifyPMLGroup
ReassignBoundary
RenameBoundary
SetAllHybridRegionsToOneWayCoupled
SetHybridRegionsCoupling
SetSBRSources
SetScatteredFieldFormulation
SetTotalFieldFormulation

PMLGroupCreated
RecalculatePMLMaterials
ReorderMatrix
SetAllHybridRegionsToTwoWayCoupled
SetPhaseCenterPerPort
SetSBRTxRxSettings
SetSinglePhaseCenter
SwapCircuitPortDirection

PMLGroupModified
RemoveAssignmentFromBoundary
ReprioritizeBoundaries
SetDefaultBaseName
SetSBRCreepingWaveSettings
SetSBRWedgeSettings
SetTerminalReferenceImpedances
SwapLatticePair

oModule-MeshSetup

AssignApplyCurvilinearElementsOp
AssignCylindricalGapOp
AssignEdgeCutLayerOp
AssignRotationalLayerOp
AssignTrueSurfOp
EditCloneOp
EditDefeatureOp
EditLengthOp
EditSkinDepthOp
GetOperationNames
RenameOp

AssignCloneOp
AssignDefeatureOp
AssignLengthOp
AssignSkinDepthOp
DeleteOp
EditCurvatureExtractionOp
EditDensityControlOp
EditModelResolutionOp
EditSurfPriorityOp
InitialMeshSettings

AssignCurvatureExtractionOp
AssignDensityControlOp
AssignModelResolutionOp
AssignSurfPriorityForTauOp
EditApplyCurvilinearElementsOp
EditCylindricalGapOp
EditEdgeCutLayerOp
EditRotationalLayerOp
EditTrueSurfOp
ReassignOp

oModule-AnalysisSetup

ClearLinkedData
CopySweep
DeleteSweep
EditFrequencySweep
GetSetups
InsertDrivenSweep
InsertSetup
PasteSweep
RenameSweep
RevertAllToInitialTemperature
RevertSetupToInitialTemperature

CopyDrivenSetup
DeleteDrivenSweep
DoesSweepSetupExists
EditSetup
GetSweepCount
InsertFrequencySweep
PasteDrivenSetup
RenameDrivenSweep
ResetToTimeZero
RevertAllToZeroDisplacement
RevertSetupToZeroDisplacement

CopyEigenSetup
DeleteSetups
EditDrivenSweep
GetSetupCount
GetSweeps
InsertMeshLinkedSetup
PasteEigenSetup
RenameSetup
RevertAllToInitial
RevertSetupToInitial
SolveSetup

oModule-Optimetrics

CopySetup
EditSetup
ExportDOELocalSensitivityCurve
ExportDOEResponseSurface
ExportOptimetricsResult
ExportRespSurfaceMinMaxTable
ExportRespSurfaceResponsePoints
GetChildNames
GetName
GetOptimetricResultRowCount
GetSetupNames
InsertSetup
SetPropValue

DeleteSetups
EnableSetup
ExportDOEResponseCurve
ExportDXConfigFile
ExportParametricResults
ExportRespSurfacePlotToFile
ExportRespSurfaceVerificationPoints
GetChildObject
GetObjPath
GetPropNames
GetSetupNamesByType
PasteSetup
SolveAllSetup

DistributedAnalyzeSetup
ExportDOELocalSensitivity
ExportDOEResponseCurveSlices
ExportOptimetricsProfile
ExportParametricSetupTable
ExportRespSurfaceRefinePoints
GenerateVariationData
GetChildTypes
GetOptimetricResult
GetPropValue
ImportSetup
RenameSetup
SolveSetup

oModule-Solutions

DeleteImportData

DeleteSolutionVariation

EditSources

ExportEigenmodes
ExportNMFData
ExportWElement
GetAdaptiveSettings
GetAllSourcePhases
GetAvailableVariations
GetFieldType
GetNetworkDataSolution
GetNetworkPostprocSetup
GetTerminalExcitationType
GetValidISolutionList
HasMesh
IsFieldAvailableAt
ListVariations
SetSourceContexts

ExportForHSpice
ExportNetworkData
FFTONReport
GetAllSourceMagnitudes
GetAllSources
GetEditSourcesCount
GetIncludePortPostProcessing
GetNetworkDataSolutionDefinition
GetSolveRangeInfo
GetTransientSolveTimes
HasFields
ImportSolution
ListMatchingVariations
SetExcitationScaling
SetTuningOffsets

ExportForSpice
ExportTransientData
GetAdaptiveFreq
GetAllSourceModes
GetAntennaParameters
GetExcitationScaling
GetMultipactionBreakdown
GetNetworkDataSolutionV2
GetSourceContexts
GetTransmissionLineNetworkData
HasMatrixData
ImportTable
ListValuesOfVariable
SetPortSourcesUsingVoltageAndCurrent
TDROnReport

oModule-ModelSetup

AssignArray
EditArray
IsArrayDefined

CreateOpenRegion
GetArrayNames
UpdateOpenRegionPadding

DeleteArray
GetLatticeVectors

oModule-FieldsReporter

AddMarker
AddNamedExpression
CalcStack
CalculatorWrite
ClcMaterial
ClearAllNamedExpr
DeleteFieldPlot
DeleteUneditablePlot
EnterComplex
EnterEdge
EnterPoint
EnterScalarFunc
EnterVectorFunc
ExportMarkerTable
ExportToFile
GetMeshPlotNames
HidePolarPlot
ModifyFieldPlot
RenamePlotFolder
SetFieldPlotSettings
SetPlotsSolutionContext
ShowPolarPlot
UpdateAllFieldsPlots

AddMarkerToPlot
CalcOp
CalcWrite
ChangeGeomSettings
ClcMaterialValue
CopyNamedExprToStack
DeleteMarker
DoesNamedExpressionExists
EnterComplexVector
EnterLine
EnterQty
EnterSurf
EnterVol
ExportOnGrid
GetFieldFolderNames
GetTopEntryValue
HideRadiatedPlotOverlay
ReassignFieldPlot
SaveFieldsPlots
SetFieldTypeSettings
SetPlotsViewSolutionContext
ShowRadiatedPlotOverlay
UpdateQuantityFieldsPlots

AddNamedExpr
CalcRead
CalculatorRead
ClcEval
ClearAllMarkers
CreateFieldPlot
DeleteNamedExpr
DumpCalculatorStack
EnterCoord
EnterOutputVar
EnterScalar
EnterVector
ExportFieldPlot
ExportPlotImageToFile
GetFieldPlotNames
HideAntennaParameterOverlay
LoadNamedExpressions
RenameFieldPlot
SaveNamedExpressions
SetPlotFolderSettings
ShowAntennaParameterOverlay
Test
XForm

oModule-RadField

AddAntennaOverlay
CopySetup
DeleteSetup
EditBoxSetup
EditLineSetup
EditNearFieldRectangleSetup
EditRadiatedPowerCalculationMethod

AddRadFieldSourceGroup
DeleteFarFieldSetup
EditAntennaArraySetup
EditFarFieldSphereSetup
EditNearFieldBoxSetup
EditNearFieldSphereSetup
EditRectangleSetup

CopyRadFieldSetup
DeleteNearFieldSetup
EditAntennaOverlay
EditInfiniteSphereSetup
EditNearFieldLineSetup
EditRadFieldSourceGroup
EditSphereSetup

ExportFieldsToFile
ExportRadiationFieldsToFile
GetChildNames
GetInfiniteGroundPlaneCoordSystem
GetPropNames
InsertBoxSetup
InsertLineSetup
InsertNearFieldRectangleSetup
InsertSphereSetup
RenameSetup

ExportParametersToFile
ExportRadiationParametersToFile
GetChildObject
GetName
GetPropValue
InsertFarFieldSphereSetup
InsertNearFieldBoxSetup
InsertNearFieldSphereSetup
PasteRadFieldSetup
SetPropValue

ExportRadarRom
ExportRadiationSurfaceMeshAndFields
GetChildTypes
GetObjPath
GetSetupNames
InsertInfiniteSphereSetup
InsertNearFieldLineSetup
InsertRectangleSetup
PasteSetup

oModule-ReportSetup

AddAllEyeMeasurements
AddCartesianLimitLineFromEquation
AddCartesianYMarkerToStack
AddNote
ApplyReportTemplate
ClearAllTraceCharacteristics
CompareReportDataForRegressionTesting2
CopyPlotSettings
CopyTraceDefinitions
CreateReportFromFile
DeleteAllReports
DeleteTraces
DumpReportDataForRegressionTesting
EditMarker
ExportReportDataToFile
ExportUniformPointsToFile
GetAllReportNames
GetAvailableSolutions
GetChildTypes
GetDynLinkIntrinsicVariables
GetDynLinkTraces
GetObjPath
GetPropertyValue
GetReportTraceNames
GroupPlotCurvesByGroupingStrategy
MovePlotCurvesToGroup
OpenWindowForReports
PasteReportsWithLegacyNames
RenameReport
SavePlotSettingsAsDefault
UngroupPlotCurvesInGroup
UpdateTraces

AddCartesianLimitLine
AddCartesianXMarker
AddDeltaMarker
AddTraceCharacteristics
ChangeProperty
CloneReportsFromDatasetSolution
CompareTracesForRegressionTesting
CopyReportDefinitions
CopyTracesData
CreateReportFromTemplate
DeleteReports
DoesSupportTraceCharacteristics
EditCartesianXMarker
ExportEyeMaskViolation
ExportTableToFile
GetAllCategories
GetAvailableDisplayTypes
GetChildNames
GetCurvePropServerName
GetDynLinkQtyData
GetDynLinkVariableValues
GetPropNames
GetQtyExpressionsForSourceTrace
GetSolutionContexts
ImportIntoReport
MovePlotCurvesToNewGroup
PastePlotSettings
PasteTraces
RenameTrace
SetLinkOutputTraces
UpdateAllReports
UpdateTracesContextAndSweeps

AddCartesianLimitLineFromCurve
AddCartesianYMarker
AddMarker
AddTraces
ClearAllMarkers
CompareReportDataForRegressionTesting
CompareTracesForRegressionTesting2
CopyReportsData
CreateReport
CreateReportOfAllQuantities
DeleteTraceCharacteristics
DumpAllReportsData
EditCartesianYMarker
ExportImageToFile
ExportToFile
GetAllQuantities
GetAvailableReportTypes
GetChildObject
GetDisplayType
GetDynLinkQtyValueState
GetName
GetPropValue
GetReportSummaryForRegressionTesting
GetSolutionDataPerVariation
ImportReportDataIntoReport
OpenWindowForAllReports
PasteReports
PasteTracesWithLegacyNames
ResetPlotSettings
SetPropValue
UpdateReports

oModule-OutputVariable

CreateOutputVariable
EditOutputVariable
GetOutputVariables

DeleteOutputVariable
ExportOutputVariables
ImportOutputVariables

DoesOutputVariableExist
GetOutputVariableValue

oModule-UserDefinedSolutionModule

CreateUserDefinedSolution
GetUserDefinedSolutionNames

DeleteUserDefinedSolutions
GetUserDefinedSolutionProperties

EditUserDefinedSolution

