

# Protium 2500

UART Communication Specification

# UART Specification

Parameter	Value
Baud Rate	57600 bps
Data Bits	8
Parity Bit	None
Stop Bits	1
Flow Control	None

For this document, sample message output from the Protium-2500 will be written in blue:

`Sample output`

Sample commands to the protium-2500 will be written in green:

`Sample input`

Hexadecimal values will be written in red, with a “0x” prefix (unless otherwise specified):

`0x1F`

# Message Output from the Protium-2500

- All UART output **from** the Protium-2500 is displayed in human-readable format (i.e. as a string of ASCII characters).
- In order to decode the information by an external program, the string has to be parsed to extract the values.
- In order to aid the parsing of messages, special characters are used to separate values and messages.

# Message Input to the Protium-2500

- All UART input **to** the Protium-2500 is also sent as a string of ASCII characters.
- A full list of all commands can be found in Annex A.
- The Protium-2500 will expect certain commands at certain phases of operation. If an incorrect command is received, it will display the following error message:

Command not found.

# Phases of Operation

- There are 3 phases of operation, during each of which the Protium-2500 will expect different commands:
  - Startup
  - Running
  - End

# Startup

Upon powering up, the Protium-2500 will display the following message:

```
Spectronik Protium 2500
```

```
Type help<enter> for list of commands
```

```
Total Mileage:    1.57 kWh
```

```
Total Runtime: 0001:40 hrs
```

```
Ready to start.
```

In order to enter the running phase, the Protium-2500 expects the following command:

```
start
```

# Startup

The Protium-2500 will then go through a series of checks before entering the running phase. Do not send any commands during this period. A portion of the messages during this part of the startup phase is shown below:

```
P2500 2203-05 initialising
```

```
Firmware version : V2.5_03032022_0642_2203-05-A
```

```
No. of cells : 80
```

```
Entering to Starting phase...
```

```
Anode Supply Pressure OK
```

```
Temperature Check OK
```

# Running

As soon as the Protium-2500 enters its running phase, it will output messages in the following format, at a frequency of 1Hz:

```
|FC_V : 71.17 V | FCT1: 30.90 C | H2P1 : 0.61 B | DCDCV: XX.X V |
FC_A : 10.21 A | FCT2: 28.46 C | H2P2 : 0.59 B | DCDCA: XX.X A |
FC_W : 726.6 W | FAN : 89 % | Tank-P: 117.0 B | DCDCW: XXXX.X W |
Energy: 298 Wh| BLW : 21 % | Tank-T: 25.08 C | BattV: 23.49 V |
| | | | !
```

```
Fan PWM auto
```

```
Blower auto
```



# Running

The pipe character `|` (`0x7C`) is used to denote the start of these running phase messages, and to separate values. The exclamation point `!` (`0x21`) is used to denote the end of the message.

```
|FC_V : 71.17 V | FCT1: 30.90 C | H2P1 : 0.61 B | DCDCV: XX.X V |  
FC_A : 10.21 A | FCT2: 28.46 C | H2P2 : 0.59 B | DCDCA: XX.X A |  
FC_W : 726.6 W | FAN : 89 % | Tank-P: 117.0 B | DCDCW: XXXX.X W |  
Energy: 298 Wh | BLW : 21 % | Tank-T: 25.08 C | BattV: 23.49 V |  
| | | | !
```

Fan PWM auto

Blower auto

# Running

A string parser is required to extract information from the running phase messages. A sample parsing algorithm would be as follows:

1. Extract the entire message as a string from the first pipe (|) to the exclamation point (!).
2. Separate the string into sub-strings by using the pipes (|) as separators. So for example, you would have sub-strings such as “FC\_V : 71.17 V” and “Tank-P: 117.0 B”.
3. From the sub-strings of interest, extract the value of the reading by using the colon (:) to separate the reading name from the value.

# End Phase

To exit the running phase, the following command must be given:

```
end
```

This prompts the Protium-2500 to shut down and enter the ending phase, with the following messages:

```
Shutdown initiated
```

```
This Mileage:      14.0 Wh  
This Runtime: 0000:07 hrs
```

```
Total Mileage:    1.57 kWh  
Total Runtime: 0001:40 hrs
```

```
System Off
```

# End Phase

If an error occurs (e.g. low hydrogen supply), the system will automatically enter the ending phase with the following messages:

```
Abnormal shutdown initiated
```

```
This Mileage:      14.0 Wh
```

```
This Runtime: 0000:07 hrs
```

```
Total Mileage:    1.57 kWh
```

```
Total Runtime: 0001:40 hrs
```

```
System Off
```

# Annex A: List of Commands

Command	Function	Phase when message is valid	Bytes to be transmitted (hexadecimal)
start	To enter the running phase	Starting	73 74 61 72 74
end	To exit the running phase	Running	65 6E 64
f	Set the fans to auto	Running	66
b	Set the blowers to auto	Running	62
p	Single manual purge	Running	70
ver	Display the firmware version	Starting	76 65 72
9	Decrease fan speed by 1%	Running	39
0	Increase fan speed by 1%	Running	30
-	Decrease fan speed by 5%	Running	2D
=	Increase fan speed by 5%	Running	3D
[	Decrease blower intensity by 3%	Running	5B
]	Increase blower intensity by 3%	Running	5D