

## Uboot 常用的命令

### 1、环境变量相关的命令

- a) 内核启动位置
- b) 根文件挂载的位置
- c) 虚拟机与开发板同一网络位置的设置

### 2、代码数据搬运相关的(产品发布)

- a) SD --->外扩内存(DDR3) --->EMMC

---

### 1、查找显示 Uboot 中所有的命令

命令提示符: ? 或者 help

用法 1: ? 或者 help

显示 uboot 所有的命令

TINY4412 # ?

```
?          - alias for 'help'
base       - print or set address offset
bdinfo    - print Board Info structure
boot       - boot default, i.e., run 'bootcmd'
bootd      - boot default, i.e., run 'bootcmd'
bootelf    - Boot from an ELF image in memory
bootm      - boot application image from memory
bootp      - boot image via network using BOOTP/TFTP protocol
bootvx     - Boot vxWorks from an ELF image
chpart     - change active partition
cmp        - memory compare
coninfo    - print console devices and information
cp         - memory copy
crc32      - checksum calculation
dcache     - enable or disable data cache
dnw        - dnw          - initialize USB device and ready to receive for Windows server
(specific)

echo       - echo args to console
editenv    - edit environment variable
emmc       - Open/Close eMMC boot Partition
env        - environment handling commands
exit       - exit script
ext2format - ext2format - disk format by ext2

ext2load   - load binary file from a Ext2 filesystem
ext2ls     - list files in a directory (default /)
ext3format - ext3format - disk format by ext3
```

false - do nothing, unsuccessfully  
fastboot- fastboot- use USB Fastboot protocol

fatformat- fatformat - disk format by FAT32

fatinfo - fatinfo - print information about filesystem  
fatload - fatload - load binary file from a dos filesystem

fatls - list files in a directory (default /)  
fdisk - fdisk for sd/mmc.

go - start application at address 'addr'  
help - print command description/usage  
icache - enable or disable instruction cache  
imininfo - print header information for application image  
imxtract- extract a part of a multi-image  
itest - return true/false on integer compare  
loadb - load binary file over serial line (kermit mode)  
loads - load S-Record file over serial line  
loady - load binary file over serial line (ymodem mode)  
loop - infinite loop on address range  
md - memory display  
mm - memory modify (auto-incrementing address)  
mmc - MMC sub system  
mmcinfo - mmcinfo <dev num>-- display MMC info  
movi - movi - sd/mmc r/w sub system for SMDK board  
mtdparts- define flash/nand partitions  
mtest - simple RAM read/write test  
mw - memory write (fill)  
nfs - boot image via network using NFS protocol  
nm - memory modify (constant address)  
ping - send ICMP ECHO\_REQUEST to network host  
printenv- print environment variables  
reginfo - print register information  
reset - Perform RESET of the CPU  
run - run commands in an environment variable  
saveenv - save environment variables to persistent storage  
setenv - set environment variables  
showvar - print local hushshell variables  
sleep - delay execution for some time  
source - run script from memory  
test - minimal test like /bin/sh  
tftpboot- boot image via network using TFTP protocol

```
true      - do nothing, successfully
usb       - USB sub-system
version   - print monitor version
TINY4412 #
```

用法 2: help 命令  
查看某一命令的具体的用法

```
TINY4412 # help printenv
printenv - print environment variables

Usage:
printenv
    - print values of all environment variables
printenv name ...
    - print value of environment variable 'name'
TINY4412 #
```

## 2、查看环境变量

命令提示符: printenv

```
TINY4412 # printenv
baudrate=115200
bootargs=noinitrd root=/dev/nfs nfsroot=192.168.10.106:/root/work/root_nfs
ip=192.168.10.123:192.168.10.106:192.168.10.1:255.255.255.0::eth0:off
init=/linuxrc console=ttySAC0 lcd=S702
bootcmd=movi read kernel 0 40008000;movi read rootfs 0 41000000 400000;bootm
40008000 41000000
bootdelay=3
ethaddr=00:40:5c:26:0a:5b
gatewayip=192.168.0.1
ipaddr=192.168.0.20
netmask=255.255.255.0
serverip=192.168.0.10

Environment size: 438/16380 bytes
TINY4412 #
```

Administrator 2017-10-18 09:48



批注[A1]: 常用的

## 2、设置/删除环境变量

命令提示符: setenv

```
TINY4412 # help setenv
setenv - set environment variables

Usage:
setenv name value ...
```

Administrator 2017-10-18 09:48



批注[A2]: 设置环境变量, 临时设置, 重启后变量不存在, 必须修改后保存

```
- set environment variable 'name' to 'value ...'  
setenv name  
- delete environment variable 'name'  
TINY4412 #
```

Administrator 2017-10-18 09:49



批注[A3]: 删除环境变量

#### A) 设置环境变量

```
TINY4412 # setenv aaa 5  
TINY4412 # printenv  
aaa=5  
baudrate=115200  
bootargs=noinitrd root=/dev/nfs nfsroot=192.168.10.106:/root/work/root_nfs  
ip=192.168.10.123:192.168.10.106:192.168.10.1:255.255.255.0::eth0:off  
init=/linuxrc console=ttySAC0 lcd=S702  
bootcmd=movi read kernel 0 40008000;movi read rootfs 0 41000000 400000;bootm  
40008000 41000000  
bootdelay=3  
ethaddr=00:40:5c:26:0a:5b  
gatewayip=192.168.0.1  
ipaddr=192.168.0.20  
netmask=255.255.255.0  
serverip=192.168.0.10  
  
Environment size: 446/16380 bytes  
TINY4412 #
```

#### B) 删除环境变量

```
TINY4412 # setenv aaa  
TINY4412 # printenv  
baudrate=115200  
bootargs=noinitrd root=/dev/nfs nfsroot=192.168.10.106:/root/work/root_nfs  
ip=192.168.10.123:192.168.10.106:192.168.10.1:255.255.255.0::eth0:off  
init=/linuxrc console=ttySAC0 lcd=S702  
bootcmd=movi read kernel 0 40008000;movi read rootfs 0 41000000 400000;bootm  
40008000 41000000  
bootdelay=3  
ethaddr=00:40:5c:26:0a:5b  
gatewayip=192.168.0.1  
ipaddr=192.168.0.20  
netmask=255.255.255.0  
serverip=192.168.0.10  
  
Environment size: 438/16380 bytes  
TINY4412 #
```

### 3、保存环境变量

命令提示符: help saveenv

```
TINY4412 # saveenv
Saving Environment to SMDK bootable device...
done
TINY4412 #
```

### 4、查看设备带点 fat 分区

```
TINY4412 # help fatinfo
fatinfo - fatinfo - print information about filesystem
```

```
Usage:
fatinfo {<interface>}<dev[:part]>
        - print information about filesystem from 'dev' on 'interface'
```

```
TINY4412 #
```

查看 sd 卡的信息

```
TINY4412 # fatinfo mmc 0
----Partition 1----
Partition1: Start Address(0x4b800), Size(0xe78800)
-----
----Partition 2----
Partition1: Start Address(0x4b800), Size(0xe78800)
-----
----Partition 3----
Partition1: Start Address(0x4b800), Size(0xe78800)
-----
----Partition 4----
Partition1: Start Address(0x4b800), Size(0xe78800)
-----
Interface:  SD/MMC
  Device 0: Vendor: Man 123456 Snr 4b924233 Rev: 0.0 Prod: SD
            Type: Removable Hard Disk
            Capacity: 14.7 MB = 0.0 GB (30240 x 512)
Partition 1: Filesystem: FAT32 "NO NAME"
TINY4412 #
```

### 5、代码数据搬运命令

命令提示符: help mmc

```
TINY4412 # help mmc
mmc - MMC sub system
```

```
Usage:
```

Administrator 2017-10-18 10:10

批注[A4]: 可以是 usb 或者 mmc, mmc 表示 sd 卡、MMC 卡, eMMC

Administrator 2017-10-18 10:11

批注[A5]: 开发板上的存储设备, 用数字表示, 0 表示。

Tiny4412 开发板的启动方式: sd 卡启动、EMMC 启动

当从 sd 卡启动时, 0 表示 sd 卡, 1 表示 EMMC 反之, 0 表示 EMMC 卡, 1 表示 sd 卡。

```
mmc read <device num> addr blk# cnt  
mmc write <device num> addr blk# cnt  
mmc rescan <device num>  
mmc erase <boot | user> <device num> <start block> <block count>  
mmc list - lists available devices  
TINY4412 #
```

把 sd 卡中的 uboot 整体搬运到 EMMC 中，取出 SD 卡，重启，设置为 EMMC 启动，看开机的效果是否与 SD 卡启动一样。

Exynos4412 的外扩 DDR3 的起始地址为：0x40000000

1、把 sd 卡中的 uboot 整体搬运到 EMMC

```
mmc read 0 0x40000000 1 800
```

2、打开 EMMC 设备

```
emmc open 1
```

3、把内存中的 uboot 写入到 EMMC 中

```
mmc write 1 0x40000000 0 800
```

4、关闭 EMMC 设备

```
emmc close 1
```

Administrator 2017-10-18 10:55



批注[A6]: 数据流向 设备----->内存

mmc read <device num> addr blk# cnt  
mmc 读 设备号 内存地址 从哪开始 多少块  
在 sd 卡和 EMMC 中 1 块的大小为：512B

SD 卡：默认从第 1 块存放

EMMC：默认从第 0 块开始存放

Administrator 2017-10-18 10:58



批注[A7]: 数据流向 内存----->设备

Administrator 2017-10-18 14:18



批注[A8]: SD 卡：默认从第 1 块存放

Administrator 2017-10-18 14:18



批注[A9]: EMMC：默认从第 0 块开始存放