

Interface name	failure notification
Method	PUT

URI /v1/MSFcontroller/failure status

message	code	body	type	required	Allow null	Allow empty array	overview	remarks
request	-	physical unit	object	x	○		Failure notification information(per physical unit)	-
		nodes	object[ ]	x	○	○	Node information list	Node failure notification
		cluster id	string	○	x		Cluster ID	-
		fabric type	string	○	x		Node type(Leaf or Spine)	-
		node id	string	○	x		Node ID	-
		failure status	string	○	x		Failure status	"up" "down"
		ifs	object[ ]	x	○	○	IF information list	IF failure notification
		cluster id	string	○	x		Cluster ID	-
		fabric type	string	○	x		Node type(Leaf or Spine)	-
		node id	string	○	x		Node ID	-
		if type	string	○	x		IF type(see remark)	"physical-if": physical-IF "lag-if": LAG IF "breakout-if": breakoutIF
		if id	string	○	x		IF ID	-
		failure status	string	○	x		Failure status	"up" "down"
		cluster unit	object	x	○		Failure notification information(per cluster unit)	-
		clusters	object[ ]	○	x	○	Cluster information	-
		cluster id	string	○	x		Cluster ID	-
		type	string	○	x		type(see remark)	"edge_point": edge-point "cluster_link-if": inter-cluster IF "internal": internal cluster
		id	string	x	○		ID(see remark)	Specified "type"s ID (i.e. if type is edge-point, edge-point id is obtained.)
		failure status	string	○	x		Failure status	"up" "down" "warn"
		slice unit	object	x	○			Not support
		slices	object[ ]	○	x	○		
		slice type	string	○	x			
		slice id	string	○	x			
		cp ids	string[ ]	○	x	○		
		failure status	string	○	x			
		reachable statuses	object[ ]	○	x	○		
		cp id	string	○	x			
		opposite type	string	○	x			
		opposite id	string	○	x			
		reachable status	string	○	x			
response	200	-	-	-	-	-	-	-

Refer to the "Error response format" sheet for error response

Body uses JSON format.