

The diagram illustrates the test point connections for the battery module. It shows two sets of connections. The first set, labeled '+3.3V', '+5V', and '+9V', connects to TP1 (TestPoint_3.3V), TP2 (TestPoint_5V), TP3 (TestPoint_VCali), and TP4 (TestPoint_GND). The second set, labeled 'CHRG_BAT_POS' and 'GND', connects to TP5 (TestPoint_Battery_POS), TP6 (TestPoint_Battery_NEG), and a common GND point.

