


In non real-time simulations, the simulation speed (i.e. the perceived speed) is mainly dependent on two factors: the simulation time step and the number of simulation passes for one rendering pass (see the [simulation dialog](#) for more details). In the case of a real-time simulation, the simulation speed mainly depends on the real-time multiplication coefficient, but also to a certain degree of the simulation time step (a too small simulation time step might not be compatible with the real-time character of a simulation because of the limited calculation power of the computer). During simulation, the simulation speed can be adjusted with following toolbar buttons:

adjusted with following toolbar buttons:




[Simulation speed adjustment toolbar buttons]

The simulation speed is adjusted in a way so that the initial simulation time step is never increased (because this might have as consequence the breaking of a mechanism for example). Following two figures illustrate the simulation speed adjustment mechanisms:



[Simulation speed adjustment mechanism for non real-time simulations]




[Simulation speed adjustment mechanism for real-time simulations]

By default, each simulation cycle is composed by following **sequential** operations:

- Executing the **main script**
- Rendering the scene

stepping mode

By default, CoppeliaSim executes a simulation by running one simulation step after another, automatically. There are however many situations where it is important to be able to manually trigger each simulation step, e.g. in order to inspect each simulation step individually, or in order to synchronize CoppeliaSim with an external application. There is such a mechanism, which is the stepping mode (or synchronous mode):



[stepping simulation mode]

From within CoppeliaSim, a stepping simulation can easily be implemented via the `sysCall_beforeMainScript` callback function. From an external application, there is usually a dedicated function to enable the stepping mode, and then to trigger each individual step. Following illustrates the stepping mode from a Python ZeroMQ remote API client:

```

import time
from coppeliasim_zmqremoteapi_client import RemoteAPIClient

client = RemoteAPIClient()
sim = client.getObject('sim')

sim.setStepping(True)

sim.startSimulation()
while (t := sim.getSimulationTime()) < 3:
    s = f'Simulation time: {t:.2f} [s]'
    print(s)
    sim.step()
sim.stopSimulation()
  
```