



BOOTMODE0	1	
BOOTMODE1	1	BOOTMODE[2:0]: PLL Config, set to '011' for 25MHz input frequency.
BOOTMODE2	0	
BOOTMODE3	0	
BOOTMODE4	0	MCU_BOOTMODE[6:3]: Primary Boot Mode, set to '1000' for primary boot is MMCSD Boot (SD Card).
BOOTMODE5	0	
BOOTMODE6	1	
BOOTMODE7	0	
BOOTMODE8	0	MCU_BOOTMODE[9:7]: Primary Boot Mode Config, set to '100'. B9=1: MMC Port 1 (4 bit width). B8=x: Reserved. B7=0: Filesystem mode.
BOOTMODE9	1	
BOOTMODE10	0	
BOOTMODE11	0	MCU_BOOTMODE[12:10]: Backup Boot Mode, set to '100' for Backup boot is Ethernet.
BOOTMODE12	1	
BOOTMODE13	0	MCU_BOOTMODE[13]: Backup Boot Mode Config, set to '0' :RGMII with internal TX delay.
BOOTMODE14	0	
BOOTMODE15	0	MCU_BOOTMODE[15:14]: Reserved pins.