

ALARM ADDRESS	A5.4	ALARM NO.	1128
ALARM TEXT	AXES NOT AT ATC POS.		
Related Signal			
CAUSE	Z axis not at ATC Position while performs M25 / M26 / M27 Code °		
ACTION	Operating G91 G30 Z0 in MDI mode in advance °		