


ALARM ADDRESS	A11.6	ALARM NO.	1178
ALARM TEXT	C-ST.-> SRV FIN. & AUTO CONTINUE.		
Related Signal			
CAUSE	When ATC cycle was interrupted. This is a prompt for operator °		
ACTION	<div>  </div> <p>Press cycle start button to finish ATC cycle °</p>		