

# Alarm Help - MV SERIES -



ALARM ADDRESS	A4.3	ALARM NO.	1119
ALARM TEXT	TOOL CLAMP/UNCLAMP LS. BOTH ON.		
Related Signal	Input: X2.0 ,X2.1 (MV154/154APC/MV204) , X7.4 & X7.5 (184C) °		
CAUSE	SPDL Tool Clamp & Unclamp Sensor both ON °		
ACTION	<p>Check sensor is damaged ?</p> 		