

ALARM ADDRESS	A15.1	ALARM NO.	2017
OP. MESSAGE	TOOL TABLE INITIAL FUNCTION ENABLE. ATFER MAG. ZRN. THE TOOL TABLE WILL INI. SPDL-TL(D0)=0, CURRENT MAG. CTR.(D22)=1 POCKET NO.1 -> TOOL NO.1 POCKET NO.2 -> TOOL NO.2		
Related Signal			
CAUSE	When Tool table initial function has been turn on , this message occurred °		
ACTION	This is a prompt for operator ° After finish it will auto disappear °		