


ALARM ADDRESS	A13.7	ALARM NO.	2007
OP. MESSAGE	!!! ATTENTION !!! ATC INTO SRV-MODE, NO INTERLOCK ACTIVE DAMAGE OF MACHINE POSSIBLE. CLEAR THIS MODE BY "RESET" KEY !!		
Related Signal			
CAUSE	ATC service mode has been turn on.		
ACTION	Operator must pay attention to operate machine. <div style="display: flex; align-items: center; justify-content: center;">  </div> Cancel this function by press reset button on FANUC panel •		