


ALARM ADDRESS	A11.4	ALARM NO.	1176
ALARM TEXT	PRESS SRV KEY -> ARM CW TO BOTTOM.		
Related Signal			
CAUSE	When ATC cycle was interrupted. This is a prompt for operator °		
ACTION	<div> <div>Press service button</div> <div>  </div> <div>the ARM will perform CW to bottom position °</div> </div>		