

超声波测距仪传感器

这个例子展示了如何使用 [超声波测距仪传感器](#)。它的测量最大范围为400cm，测量最小范围是3cm，分辨率为1cm。

如果没有障碍物，则会默认返回500cm。

在这个notebook里，我们只展示如何控制grove ultrasonic ranger连接到Pmod接口上，因此需要一个pmod grove和转换器。当然读者也可以自己把控制移植到Arduino接口的版本上去。

```
from pyng.overlays.base import BaseOverlay

base = BaseOverlay("base.bit")
```

1. 使用 Microblaze 去控制超声波传感器

下面的程序假设超声波传感器是连接在Pmod-Grove转接器的G1接口上的，以及该转接器连接在PMODA接口上。

时钟控制器的寄存器分布如下：

Register name	Register functionality	Register value
TCSR0	Timer 0 Control and Status Register	0x00
TLR0	Timer 0 Load Register	0x04
TCR0	Timer 0 Counter Register	0x08
TCSR1	Timer 1 Control and Status Register	0x10
TLR1	Timer 1 Load Register	0x14
TCR1	Timer 1 Counter Register	0x18

```
%%microblaze base.PMODA

#include "xparameters.h"
#include "xtmrctr.h"
#include "gpio.h"
#include "timer.h"
#include <pmod_grove.h>

#define TCSR0 0x00
#define TLR0 0x04
#define TCR0 0x08
#define TCSR1 0x10
```

```

#define TLR1 0x14
#define TCR1 0x18
#define MAX_COUNT 0xFFFFFFFF

void create_10us_pulse(gpio usranger){
    gpio_set_direction(usranger, GPIO_OUT);
    gpio_write(usranger, 0);
    delay_us(2);
    gpio_write(usranger, 1);
    delay_us(10);
    gpio_write(usranger, 0);
}

void configure_as_input(gpio usranger){
    gpio_set_direction(usranger, GPIO_IN);
}

unsigned int capture_duration(gpio usranger){
    unsigned int count1, count2;
    count1=0;
    count2=0;
    XTmrCtr_WriteReg(XPAR_TMRCTR_0_BASEADDR, 0, TLR0, 0x0);
    XTmrCtr_WriteReg(XPAR_TMRCTR_0_BASEADDR, 0, TCSR0, 0x190);
    while(!gpio_read(usranger));
    count1=XTmrCtr_ReadReg(XPAR_TMRCTR_0_BASEADDR, 0, TCR0);
    while(gpio_read(usranger));
    count2=XTmrCtr_ReadReg(XPAR_TMRCTR_0_BASEADDR, 0, TCR0);
    if(count2 > count1) {
        return (count2 - count1);
    } else {
        return((MAX_COUNT - count1) + count2);
    }
}

unsigned int read_raw(){
    gpio usranger;
    usranger = gpio_open(PMOD_G1_A);
    create_10us_pulse(usranger);
    configure_as_input(usranger);
    return capture_duration(usranger);
}

```

2. 测量距离

记住放一些障碍物在传感器面前，否则它将返回默认的500cm。

```
from pynq import clocks

def read_distance_cm():
    raw_value = read_raw()
    clk_period_ns = int(1000 / clocks.fclk0_mhz)
    num_microseconds = raw_value * clk_period_ns * 0.001
    if num_microseconds * 0.001 > 30:
        return 500
    else:
        return num_microseconds/58
```

```
read_distance_cm()
```

```
11.873448275862069
```