



The counter size is set by changing the Matlab workspace variable `max_reset_Nsample` that is found in the `InitFcn` callback.

Example:  
`max_reset_Nsamples = 1024 % should be a power of 2`  
`max_reset_Nbits = ceil(log2(max_reset_Nsamples));`