

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
103A	HEADLIGHT POSITION CONTROL
103W	RIGHT-HAND LIN COMMUNICATION SIGNAL (MULTIPLEXING)
103X	LEFT-HAND LIN COMMUNICATION SIGNAL (MULTIPLEXING)
107F	MULTIMEDIA MICROPHONE SIGNAL
107G	HANDS FREE TELEPHONE MICROPHONE +
107J	TELEPHONE MICROPHONE SCREENING
107W	DIAGNOSTIC SOCKET CANH MULTIMEDIA SIGNAL
107X	DIAGNOSTIC SOCKET CANL MULTIMEDIA SIGNAL
134A	TIMED BATTERY CUT OFF +RELAY CONTROL
134B	TIMED BATTERY NOT CUT OFF +RELAY CONTROL
137G	CAN L SIGNAL
137H	CAN H SIGNAL
13AM	RIGHT-HAND COURTESY MIRROR LIGHTING SWITCH
13AN	LEFT-HAND COURTESY MIRROR LIGHTING SWITCH
13AY	REAR COURTESY LIGHT CONTROL
13C	INTERIOR LIGHT - CONTROL
141B	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 1 SIGNAL
141C	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 2 SIGNAL
141D	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 3 SIGNAL
141G	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 4 SIGNAL
141H	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 5 SIGNAL
141K	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 1 SIGNAL
141L	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 2 SIGNAL
141M	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 3 SIGNAL
141N	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 4 SIGNAL
141P	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 5 SIGNAL
141Q	STEERING COLUMN CONTROL INFORMATION DISPLAY LINE 6 SIGNAL
141R	STEERING COLUMN CONTROL INFORMATION DISPLAY COLUMN 6 SIGNAL
14K	WINDSCREEN WIPER TIMER LOW SPEED + CONTROL
14L	WINDSCREEN WIPER TIMER HIGH SPEED + CONTROL
14M	WINDSCREEN WIPER PARK POSITION CONTROL > COMPUTER
14S	RAIN SENSOR SERIAL LINE SIGNAL
151C	EXTERIOR LEFT HAND REAR SENSOR SIGNAL
151E	PARKING AID WARNING LIGHT CONTROL
151H	EXTERIOR RIGHT HAND REAR SENSOR SIGNAL
151M	INTERIOR LEFT HAND REAR SENSOR SIGNAL
151Q	INTERIOR RIGHT HAND REAR SENSOR SIGNAL
151R	BUZZER +
151S	BUZZER CONTROL
151T	CARAVAN DETECTION SIGNAL
151U	EXTERIOR + SENSOR
151V	EXTERIOR - SENSOR
151W	PARKING AID DEACTIVATION
153A	POWER ASSISTED STEERING CAN H SIGNAL
153B	POWER ASSISTED STEERING CAN L SIGNAL
15A	HEATED REAR SCREEN WARNING LIGHT CONTROL
15B	HEATED REAR SCREEN + CONTROL
15LP	PROTECTED HEATED REAR SCREEN + CONTROL
15M	HEATED REAR SCREEN RELAY - CONTROL
15N	+ DE-ICING / AUTOMATIC
15P	- DE-ICING / SELF
15RP	PROTECTED HEATED REAR VIEW MIRROR + CONTROL
16A	WINDSCREEN WASHER PUMP + CONTROL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
173A	LOW SPEED FRONT FAULT TOLERANT CANH SIGNAL (LSFT)
173B	LOW SPEED FRONT FAULT TOLERANT CANL SIGNAL (LSFT)
173E	LOW SPEED DASHBOARD FAULT TOLERANT CANH SIGNAL (LSFT)
173G	LOW SPEED DASHBOARD FAULT TOLERANT CANL SIGNAL (LSFT)
173L	LOW SPEED FAULT TOLERANT CANH SIGNAL (LSFT)
173M	LOW SPEED REAR FAULT TOLERANT CANL SIGNAL (LSFT)
18A	BOOT LIGHT - CONTROL
19F	+ DIMMER FEED
1A	STARTER SOLENOID + CONTROL > RELAY
20AR	DEADLOCKING MOTOR CONTROL
20AW	ONE-TOUCH DOOR LOCKING/UNLOCKING CONTROL
20BD	OPEN FRONT/REAR PASSENGER DOORS MOTOR CONTROL
20BR	FUEL FILLER FLAP OPENING CONTROL
20D	ELECTRIC DOOR LOCKS CLOSE + CONTROL
20DA	LUGGAGE COMPARTMENT OPENING INTERNAL CONTROL
20G	TAILGATE MOTOR OPEN CONTROL
20M	DOOR LOCKING LED
20S	TAILGATE MOTOR OPENING AUTHORISED FEED
20U	LEFT HAND REAR DOOR DEADLOCKING - SIGNAL
20V	RIGHT HAND REAR DOOR DEADLOCKING - SIGNAL
21Z	ONE-TOUCH ELECTRIC WINDOW LIN (LOCAL INTERCONNECT NETWORK) SIGNAL
23T	REAR LEFT ELECTRIC WINDOW UPWARDS/DOWNWARDS CONTROL / UCH CONTROL UNIT
23U	REAR LEFT ELECTRIC WINDOW RAISE/LOWER CONTROL / UCH UNIT
23V	REAR RIGHT ELECTRIC WINDOW RAISE/LOWER CONTROL / UCH CONTROL UNIT
23W	UCH CONTROL UNIT REAR RIGHT ELECTRIC WINDOW RAISE/LOWER CONTROL
24A	REAR SCREEN WASHER PUMP + CONTROL
26AM	KEYLESS VEHICLE BOOT LID EXTERNAL AERIAL A SIGNAL
26AN	KEYLESS VEHICLE BOOT LID EXTERNAL AERIAL SIGNAL2
26AP	KEYLESS VEHICLE LOCKING SIGNAL / DRIVER SIDE DOORS SWITCH
26AT	KEYLESS VEHICLE INTERIOR AERIAL 1 SIGNAL 1
26AU	KEYLESS VEHICLE FRONT INTERIOR AERIAL SIGNAL 2
26AV	KEYLESS VEHICLE INTERIOR AERIAL 2 SIGNAL 1
26AW	KEYLESS VEHICLE INTERIOR AERIAL 2 SIGNAL 2
26AX	KEYLESS VEHICLE INTERIOR AERIAL 3 SIGNAL 1
26AY	KEYLESS VEHICLE CENTRAL INTERIOR AERIAL SIGNAL 2
26AZ	KEYLESS VEHICLE STEERING COLUMN LOCK CAN H SIGNAL
26B	CARD PRESENT + SIGNAL
26BA	KEYLESS VEHICLE STEERING COLUMN LOCK CAN L SIGNAL
26BC	CARD LOCATION ELECTROLUMINESCENT DIODE CONTROL
26BD	UCH SYNCHRONISATION / CARD READER SIGNAL
26BG	UCH DATA / CARD READER SIGNAL
26BH	+ CARD READER
26BK	- CARD READER
26BV	UPC/UCH LINE PROTECTION SIGNAL
26CL	KEYLESS VEHICLE LEFT-HAND FRONT DOOR EXTERNAL AERIAL A SIGNAL
26CM	KEYLESS VEHICLE LEFT-HAND FRONT DOOR EXTERNAL AERIAL B SIGNAL
26CP	KEYLESS VEHICLE RIGHT-HAND FRONT DOOR EXTERNAL AERIAL A SIGNAL
26CQ	KEYLESS VEHICLE RIGHT-HAND FRONT DOOR EXTERNAL AERIAL B SIGNAL
26I	+ STEERING COLUMN LOCK
26J	CONTROL - SAFETY HALL SENSOR
26M	ENGINE RUNNING WARNING LIGHT CONTROL
26N	ENGINE START/STOP + SIGNAL
26P	DOOR HANDLE INFRARED SENSOR +

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
26Q	PASSENGER SIDE DOOR HANDLE INFRARED SENSOR SIGNAL
26R	RIGHT HAND REAR HANDLE INFRARED SENSOR SIGNAL
26S	DRIVER'S SIDE REAR HANDLE INFRARED SENSOR SIGNAL
26T	DRIVER'S HANDLE INFRARED SENSOR SIGNAL
26X	CLUTCH - SIGNAL
26Z	AUTOMATIC TRANSMISSION NEUTRAL + SIGNAL
27A	HANDBRAKE WARNING LIGHT - CONTROL
28A	OIL PRESSURE WARNING LIGHT - CONTROL
2N	ALTERNATOR SYNCHRONOUS BIT SIGNAL (CHARGE SIGNAL MANAGED BY UPC)
30A	BRAKE FLUID LEVEL WARNING LIGHT - CONTROL
32A	OIL LEVEL SENSOR SIGNAL 2
32B	OIL LEVEL SENSOR SIGNAL 1
32C	ENGINE PROTECTION UNIT / OIL LEVEL SENSOR SIGNAL 2
32D	UPC / OIL LEVEL SENSOR SIGNAL 1
34A	LEFT HAND REAR LOUDSPEAKER + SIGNAL
34AN	AM/FM AERIAL SIGNAL
34AO	RADIO SATELLITE L3 (LINE 3) SIGNAL
34AP	RADIO SATELLITE SIGNAL L0
34AQ	RADIO SATELLITE SIGNAL L1
34AR	RADIO SATELLITE SIGNAL L2
34AS	RADIO SATELLITE IN0 SIGNAL
34AT	RADIO SATELLITE IN1 SIGNAL
34AU	RADIO SATELLITE IN2 SIGNAL
34B	LEFT HAND REAR LOUDSPEAKER - SIGNAL
34C	RIGHT HAND REAR LOUDSPEAKER - SIGNAL
34D	RIGHT HAND REAR LOUDSPEAKER + SIGNAL
34E	RIGHT HAND FRONT LOUDSPEAKER + SIGNAL
34EC	RIGHT HAND LINE IN + SIGNAL
34EE	LEFT HAND LINE IN + SIGNAL
34EP	AM/FM1 RADIO SIGNAL
34EQ	FM2 RADIO SIGNAL
34ER	SCREEN PRINTED AERIAL SIGNAL (INTEGRATED IN REAR SCREEN)
34ET	- LINE IN
34F	RIGHT HAND FRONT LOUDSPEAKER - SIGNAL
34G	LEFT HAND FRONT LOUDSPEAKER + SIGNAL
34GB	MULTIMEDIA 2 CAN H SIGNAL
34GC	MULTIMEDIA 2 CAN L SIGNAL
34H	LEFT HAND FRONT LOUDSPEAKER - SIGNAL
34HU	MULTIMEDIA WAKE-UP SIGNAL
34HY	MULTIMEDIA STOP/START CONTROL
34KP	SCREEN PRINTED RADIO AERIAL SIGNAL (INTEGRATED IN REAR SCREEN)
34PE	C_BOX RIGHT HAND AUDIO + SIGNAL
34PG	C_BOX AUDIO - SIGNAL
34PH	C_BOX LEFT-HAND AUDIO + SIGNAL
34PJ	C_BOX CONNECTION DETECTION SIGNAL
34TE	USB + SUPPLY
34TG	USB - SUPPLY
34TH	USB + SIGNAL
34TJ	USB - SIGNAL
38AH	FAN MOTOR SPEED 1 + CONTROL
38AJ	FAN MOTOR SPEED 2 + CONTROL
38AK	FAN MOTOR SPEED 3 + CONTROL
38AL	FAN MOTOR SPEED 4 + CONTROL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
38AP	AIR CONDITIONING EVAPORATOR SENSOR + SIGNAL
38DA	HEATING FAN ASSEMBLY + CONTROL > AIR CONDITIONING PANEL
38DB	HEATER BLOWER + CONTROL > AIR CONDITIONING PANEL
38ES	AIR CONDITIONING WARNING LIGHT - CONTROL
38EW	0 VOLT EVAPORATOR TEMPERATURE SENSOR CLIMATE CONTROL SIGNAL
38GZ	INTERIOR TEMPERATURE SENSOR SIGNAL
38HC	AIR CONDITIONING FAN SPEED RETURN SIGNAL
38JA	RECIRCULATION MOTOR CONTROL 1
38JB	RECIRCULATION MOTOR CONTROL 2
38JG	+ TOXICITY SENSOR
38JH	NITROGEN OXIDE SENSOR SIGNAL
38JK	CARBON MONOXIDE SENSOR SIGNAL
38JL	0V AIR TOXICITY SENSOR
38JN	SUN TEMPERATURE HUMIDITY SENSOR ZERO VOLTS
38KY	AIR DISTRIBUTION MOTOR B2 COIL CONTROL
38KZ	AIR DISTRIBUTION MOTOR A2 COIL CONTROL
38LA	AIR DISTRIBUTION MOTOR B1 COIL CONTROL
38LB	AIR DISTRIBUTION MOTOR A1 COIL CONTROL
38LP	AIR CONDITIONING STOP/START CONTROL
38LQ	FAN ASSEMBLY SPEED 0 SIGNAL
38LR	PASSENGER COMPARTMENT FAN SET SPEED 2 CONTROL
38MU	ENGINE RELAY 2 RUNNING + CONTROL
38NF	TOXICITY SENSOR + SUPPLY
38R	AIR CONDITIONING CLUTCH + CONTROL
38SA	RECIRCULATION MOTOR + SUPPLY
38SB	RECYCLING MOTOR B2 COIL CONTROL
38SC	RECYCLING MOTOR A2 COIL CONTROL
38SD	RECYCLING MOTOR B1 COIL CONTROL
38SE	RECYCLING MOTOR A1 COIL CONTROL
38SG	RIGHT-HAND MIXER MOTOR + SUPPLY
38SJ	RIGHT-HAND MIXER MOTOR B2 COIL CONTROL
38SK	RIGHT-HAND MIXER MOTOR A2 COIL CONTROL
38SL	RIGHT-HAND MIXER MOTOR B1 COIL CONTROL
38SM	RIGHT-HAND MIXER MOTOR A1 COIL CONTROL
38SP	LEFT-HAND MIXER MOTOR + SUPPLY
38SQ	LEFT-HAND MIXER MOTOR B2 COIL CONTROL
38SR	LEFT-HAND MIXER MOTOR A2 COIL CONTROL
38SS	LEFT-HAND MIXER MOTOR B1 COIL CONTROL
38ST	LEFT-HAND MIXER MOTOR A1 COIL CONTROL
38SU	DISTRIBUTION MOTOR + SUPPLY
38U	- REFRIGERANT GAS PRESSURE SENSOR
38X	REFRIGERANT GAS PRESSURE SENSOR SIGNAL
38Y	REFRIGERANT GAS PRESSURE SENSOR +
39G	HEADLIGHT WASHERS RELAY 1 + CONTROL
39H	HEADLIGHT WASHERS RELAY 2 + CONTROL
3AA	INJECTION LOCKING RELAY COIL - CONTROL
3AAZ	WATER PUMP RELAY/FUEL PRESSURE ADJUSTMENT- CONTROL
3ABZ	VARIABLE INLET CAMSHAFT/VACUUM PUMP RELAY CONTROL
3AC	FUEL PUMP RELAY COIL - CONTROL
3ACK	AUXILIARY FUEL TANK RELAY CONTROL
3ACL	AUXILIARY FUEL TANK PUMP CONTROL
3ACM	AUXILIARY FUEL TANK SOLENOID VALVE CONTROL
3AFZ	MINIMUM FUEL LEVEL SIGNAL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
3AJB	THROTTLE MOTOR + CONTROL
3AJC	THROTTLE MOTOR - CONTROL
3AJP	+ MANIFOLD PRESSURE SENSOR
3AJQ	MANIFOLD PRESSURE SENSOR SIGNAL
3AJR	MANIFOLD PRESSURE SENSOR EARTH
3AT	TURBOCHARGER PRESSURE SOLENOID VALVE CONTROL
3B	AIR TEMPERATURE SENSOR + SIGNAL
3BB	CANISTER BLEED SOLENOID VALVE
3BG	ENGINE SPEED SIGNAL > TDC SENSOR
3BGA	+ 5V TDC SENSOR
3BGB	TDC SENSOR SIGNAL
3BGC	TDC - SENSOR
3BL	ENGINE SPEED > TDC SENSOR - SIGNAL
3BS	IGNITION COIL CONTROL
3C	COOLANT TEMPERATURE SENSOR + SIGNAL
3CD	INJECTOR 1 COIL - CONTROL > INJECTOR 4 COIL
3CE	IGNITION COIL 1 CONTROL
3CF	IGNITION COIL 2 CONTROL
3CG	IGNITION COIL 3 CONTROL
3CH	INJECTOR 2 COIL - CONTROL > INJECTOR 3 COIL
3CP	INJECTION COMPUTER CONTROL > IGNITION POWER MODULE 2-3
3CQ	CAMSHAFT SENSOR SIGNAL
3CR	INJECTOR 1 - CONTROL
3CS	INJECTOR 2 - CONTROL
3CT	INJECTOR 3 - CONTROL
3CU	INJECTOR 4 - CONTROL
3CV	INJECTOR 1 & 4 IGNITION COIL - CONTROL
3CW	INJECTOR 2 & 3 IGNITION COIL - CONTROL
3CZ	INJECTION COMPUTER CONTROL > 1 4 IGNITION POWER MODULE
3DQ	PINKING SENSOR -
3EN	IGNITION COIL 4 CONTROL
3FB	INJECTION + > PROTECTIVE RELAY
3FB1	INJECTION + > PROTECTIVE RELAY
3FB2	INJECTION + > PROTECTIVE RELAY
3FB3	INJECTION + > PROTECTIVE RELAY
3FX	CRUISE CONTROL ON>OFF - CONTROL
3GF	UPSTREAM OXYGEN SENSOR HEATER - CONTROL
3GG	DOWNSTREAM OXYGEN SENSOR HEATER - CONTROL
3GH	UPSTREAM OXYGEN SENSOR EARTH
3GJ	DOWNSTREAM OXYGEN SENSOR EARTH
3GK	UPSTREAM OXYGEN SENSOR SIGNAL
3GL	DOWNSTREAM OXYGEN SENSOR SIGNAL
3JK	COOLANT TEMPERATURE -
3JQ	AIR TEMPERATURE -
3LN	TURBOCHARGER PRESSURE SENSOR -
3LP	TURBOCHARGER PRESSURE SENSOR + SIGNAL
3LQ	TURBOCHARGER PRESSURE SENSOR +
3LR	+ LOAD POTENTIOMETER 1
3LS	LOAD POTENTIOMETER 1 + SIGNAL
3LT	- LOAD POTENTIOMETER 1
3LU	+ LOAD POTENTIOMETER 2
3LV	- LOAD POTENTIOMETER 2
3LW	LOAD POTENTIOMETER 2 + SIGNAL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
3MN	MOTORISED THROTTLE POTENTIOMETER + 5 VOLTS
3MO	MOTORISED THROTTLE POTENTIOMETER SENSOR -
3MP	MOTORISED THROTTLE POTENTIOMETER 1 SIGNAL
3MQ	MOTORISED THROTTLE POTENTIOMETER 2 SIGNAL
3MS	ENGINE CAN H SIGNAL
3MT	ENGINE CAN L SIGNAL
3N	FUEL PUMP +
3PD	SPEED LIMITER ON/OFF CONTROL
3QK	+ CAMSHAFT SENSOR SIGNAL
3S	PINKING SENSOR 1 + SIGNAL > FRONT
3SM	MOTOR 2 CAN H SIGNAL
3SN	MOTOR 2 CAN L SIGNAL
3SV	INLET CAMSHAFT SENSOR SIGNAL
3SX	- INLET CAMSHAFT SENSOR
3SZ	VARIABLE INLET CAMSHAFT CONTROL
3WT	WATER IN DIESEL DETECTION SENSOR SIGNAL
3YC	- OIL VAPOUR REHEATER
3YL	- CAMSHAFT SENSOR
41A	FUEL LEVEL SENDER + SIGNAL
41B	FUEL LEVEL -
46CB	NAVIGATION AERIAL SIGNAL
46CC	GPS NAVIGATION SIGNAL
46CD	NAVIGATION SOUND SIGNAL
46CE	RIGHT-HAND AUDIO NAVIGATION + SIGNAL
46CG	LEFT-HAND AUDIO NAVIGATION + SIGNAL
46CH	AUDIO NAVIGATION - SIGNAL
46CJ	NAVIGATION/RADIO AM/FM SIGNAL
47F	VEHICLE SPEED SIGNAL
49L	FAN LOW SPEED RESISTANCE + CONTROL
49Q	- FAN HIGH SPEED CONTROL RELAY
49R	FAN HIGH SPEED FEED
4AH	ELECTRONIC STABILITY PROGRAM SENSOR PRIVATE CAN H SIGNAL
4AP	ELECTRONIC STABILITY PROGRAM SENSOR PRIVATE CAN L SIGNAL
4AQ	ELECTRONIC STABILITY PROGRAM ON/OFF SWITCH - CONTROL
4C	LEFT HAND FRONT WHEEL SENSOR SIGNAL
4DK	+12 VOLTS CLUSTER SENSOR
4DL	- CLUSTER
4DM	ANTI-LOCK BRAKING SYSTEM UPPER CAN SIGNAL
4DN	ANTI-LOCK BRAKING SYSTEM LOWER CAN SIGNAL
4E	LEFT HAND FRONT WHEEL SENSOR +
4G	LEFT HAND REAR WHEEL SENSOR SIGNAL
4H	LEFT HAND REAR WHEEL SENSOR +
4M	RIGHT HAND FRONT WHEEL SENSOR SIGNAL
4N	RIGHT HAND FRONT WHEEL SENSOR +
4S	RIGHT HAND REAR WHEEL SENSOR SIGNAL
4T	RIGHT HAND REAR WHEEL SENSOR +
52D	DIGITAL CONTROL EARTH
52G	1-BIT DIGITAL CONTROL
52H	2-BIT DIGITAL CONTROL
53AH	(BODY) HEIGHT SENSOR + FEED
53AK	(BODY) HEIGHT SENSOR - FEED
53W	REAR HEIGHT SENSOR SIGNAL
53X	FRONT HEIGHT SENSOR SIGNAL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
5A	BRAKE PEDAL SWITCH + SIGNAL
5BZ	GEARBOX OIL TEMPERATURE +
5DF	MULTIFUNCTION SWITCH SIGNAL 1
5DG	MULTIFUNCTION SWITCH SIGNAL 2
5DH	MULTIFUNCTION SWITCH SIGNAL 3
5DJ	MULTIFUNCTION SWITCH SIGNAL 4
5DL	MODULATING SOLENOID VALVE 3
5DU	GEAR LEVER LOCKING - CONTROL
5FM	LOWER CONTACT MULTIFUNCTION PUSH BUTTON CONTROL
5H	N+1 PUSH BUTTON CONTROL
5HG	LOCKING ON/OFF SELECTION SOLENOID VALVE CONTROL
5HH	STEPPER MOTOR COIL A CONTROL
5HK	STEPPER MOTOR COIL B CONTROL
5HL	STEPPER MOTOR COIL C CONTROL
5HM	STEPPER MOTOR COIL D CONTROL
5HN	SENSOR EARTH
5HP	CVT COMPUTER CLOCK SIGNAL
5HQ	REPROGRAMMABLE MEMORY SELECTION SIGNAL
5HR	INPUT/OUTPUT DATA SIGNAL
5HU	SECONDARY PRESSURE SENSOR SIGNAL (SECONDARY PULLEY)
5HW	PRIMARY PRESSURE SENSOR SIGNAL (PRIMARY PULLEY)
5HX	+ SENSOR FEED
5NT	PRIMARY SPEED SENSOR SIGNAL 1
5PR	SECONDARY SPEED SENSOR SIGNAL
5Q	MODULATING SOLENOID VALVE 1
5R	MODULATING SOLENOID VALVE 2
60AM	LEVEL 1 DRIVER'S FRONT AIR BAG + CONTROL
60AN	LEVEL 1 DRIVER'S FRONT AIR BAG - CONTROL
60EA	FRONT LEFT-HAND CHEST PELVIC AIRBAG + CONTROL
60EB	FRONT LEFT-HAND CHEST PELVIC AIRBAG - CONTROL
60EC	FRONT RIGHT-HAND CHEST PELVIC AIRBAG + CONTROL
60ED	FRONT RIGHT-HAND CHEST AIRBAG - CONTROL
60H	PASSENGER EURO BAG + SIGNAL
60HS	FRONT LEFT-HAND SEAT BELT SWITCH + SIGNAL
60HT	FRONT LEFT-HAND SEAT BELT SWITCH - SIGNAL
60K	PASSENGER'S FRONT AIR BAG LEVEL 1 - CONTROL
60KX	LEFT-HAND SIDE SATELLITE (AIRBAG) + SIGNAL
60KY	LEFT-HAND SIDE SATELLITE (AIRBAG) - SIGNAL
60KZ	RIGHT-HAND SIDE SATELLITE (AIRBAG) + SIGNAL
60LA	RIGHT-HAND SIDE SATELLITE (AIRBAG) - SIGNAL
60LY	LEFT-HAND CURTAIN AIRBAG + CONTROL
60LZ	LEFT-HAND CURTAIN AIRBAG - CONTROL
60MA	RIGHT-HAND CURTAIN AIRBAG + CONTROL
60MB	RIGHT-HAND CURTAIN AIRBAG - CONTROL
60NA	FRONT RIGHT-HAND INERTIA REEL + CONTROL
60NB	FRONT RIGHT-HAND INERTIA REEL - CONTROL
60NC	FRONT LEFT-HAND INERTIA REEL + CONTROL
60ND	FRONT LEFT-HAND INERTIA REEL - CONTROL
60PA	AIRBAG RECYCLING SIGNAL
60PB	PASSENGER AIRBAG OFF WARNING LIGHT + FEED
60PC	PASSENGER AIRBAG OFF WARNING LIGHT CONTROL
64C	LEFT HAND TURN SIGNAL LIGHTS CONTROL
64CA	REAR LEFT-HAND VEHICLE INDICATOR LIGHTS CONTROL VIA TOWING MODULE

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
64CB	REAR LEFT-HAND TRAILER INDICATOR LIGHTS CONTROL VIA TOWING MODULE
64D	RIGHT HAND TURN SIGNAL LIGHTS CONTROL
64DA	REAR RIGHT-HAND VEHICLE INDICATOR LIGHTS CONTROL VIA TOWING MODULE
64DB	REAR RIGHT-HAND TRAILER INDICATOR LIGHTS CONTROL VIA TOWING MODULE
64F	HAZARD WARNING LIGHTS INDICATOR LIGHT + CONTROL
64Q	FLASHER UNIT TIMER - CONTROL
65A	BRAKE LIGHTS + CONTROL
65AA	TRAILER BRAKE LIGHTS + CONTROL VIA TOWING MODULE
65L	RIGHT-HAND BRAKE LIGHT CONTROL
65M	LEFT-HAND BRAKE LIGHT CONTROL
65P	HIGH LEVEL BRAKE LIGHT CONTROL
66CA	TRAILER REVERSING LIGHTS + CONTROL VIA TOWING MODULE
66G	ENGINE PROTECTION UNIT / REVERSING SWITCH CONTROL
66H	REVERSING LIGHTS / ENGINE PROTECTION UNIT CONTROL
67A	HORN + CONTROL
67D	AUDIBLE WARNING RELAY CONTROL
67E	+ AUDIBLE WARNING RELAYED PROTECTED SUPPLY
67G	ELECTRIC CONTROL UNIT > AUDIBLE WARNING ACTIVATION SIGNAL
6A	SIGNAL L1 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6AH	DRIVER'S REAR-VIEW MIRROR UP/DOWN CONTROL > MEMORY
6AK	DRIVER'S REAR-VIEW MIRROR LEFT/RIGHT CONTROL > MEMORY 3
6AL	DRIVERS REAR-VIEW MIRROR MOTOR COMMON
6AM	DRIVER'S FOLDING REAR-VIEW MIRROR MOTOR CONTROL
6AQ	DRIVER HEATED REAR VIEW MIRROR + CONTROL
6AR	CHILD SAFETY LED - CONTROL
6AW	PASSENGER REAR VIEW MIRROR UP/DOWN CONTROL
6AX	PASSENGER REAR VIEW MIRROR RIGHT>LEFT CONTROL
6AY	PASSENGER'S REAR-VIEW MIRROR MOTOR COMMON
6AZ	PASSENGER'S FOLDING REAR-VIEW MIRROR MOTOR CONTROL
6B	SIGNAL L2 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6BA	PASSENGER'S ELECTRIC WINDOW UP CONTROL
6BB	PASSENGER'S ELECTRIC WINDOW DOWN CONTROL
6BC	EXTERNAL TEMPERATURE SENSOR + SIGNAL
6BD	EXTERNAL TEMPERATURE SENSOR ZERO VOLTS SIGNAL
6C	SIGNAL L3 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6D	SIGNAL L4 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6G	SIGNAL L5 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6H	SIGNAL C1 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6K	SIGNAL C2 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6L	SIGNAL C3 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6M	SIGNAL C4 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6N	SIGNAL C5 (MULTIPLEX DOOR INFORMATION DISPLAY CONTROL)
6P	INFORMATION DISPLAY LIGHTING + CONTROL (MULTIPLEX DOOR INFO DISPLAY CONTROL)
6Q	+ DRIVER GROUND LIGHTING
6S	CHILD SAFETY LOCK SIGNAL
6V	DRIVER ELECTRIC LOCKING CLOSING + CONTROL
6W	DRIVER DOOR OPENING MOTORS CONTROL
80A	BONNET SWITCH - SIGNAL
80AJ	ALARM SWITCH
80AL	CARD READER LOCK + CONTROL
80AM	STEERING COLUMN LOCK + CONTROL
80CB	ACCESSORIES - SIGNAL
80CC	AFTER IGNITION - SIGNAL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
80CD	STARTING - SIGNAL
86D	DECLUTCH + SIGNAL
86G	CRUISE CONTROL PROGRAMMING CONTROL
86M	CRUISE CONTROL PROGRAMMING RETURN SIGNAL
87A	LEFT HAND REAR 1st POSITION SWITCH - SIGNAL
87B	RIGHT HAND REAR 1st POSITION SWITCH - SIGNAL
87G	PASSENGER'S 1st POSITION SWITCH - SIGNAL
87H	DRIVER'S 1st POSITION SWITCH - SIGNAL
87T	BOOT LID POSITION SWITCH 1 SIGNAL
8E	+ FRONT LEFT-HAND FOG LIGHTS > RESISTANCE
8F	+ FRONT RIGHT-HAND FOG LIGHTS > RESISTANCE
96L	DRIVER'S SEATBELT REMINDER LIGHT CONTROL
9BB	REAR LEFT-HAND VEHICLE FOG LIGHT + CONTROL VIA TOWING MODULE
9BC	TOWING ATTACHMENT FOG LIGHT + CONTROL VIA TOWING MODULE
9P	PROTECTED REAR FOG LIGHTS + CONTROL
AP11	PROTECTED + AFTER IGNITION REVERSING LIGHTS FUSE
AP15	PROTECTED + AFTER IGNITION ENGINE FUNCTIONS FUSE
AP25	PROTECTED + AFTER IGNITION AIR BAG FUSE
AP4	PROTECTED + AFTER IGNITION AUTOMATIC TRANSMISSION FUSE
AP43	PROTECED + AFTER IGNITION FUSE
AP44	POWER ASSISTED STEERING ECU + AFTER IGNITION FEED FUSE PROTECTION
APCB	+ AFTER IGNITION PROTECTED / COLUMN LOCK FUSE CONTACT CLOSED AT REST
B	+ BATTERY FEED
BCP4	PROTECTED + BATTERY FEED CIRCUIT BREAKER MEMORY FUSE
BMT1	ENGINE RUNNING +BATTERY 1
BNGT	NEGATIVE BATTERY TERMINAL
BP11	PROTECTED + BATTERY FEED > PASSENGER COMPARTMENT 1
BP12	PROTECTED + BATTERY FEED > PASSENGER COMPARTMENT 2
BP13	PROTECTED + BATTERY FEED > PASSENGER COMPARTMENT 3
BP14	PROTECTED + BATTERY FEED > ABS
BP15	PROTECTED + BATTERY FEED HEATED REAR SCREEN
BP19	PROTECTED + BATTERY FEED > FLASHER UNIT TIMER
BP1C	+ BATTERY PROTECTED > PROTECTION AND SWITCHING UNIT
BP1H	PROTECTED + BATTERY FEED/MULTIMEDIA
BP23	PROTECTED + BATTERY FEED PASSENGER COMPARTMENT 4
BP25	PROTECTED + BATTERY FEED REAR SCREEN WIPER
BP26	CARPHONE PROTECTED + BATTERY FEED
BP27	PROTECTED + BATTERY FEED > ENGINE FUNCTIONS
BP3	PROTECTED + BATTERY FEED ELECTRIC DOOR LOCKING FUSE
BP31	PROTECTED + BATTERY FEED INJECTOR FUSE > FUEL PUMP
BP42	PROTECTED + BATTERY FEED > AUTOMATIC TRANSMISSION COMPUTER
BP47	PROTECTED + BATTERY FEED > TRAILER
BP55	DRIVER'S ONE-TOUCH ELECTRIC WINDOW FUSE PROTECTED + BATTERY FEED
BP69	PROTECTED BATTERY FEED > INSTRUMENT PANEL > ECU +
BP75	PROTECTED + BATTERY FEED > ALARM FUSE
BP77	BATTERY PROTECTED + FEED > UCH
BP7A	PROTECTED + BATTERY FEED > MOTOR-DRIVEN FAN ASSEMBLY MOTOR LOW SPEED FUSE
BP7B	PROTECTED + BATTERY FEED > MOTOR-DRIVEN FAN ASSEMBLY MOTOR HIGH SPEED FUSE
BP8	PROTECTED + BATTERY FEED > ANTI-LOCK BRAKING SYSTEM MOTOR
BP81	PROTECTED + BATTERY FEED > ELECTRIC POWER-ASSISTED STEERING
BP8Z	PROTECTED + BATTERY>TOWING ACCESSORIES
BP93	+ BATTERY PROTECTED SUNROOF
BPA7	BRAKE LIGHTS + BATTERY PROTECTED

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
BPDA	PROTECTED + BATTERY FEED > ALTERNATOR STARTING
BPDB	ALTERNATOR PROTECTED + BATTERY FEED
BPS1	+ BATTERY SAFETY PROTECTED
BPT	PROTECTED + BATTERY FEED TIMER
BPT5	TIMED + BATTERY FEED 5
BPT6	TIMED + BATTERY FEED 6
BPT9	TIMED + BATTERY FEED 9
BPTA	TIMED PROTECTED + BATTERY FEED A
BPZT	POSITIVE BATTERY TERMINAL
BT10	TIMED + BATTERY FEED 10
BT2	TIMED + BATTERY FEED 2
BT3	TIMED + BATTERY FEED 3
BT4	TIMED + BATTERY FEED 4
BT5	TIMED + BATTERY FEED 5
BT6	TIMED + BATTERY FEED 6
BT8	TIMED + BATTERY FEED 8
BT9	TIMED + BATTERY FEED 9
CANH	DIAGNOSTIC CAN H SIGNAL
CANL	DIAGNOSTIC CAN L SIGNAL
CPD	PROTECTED RIGHT HAND DIPPED BEAM HEADLIGHT +
CPG	PROTECTED LEFT HAND DIPPED BEAM HEADLIGHT +
HK	DIAGNOSTIC SIGNAL K
LPD	PROTECTED RIGHT HAND SIDE LIGHT +
LPDA	PROTECTED RIGHT HAND SIDE LIGHT +
LPDB	RIGHT-HAND TRAILER SIDE LIGHT + FEED VIA TOWING MODULE
LPG	PROTECTED LEFT HAND SIDE LIGHT +
LPGA	PROTECTED LEFT HAND SIDE LIGHT +
LPGB	LEFT-HAND TRAILER SIDE LIGHT + FEED VIA TOWING MODULE
M	EARTH
MAE	CARAVAN ELECTRICAL EARTH
MAH	ANTI-LOCK BRAKING SYSTEM ELECTRICAL EARTH
MAM	DASHBOARD LEFT-HAND CROSS MEMBER ELECTRICAL EARTH
MAN	DASHBOARD RIGHT-HAND CROSS MEMBER ELECTRICAL EARTH
MAO	DASHBOARD CROSS MEMBER RADIO EARTH
MAS	FRONT LEFT-HAND SIDE MEMBER ELECTRICAL EARTH
MAU	RIGHT DASHBOARD CROSS MEMBER ELECTRICAL EARTH 2
MBJ	UPPER BULKHEAD CROSS MEMBER ELECTRICAL EARTH
MBL	UCH ELECTRICAL EARTH 1
MBM	UCH ELECTRICAL EARTH 2
ME	BODYWORK GENERAL ELECTRICAL EARTH
MF	REAR RIGHT-HAND ELECTRICAL EARTH
MG	REAR LEFT-HAND ELECTRICAL EARTH
MH	ENGINE EARTH
MHA	ENGINE GENERAL ELECTRICAL EARTH
MHB	FRONT LEFT-HAND SIDE MEMBER ELECTRICAL EARTH 3
MHD	ENGINE FRONT LEFT-HAND SIDE MEMBER ELECTRIC EARTH
MT	RADIO ELECTRICAL EARTH
NAA	UCH ELECTRONIC EARTH 1
NAM	UPPER LEFT-HAND CROSS MEMBER ELECTRONIC EARTH
NH	ENGINE EARTH
NM	AIRBAG ELECTRONIC EARTH
NUA	PROTECTION & SWITCHING UNIT 1 ELECTRONIC EARTH
RPD	RIGHT HAND PROTECTED MAIN BEAM HEADLIGHT +

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
RPG	LEFT HAND PROTECTED MAIN BEAM HEADLIGHT +
S2	ACCESSORIES RELAY CONTROL
SP1B	PROTECTED + ACCESSORIES FEED > WINDSCREEN AND REAR SCREEN WASHER
SP3	PROTECTED + ACCESSORIES > HEATER
SP4G	CIGARETTE LIGHTER PROTECTED + ACCESSORIES FEED
TB1	PINKING SENSOR SCREENING BRAID
TB13	AM/FM AERIAL SHIELDING
TB15	NAVIGATION AERIAL SHIELDING
TB36	SCREEN PRINTED RADIO AERIAL SHIELDING (INTEGRATED IN REAR SCREEN)
TB37	LINE IN SHIELDED CABLE
TB39	AM/FM1 RADIO SHIELDING BRAID
TB40	FM2 RADIO SHIELDING BRAID
TB41	GPS NAVIGATION SHIELDING BRAID
TB53	USB SHIELDED CABLE
TB59	AUDIO C_BOX SHIELDED CABLE
TB81	NAVIGATION AUDIO SHIELDED CABLE
TB82	NAVIGATION/RADIO AM/FM SHIELDED CABLE