

INDEX OF FUNCTIONS

| FUNCTIONS | PLATE NUMBERS |
|-----------|--|
| 1 - 14 | EARTH |
| 15 - 16 | POWER SUPPLY |
| 17 - 19 | NAVIGATION ASSISTANCE AND COMMUNICATION ACCESSORIES |
| 20 | PARKING DISTANCE CONTROL |
| 21 | AIR BAG AND SEAT BELT PRETENSIONER |
| 22 | REMOTE LOCKING AUDIBLE ALERT |
| 23 - 24 | CIGARETTE LIGHTER |
| 25 | INTERNAL AERIALS FOR HANDS-FREE STARTING |
| 26 - 27 | ANTI-LOCK BRAKING SYSTEM AND DIRECTIONAL STABILITY CONTROL |
| 28 - 29 | ANTI-THEFT TRACKER |
| 30 | STARTER AUTHORISATION |
| 31 | ELECTROMAGNETIC HORN |
| 32 - 33 | CONTINUOUSLY VARIABLE GEARBOX |
| 34 | RAIN AND LIGHT SENSOR |
| 35 - 36 | CHARGE CIRCUIT |
| 37 - 38 | STARTING CIRCUIT |
| 39 | CENTRAL DOOR LOCKING CONTROL |
| 40 - 41 | UNDER STEERING WHEEL CONTROL |
| 42 | AIR CONDITIONING COMPRESSOR |
| 43 - 44 | DOOR LOCKING |
| 45 | TAILGATE LOCKING |
| 46 | FUEL FILLER FLAP LOCKING |
| 47 - 48 | AIR CONDITIONING |
| 49 | AUTOMATIC AIR CONDITIONING |
| 50 | BONNET SWITCH |
| 51 | ANTI-THEFT SWITCH |
| 52 | CLUTCH PEDAL SWITCH |
| 53 | CLUTCH PEDAL END OF TRAVEL SWITCH |
| 54 | DISCHARGE LAMP CORRECTOR |
| 55 - 56 | REAR WINDOW DE-ICING |
| 57 | ELECTRIC POWER ASSISTED STEERING |
| 58 | LUGGAGE COMPARTMENT LIGHTING |
| 59 | COURTESY MIRROR LIGHTING |
| 60 - 61 | COURTESY LIGHTING |
| 62 | DOOR LIGHTING |
| 63 - 64 | LIGHTING DIMMER |
| 65 | STORAGE COMPARTMENT LIGHTING |
| 66 | FRONT WINDSCREEN WASHER AND WIPER |
| 67 | REAR FOGLIGHTS |
| 68 | FRONT FOGLIGHTS |
| 69 | DIPPED HEADLIGHTS |
| 70 - 71 | REVERSING LIGHTS |
| 72 | SIDELIGHTS |
| 73 | MAIN BEAM HEADLIGHTS |
| 74 | BRAKE LIGHT AND HIGH-LEVEL LIGHTS |
| 75 | DIRECTION INDICATORS AND HAZARD WARNING LIGHTS |
| 76 | OIL LEVEL INDICATOR |
| 77 | FUEL LEVEL AND FUEL PUMP |
| 78 | OIL PRESSURE INDICATOR |

INDEX OF FUNCTIONS

| FUNCTIONS | PLATE NUMBERS |
|-----------|---|
| 79 - 83 | ELECTRONIC INJECTION |
| 84 | HEADLIGHT WASHERS |
| 85 | CARD READER AND STARTER |
| 86 | REAR ELECTRIC WINDOWS |
| 87 | FRONT PASSENGER ELECTRIC WINDOWS |
| 88 - 89 | DRIVER'S DOOR MULTIPLEXING |
| 90 | POWER FUSE BOARD |
| 91 - 94 | PASSENGER COMPARTMENT FUSE AND RELAY BOARD |
| 95 | ENGINE FUSE AND RELAY BOARD |
| 96 | ACCESSORIES SOCKET |
| 97 | CARAVAN SOCKET |
| 98 | DIAGNOSTICS SOCKET |
| 99 - 101 | RADIO AND COMMUNICATION SYSTEMS |
| 102 | ENGINE COOLING SYSTEM |
| 103 | IN HEADLIGHT HEIGHT ADJUSTMENT |
| 104 | SPEED REGULATOR |
| 105 | AUTO-DIMMING INTERNAL REAR-VIEW MIRROR |
| 106 | ELECTRIC EXTERIOR REAR-VIEW MIRRORS |
| 107 - 109 | INSTRUMENT PANEL |
| 110 | HANDBRAKE WARNING LIGHT |
| 111 | LOW BRAKE FLUID WARNING LIGHT |
| 112 | ELECTRIC SUNROOF |
| 113 - 114 | TRANSPONDER |
| 115 | UCH SECTION 1 |
| 116 - 117 | UCH SECTION 2 |
| 118 - 119 | PROTECTION AND SWITCHING UNIT PASSENGER COMPARTMENT SECTION |
| 120 | PROTECTION AND SWITCHING UNIT ENGINE SECTION |
| 121 | KEYLESS VEHICLE AND HANDS-FREE ACCESS |
| 122 | STEERING COLUMN LOCK |